



Solaris™ Reference Manual for
SMCC-Specific Software

Solaris 2.6 Hardware: 3/98

Sun Microsystems, Inc.
901 San Antonio Road
Palo Alto, CA 94303
U.S.A. 650-960-1300

Part No. 805-3515-10
March 1998, Revision A

Copyright 1998 Sun Microsystems, Inc., 901 San Antonio Road, Palo Alto, CA 94303 U.S.A. All rights reserved.

This product or document is protected by copyright and distributed under licenses restricting its use, copying, distribution, and decompilation. No part of this product or document may be reproduced in any form by any means without prior written authorization of Sun and its licensors, if any. Third-party software, including font technology, is copyrighted and licensed from Sun suppliers.

Parts of the product may be derived from Berkeley BSD systems, licensed from the University of California. UNIX is a registered trademark in the U.S. and other countries, exclusively licensed through X/Open Company, Ltd.

Sun, Sun Microsystems, the Sun logo, SunSoft, SunDocs, SunExpress, Solstice, Solstice SyMON, SunVTS, Sun MediaCenter, and Solaris are trademarks, registered trademarks, or service marks of Sun Microsystems, Inc. in the U.S. and other countries. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. in the U.S. and other countries. Products bearing SPARC trademarks are based upon an architecture developed by Sun Microsystems, Inc.

The OPEN LOOK and Sun™ Graphical User Interface was developed by Sun Microsystems, Inc. for its users and licensees. Sun acknowledges the pioneering efforts of Xerox in researching and developing the concept of visual or graphical user interfaces for the computer industry. Sun holds a non-exclusive license from Xerox to the Xerox Graphical User Interface, which license also covers Sun's licensees who implement OPEN LOOK GUIs and otherwise comply with Sun's written license agreements.

RESTRICTED RIGHTS: Use, duplication, or disclosure by the U.S. Government is subject to restrictions of FAR 52.227-14(g)(2)(6/87) and FAR 52.227-19(6/87), or DFAR 252.227-7015(b)(6/95) and DFAR 227.7202-3(a).

DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID.

Copyright 1998 Sun Microsystems, Inc., 901 San Antonio Road, Palo Alto, Californie 94303 Etats-Unis. Tous droits réservés.

Ce produit ou document est protégé par un copyright et distribué avec des licences qui en restreignent l'utilisation, la copie, la distribution, et la décompilation. Aucune partie de ce produit ou document ne peut être reproduite sous aucune forme, par quelque moyen que ce soit, sans l'autorisation préalable et écrite de Sun et de ses bailleurs de licence, s'il y en a. Le logiciel détenu par des tiers, et qui comprend la technologie relative aux polices de caractères, est protégé par un copyright et licencié par des fournisseurs de Sun.

Des parties de ce produit pourront être dérivées des systèmes Berkeley BSD licenciés par l'Université de Californie. UNIX est une marque déposée aux Etats-Unis et dans d'autres pays et licenciée exclusivement par X/Open Company, Ltd.

Sun, Sun Microsystems, le logo Sun, SunSoft, SunDocs, SunExpress, Solstice, Solstice SyMON, SunVTS, Sun MediaCenter, et Solaris sont des marques de fabrique ou des marques déposées, ou marques de service, de Sun Microsystems, Inc. aux Etats-Unis et dans d'autres pays. Toutes les marques SPARC sont utilisées sous licence et sont des marques de fabrique ou des marques déposées de SPARC International, Inc. aux Etats-Unis et dans d'autres pays. Les produits portant les marques SPARC sont basés sur une architecture développée par Sun Microsystems, Inc.

L'interface d'utilisation graphique OPEN LOOK et Sun™ a été développée par Sun Microsystems, Inc. pour ses utilisateurs et licenciés. Sun reconnaît les efforts de pionniers de Xerox pour la recherche et le développement du concept des interfaces d'utilisation visuelle ou graphique pour l'industrie de l'informatique. Sun détient une licence non exclusive de Xerox sur l'interface d'utilisation graphique Xerox, cette licence couvrant également les licenciés de Sun qui mettent en place l'interface d'utilisation graphique OPEN LOOK et qui en outre se conforment aux licences écrites de Sun.

CETTE PUBLICATION EST FOURNIE "EN L'ETAT" ET AUCUNE GARANTIE, EXPRESSE OU IMPLICITE, N'EST ACCORDEE, Y COMPRIS DES GARANTIES CONCERNANT LA VALEUR MARCHANDE, L'APTITUDE DE LA PUBLICATION A REpondre A UNE UTILISATION PARTICULIERE, OU LE FAIT QU'ELLE NE SOIT PAS CONTREFAISANTE DE PRODUIT DE TIERS. CE DENI DE GARANTIE NE S'APPLIQUERAIT PAS, DANS LA MESURE OU IL SERAIT TENU JURIDIQUEMENT NUL ET NON AVENU.



Please
Recycle



Adobe PostScript

Contents

Preface v

1. User Commands (1) 1-1

smc_copy 1-1

smc_ls 1-3

smc_rm 1-4

smc_tar 1-5

symon 1-7

2. Maintenance Commands (1M) 1M-10

afbconfig 1M-10

cfgadm 1M-18

cvcd 1M-27

dr_daemon 1M-28

luxadm 1M-29

sm_configd 1M-40

sm_confsymon 1M-41

sm_control 1M-43

sm_egd 1M-44

sm_krd 1M-46

sm_logscand 1M-47

sm_symond 1M-48
smc_ftpd 1M-50
smc_gettacl 1M-54
smc_settacl 1M-55
ssp-config 1M-57
ssp-unconfig 1M-58
sunvts 1M-59
vtsk 1M-60
vtsprobe 1M-61
vtstty 1M-64
vtsui 1M-66
vtsui.ol 1M-67

3. Miscellaneous Library Functions (3) 3-68

config_admin (3X), 3-68

4. File Formats (4) 4-75

auth_checker.tcl 4-75
auth_list.tcl 4-76
event_gen.tcl 4-77
logscan.tcl 4-78
rules.tcl 4-79
sm_symond.conf 4-80

5. Devices and Network Interfaces (7) 7-81

afb 7-81
cvc 7-82
cvcredir 7-83
dr 7-84
idn 7-85

Preface

The *Solaris Reference Manual for SMCC-Specific Software* contains manual pages (man pages) for software provided to SMCC customers with the Solaris 2.6 Hardware: 3/98 product. These supplement the man pages provided in the general *Solaris 2.6 Reference Manual*.

Before you can access some of the information published in this book through the `man` command, you may need to install software from the SMCC Supplement CD for your Solaris release. In most cases, when you install a software cluster from the SMCC Supplement CD, man pages about the software in that cluster will be automatically installed. For information about installing the man page software, refer to the *Vendor Value-Added Software* section of the *Solaris Information Library* for your Solaris release.

How This Book Is Organized

This manual contains manual pages in alphabetical order within each man page category. Supplemental man pages are included for the following categories:

- User Commands (1)
- Maintenance Commands (1M)
- Miscellaneous Library Functions (3)
- File Formats (4)
- Device and Network Interfaces (7)

Ordering Sun Documents

SunDocsSM is a distribution program for Sun Microsystems technical documentation. Contact SunExpress for easy ordering and quick delivery. You can find a listing of available Sun documentation on the World Wide Web.

TABLE P-1 SunExpress Contact Information

Country	Telephone	Fax
Belgium	02-720-09-09	02-725-88-50
Canada	1-800-873-7869	1-800-944-0661
France	0800-90-61-57	0800-90-61-58
Germany	01-30-81-61-91	01-30-81-61-92
Holland	06-022-34-45	06-022-34-46
Japan	0120-33-9096	0120-33-9097
Luxembourg	32-2-720-09-09	32-2-725-88-50
Sweden	020-79-57-26	020-79-57-27
Switzerland	0800-55-19-26	0800-55-19-27
United Kingdom	0800-89-88-88	0800-89-88-87
United States	1-800-873-7869	1-800-944-0661

World Wide Web: <http://www.sun.com/sunexpress/>

Sun Documentation on the Web

The `docs.sun.com` web site enables you to access Sun technical documentation on the World Wide Web. You can browse the `docs.sun.com` archive or search for a specific book title or subject at <http://docs.sun.com>.

Sun Welcomes Your Comments

We are interested in improving our documentation and welcome your comments and suggestions. You can email your comments to us at smcc-docs@sun.com. Please include the part number of your document in the subject line of your email.

NAME	smc_copy – copies content from one Sun MediaCenter server to another
SYNOPSIS	<p>smc_copy [-p] [-s] [-t] <i>source destination</i></p> <p>where <i>source</i> and <i>destination</i> each have the form <i>hostname:<filename></i> or <i><filename></i>. Specifying only <i><filename></i> implies that a title is stored on or being copied to the machine from which you are invoking smc_copy. Options are described below.</p>
AVAILABILITY	Available with the Sun MediaCenter Server software.
DESCRIPTION	<p>The smc_copy utility copies content, specified by a title name as returned by smc_ls (1), from one Sun MediaCenter server to another.</p> <p>The syntax for smc_copy is similar to that of rcp (1), with the following exceptions:</p> <ul style="list-style-type: none"> -- You cannot specify a path to a title, in either the source or destination argument. Sun MediaCenter software looks for and stores titles and associated data in hardcoded locations. -- You cannot specify a username in an smc_copy source or destination argument. <p>As with rcp, you can invoke smc_copy on one machine to copy content from a second machine to a third machine. The machine on which you invoke smc_copy does not have to be a Sun MediaCenter server. To run smc_copy, you must have the smc_copy binary installed on the local machine.</p> <p>In the course of the copy operation, smc_copy creates a new title on a destination Sun MediaCenter server. You can rename the destination title in an smc_copy command.</p> <p>When you copy a title to another Sun MediaCenter, you, the copier, own the title access control list for that file. Other users can play the title, but cannot copy it to another server or remove it. To extend access to the newly-copied file, use smc_setacl (1M).</p>
OPTIONS	<p>The smc_copy utility has the following options:</p> <ul style="list-style-type: none"> p Preserve create time in destination file. Otherwise, the create time becomes the current time for the newly copied file. s Run in single-threaded mode. By default, the utility runs in multiple threads. This option is used for internal test purposes. t Display transfer statistics in shell from which you invoke the utility.
EXAMPLES	<p>The following example copies the title heidi from the Sun MediaCenter server server2 to the local Sun MediaCenter server, server1.</p> <pre>server1% smc_copy server2:heidi heidi</pre>

The following command accomplishes the same function as the preceding:

```
server1% smc_copy server2:heidi server1:heidi
```

The following command copies content from a local to a remote Sun MediaCenter server, renaming the title in the process:

```
server1% smc_copy heidi server2:drama
```

The following command performs the same function as the preceding, except the title is not renamed:

```
server1% smc_copy heidi server2:heidi
```

The following command copies the title **heidi** from Sun MediaCenter server **server1** to the Sun MediaCenter server **server2** and renames the title in the process. The command is invoked from a third-party machine, **machine_x**, which is not an Sun MediaCenter server.

```
machine_x% smc_copy server1:heidi server2:drama
```

SEE ALSO

smc_tar (1), smc_ls (1), smc_rm (1), smc_settacl (1M), smc_gettacl (1M), smc_ftpd (1M)

NAME	<code>smc_ls</code> – list playable titles on a Sun MediaCenter server
SYNOPSIS	<code>smc_ls [smc_svr_name]</code>
AVAILABILITY	Available with the Sun MediaCenter Server software.
DESCRIPTION	The <code>smc_ls</code> list the titles available for playback on a local or remote Sun MediaCenter server. You can play these titles through the facilities of the Media Stream Manager. For each title stored on a Sun MediaCenter server, <code>smc_ls</code> returns the title name, the normal play time, the available playback speeds, and an indication of whether the title is in use or is free.
OPTIONS	The <code>smc_ls</code> command allows you to specify the name of a remote Sun MediaCenter server, to obtain a title list from that server. To run <code>smc_ls</code> remotely, you need only the <code>smc_ls</code> binary, which is installed with the Sun MediaCenter software.
EXAMPLES	<p>The following example lists all playable content on a local Sun MediaCenter server:</p> <pre>server% smc_ls Title Status NPT Format Available Speeds terminator2 cm 01:52:30 MPEGTCE 1000,4000,-4000 dr_zhivago FREE 02:48:21 MPEG1SYS 1000,4000,-4000 mary_poppins cm,msm 02:03:17 MPEGPS 1000,-1000</pre> <p>Note, under "Available Speeds", that "1000" represents normal speed, forward direction. A value "4000" represents four times normal speed; "-4000" represents four times normal speed in the reverse direction.</p> <p>Under "Status", FREE indicates the title is not in use. The string "cm" indicates the title is in use by the Content Manager (for example, if it is being copied to another server). The string "msm" indicates the title is being played (by the Media Stream Manager).</p>
SEE ALSO	<code>smc_tar</code> (1), <code>smc_rm</code> (1), <code>smc_ftpd</code> (1M)

NAME	smc_rm – remove content from Media File System on a Sun MediaCenter server
SYNOPSIS	smc_rm [<i>smc_svr_name:</i>] <i><title1></i> [<i>smc_svr_name:</i>] <i><title2></i> ...
AVAILABILITY	Available with the Sun MediaCenter Server software.
DESCRIPTION	<p>The smc_rm removes content from the Media File System (MFS) on a Sun MediaCenter server. The command takes as an argument one or more titles. Optionally, each title can be prepended with the name of a remote Sun MediaCenter server. smc_rm removes a specified title, including the index file and all MPEG files referred to by that title.</p> <p>You can run smc_rm on a remote machine that is not a Sun MediaCenter server. All that is required to run the utility is the smc_rm binary, which you can copy from a Sun MediaCenter server.</p>
OPTIONS	The smc_rm command allows you to specify a remote Sun MediaCenter server for each title specified in a command line.
EXAMPLES	<p>The following example removes all content associated with the titles Bambi, on the local Sun MediaCenter server, and Quo Vadis, on the Sun MediaCenter server named "vidserver".</p> <pre>server% smc_rm bambi vidserver:quo_vadis</pre>
SEE ALSO	smc_tar (1), smc_ls (1), smc_copy (1)

NAME	smc_tar – move content between tar device or file and the Media File System on Sun MediaCenter server
SYNOPSIS	smc_tar <i>t</i> <i>c</i> <i>x</i> [<i>v</i>] [<i>b</i>] [<i>w</i>] <i>f</i> <i>device</i> [<i>blksize</i>]
AVAILABILITY	Available with the Sun MediaCenter Server software.
DESCRIPTION	<p>The smc_tar command loads properly prepared multimedia content from a tar device, such as an 8mm tape, or a file onto the Media Filesystem (MFS). Content must be prepared according to the rules specified in the Sun MediaCenter software documentation. These rules include the following:</p> <ul style="list-style-type: none"> • a single title per tar device; • a Table of Contents (TOC) file for each title; • an index file for each title; • a separate MPEG stream for each playback speed and direction different from normal speed, forward direction. <p>In the course of loading content, smc_tar parses the TOC file, does error-checking with respect to the index file, and converts the MPEG bit streams to MFS files.</p> <p>Note that ftp, in conjunction with the Sun MediaCenter ftp daemon, is the preferred method of loading content onto a Sun MediaCenter server.</p> <p>With the c option, you can use smc_tar to back up content from a Sun MediaCenter server to tar device or file.</p> <p>You can use smc_tar from a machine that is not a Sun MediaCenter server and from a remote Sun MediaCenter server, to move content between a server and a local or remote tar device or file. You need only the smc_tar binary, available on a Sun MediaCenter server, to run the utility.</p> <p>The smc_tar command is analogous to the Unix filesystem tar (1) utility.</p> <p>smc_tar has a single mandatory argument, f, which precedes the name of the tar device.</p>
OPTIONS	<p>b <i>blksize</i></p> <p>Where <i>blksize</i> is the block size that was used to create the tar contents. <i>blksize</i> must be a multiple of 20 and, if present, is the last argument in the smc_tar command line. One block equals 512 bytes. The recommended block size is 500, which is 256000 bytes. Most operating systems, including Solaris, have a default block size of 20.</p> <p>c Specifies creation of a tar file or copying a title from the Sun MediaCenter server to a tar device. Requires a source file argument, one or more of <i><server>:<title></i>, where <i><title></i> can be the wildcard asterisk, meaning all titles on a server. Used primarily for backup.</p> <p>t Display a table of contents of the specified tar device or file.</p>

- v** Verbose. Display progress of command.
- w** Prompt user before overwriting already-existing content.
- x** Specifies extraction from the named tar device or file.

<device>

The tar device from which you are extracting content.

EXAMPLES

The following example loads content from the tar device `/dev/rmt/0`, specifying a block size of 40 and prompting you before overwriting existing files:

```
server% smc_tar xwbf 40 /dev/rmt/0
```

The following command copies all of the files on a remote server to a local tape device:

```
remote_host% smc_tar cf /dev/rmt/0 smc_server:
```

Note that you must use a backslash (`\`) to escape the asterisk.

The following command gives you a table of contents for the titles stored in a tape device on a remote Sun MediaCenter server:

```
host% smc_tar tvf remote_server:/dev/rmt/0
```

SEE ALSO

`tar (1)`, `smc_ls (1)`, `smc_rm (1)`, `smc_settacl (1M)`, `smc_gettacl (1M)`, `smc_ftpd (1M)`

NAME	symon – bring up the Solstice SyMON system monitor console
SYNOPSIS	<pre> symon [-colorMap] [-cm] [*colorMap] [-dragThreshold <i>pixels</i>] [*dragThreshold <i>pixels</i>] [-flashDuration <i>milliseconds</i>] [-fd <i>milliseconds</i>] [*flashDuration <i>milliseconds</i>] [-flashInterval <i>milliseconds</i>] [-fi <i>milliseconds</i>] [*flashInterval <i>milliseconds</i>] [-heartbeatInterval <i>intervals</i>] [-hi <i>intervals</i>] [*heartbeatInterval <i>intervals</i>] [-interval <i>intervals</i>] [-i <i>intervals</i>] [*interval <i>intervals</i>] [-installDir <i>path</i>] [-I <i>path</i>] [*installDir <i>path</i>] [-minWait <i>seconds</i>] [-mw <i>seconds</i>] [*minWait <i>seconds</i>] [-pruneTime <i>minutes</i>] [-pt <i>minutes</i>] [*pruneTime <i>minutes</i>] [-session <i>file</i>] [*session <i>file</i>] [-target <i>machine</i>] [-t <i>machine</i>] [*target <i>machine</i>] [-tempPruneTime <i>minutes</i>] [-tpt <i>minutes</i>] [*tempPruneTime <i>minutes</i>] [-vtsui <i>file</i>] [*vtsui <i>file</i>] [-help] [-h] [-?] </pre>
AVAILABILITY	SUNWsymon
DESCRIPTION	<p>symon is the primary user interface to the Solstice SyMON system monitor. Invoking symon brings up the launcher window, from which the seven Solstice SyMON consoles are launched:</p> <ul style="list-style-type: none"> • Event Viewer • Kernel Data Catalog • Physical View • Log Viewer • Logical View • Process Viewer • On-line Diagnostics <p>For further details on the operation of symon please see the <i>Solstice SyMON User's Guide</i>.</p>
OPTIONS	<p>-colorMap Use a private color map for the Launcher and Physical View windows to ensure correct colors in the images. May result in colormap flashing of images and of other applications, such as the Netscape browser (default is to use the default colormap).</p> <p>-cm Same as -colorMap</p> <p>*colorMap Same as -colorMap</p> <p>-flashDuration Set time that flashes of the system indicator on the launcher console will last (default is 30 milliseconds).</p>

-dragthreshold	Sets the mouse drag threshold for Sysmeters (default is 10 pixels).
*dragthreshold	Same as -dragthreshold
-fd	Same as -flashDuration
*flashDuration	Same as -flashDuration
-flashInterval	Set time interval between flashes of the system indicator on the launcher console (default is 2000 milliseconds).
-fi	Same as -flashInterval
*flashInterval	Same as -flashInterval
-heartbeatInterval	Set the polling time for the heartbeat check for agents (default is 10 intervals).
-hi	Same as -heartbeatInterval
-installDir	Set the directory root to examine for tcl files, etc. (default is /opt/SUNWsymon).
-I	Same as -installDir
*installDir	Same as -installDir
-interval	Set the polling interval for agents (default is 10 intervals).
-i	Same as -interval
-minWait	Set a minimum wait time between polls/updates (default is 1 second between the end of one poll and the start of the next).
-mw	Same as -minWait
-pruneTime	Time after which unchanged data (old processes) is pruned from the sm_krd (Kernel Reader) hierarchy (default is 120 minutes).
-pt	Same as -pruneTime
-session	Specifies a Tcl file, which defines the layout and contents of a Solstice SyMON instance. This file is read when Solstice SyMON starts up to restore a previously saved layout.
-tempPruneTime	Time after which unchanged Config Reader data (board temperature) will be pruned from sm_configd hierarchy (default is 1440 minutes).
-tpt	Same as -tempPruneTime
-target	System to be monitored.
-t	Same as -target
-vtsui	Name of SunVTS user interface binary (default is vtsui).
-help	Listing of arguments.
-h	Same as -help

	-?	Same as -help
ENVIRONMENT	TCL_LIBRARY	Location of the Tcl library.
	XFILESEARCHPATH	Location of the X Files.
	DTAPPSEARCHPATH	Location of the CDE X Defaults files.
	DTDATABASESEARCHPATH	Location of the CDE database files.
	DTHELPSSEARCHPATH	Location of the CDE help files.
	XMICONSEARCHPATH	Location of the symon icons.
FILES	common.tcl	Common Tcl routines for the display.
	cpu_utilization.tcl	Tcl routines to define the chart for CPU utilization.
	memory_usage.tcl	Tcl routines to define the chart for memory usage.
	init.tcl	Tcl routines to initialize symon .
	queue_lengths.tcl	Tcl routines to define the chart for queue lengths.
	sysmeter.tcl	Tcl routines to define the chart for System Meters.
NOTES	<p>Solstice SyMON uses ASCII-format Tcl files as a means of saving and restoring the state of the program's GUI. Currently, this feature only works for system meters, the process viewer, and the event viewer. Some Tcl files are provided with the Solstice SyMON product to serve as examples. Normally these Tcl files should be created by using the GUI to configure the desired windows, and then saved by invoking save in a system meter (to save the state of one system meter) or in the kernel data catalog window (to save the state of all system meters).</p> <p>Symon examines or creates the directory \$HOME/.symon and creates a directory structure there to contain Tcl files that the user has created and links to Tcl files in the official installation. The purpose is that both sets of files may be browsed easily at the same time in a single file selection dialog.</p> <p>When a Solstice SyMON release is run for the first time by a user, it will create symbolic links in the user's directory (\$HOME/.symon/lib/tcl/C) that point to any Tcl files in the installation directory (usually /opt/SUNWsymon/lib/tcl/C). Thus, any new Tcl files in a new release will be picked up. If the user has files or links in their directory that match the names of files in the official directory, then links will be removed and remade to the official files. User files matching official file names will result in a dialog box in Solstice SyMON that explains the options the user has at that point: Either to keep the local file, to remove it and have Solstice SyMON link to the official version, or to manually merge the two files.</p>	
SEE ALSO	sm_configd(1M), sm_confsymon(1M), sm_control(1M), sm_egd(1M), sm_krd(1M), sm_logscand(1M), sm_symond(1M), auth_checker.tcl(4), auth_list.tcl(4), event_gen.tcl(4), logscan.tcl(4), rules.tcl(4), sm_symond.conf(4)	

NAME	afbconfig – configure the AFB Graphics Accelerator
SYNOPSIS	<pre> /usr/sbin/afbconfig [-dev <i>device-filename</i>] [-res <i>video-mode</i> [now try] [noconfirm nocheck]] [-file machine system] [-deflinear true false] [-defoverlay true false] [-linearorder first last] [-overlayorder first last] [-expvis enable disable] [-sov enable disable] [-maxwids <i>n</i>] [-extovl enable disable] [-g <i>gamma-correction-value</i>] [-gfile <i>gamma-correction-file</i>] [-propt] [-prconf] [-defaults] /usr/sbin/afbconfig [-propt] [-prconf] /usr/sbin/afbconfig [-help] [-res ?] </pre>
AVAILABILITY	SUNWafbcf
DESCRIPTION	<p>afbconfig configures the AFB Graphics Accelerator and some of the X11 window system defaults for AFB.</p> <p>The first form of afbconfig shown in the synopsis above stores the specified options in the OWconfig file. These options will be used to initialize the AFB device the next time the window system is run on that device. Updating options in the OWconfig file provides persistence of these options across window system sessions and system reboots.</p> <p>The second and third forms which invoke only the -prconf, -propt, -help, and -res ? options do not update the OWconfig file. Additionally, for the third form all other options are ignored.</p> <p>Options may be specified for only one AFB device at a time. Specifying options for multiple AFB devices requires multiple invocations of afbconfig.</p> <p>Only AFB-specific options can be specified through afbconfig. The normal window system options for specifying default depth, default visual class and so forth are still specified as device modifiers on the openwin command line (see the Xsun(1) manual page in the Openwindows Reference Manual).</p> <p>The user can also specify the OWconfig file that is to be updated. By default, the machine-specific file in the /etc/openwin directory tree is updated. The -file option can be used to specify an alternate file to use. For example, the system-global OWconfig file in the /usr/openwin directory tree can be updated instead.</p>

Both of these standard OWconfig files can only be written by root. Consequently, the **afbconfig** program, which is owned by the root user, always runs with setuid root permission.

OPTIONS

- dev** *device-filename*
Specifies the AFB special file. The default is **/dev/fbs/afb0**.
- file** **machine** | **system**
Specifies which OWconfig file to update. If **machine**, the machine-specific OWconfig file in the **/etc/openwin** directory tree is used. If **system**, the global OWconfig file in the **/usr/openwin** directory tree is used. If the file does not exist, it is created.
- res** *video-mode* [**now** | **try** [**noconfirm** | **nocheck**]]
Specifies the video mode used to drive the monitor connected to the specified AFB device.

The format of these built-in video modes is:

widthxheightxrate

where **width** is the screen width in pixels, **height** is the screen height in pixels, and **rate** is the vertical frequency of the screen refresh. The **s** suffix of **960x680x112s** and **960x680x108s** means that these are stereo video modes. The **i** suffix of **640x480x60i** and **768x575x50i** designates interlaced video timing. If absent, non-interlaced timing will be used. As a convenience, **-res** also accepts formats with '@' (at sign) in front of the refresh rate instead of x. For example: **1280x1024@76**. Note, some video-modes, supported by AFB, may not be supported by the monitor. The list of video-modes supported by the AFB device and the monitor can be obtained by running **afbconfig** with the **-res ?** option (the third form shown in the command synopsis above). A list of all possible video-modes supported on AFB is shown below.

```
1024x768x60
1024x768x70
1024x768x75
1024x768x77
1024x800x84
1152x900x66
1152x900x76
1280x800x76
1280x1024x60
1280x1024x67
1280x1024x76
960x680x112s   (Stereo)
960x680x108s  (Stereo)
640x480x60
640x480x60i   (Interlaced)
768x575x50i   (Interlaced)
```

Symbolic names

For convenience, some of the above video modes have symbolic names defined for them. Instead of the form **width x height x rate**, one of these names may be supplied as the argument to **-res**. The meaning of the symbolic name **none** is that when the window system is run the screen resolution will be the video mode that is currently programmed in the device.

Name	Corresponding Video Mode
svga	1024x768x60
1152	1152x900x76
1280	1280x1024x76
stereo	960x680x112s
ntsc	640x480x60i
pal	768x575x50i
none	(see text above)

The **-res** option also accepts additional, optional arguments immediately following the video mode specification. Any or all of these may be present.

now If present, not only will the video mode be updated in the OWconfig file, but the AFB device will be immediately programmed to display this video mode. (This is useful for changing the video mode before starting the window system).

Note – It is inadvisable to use this suboption with **afbconfig** while the configured device is being used (e.g. while running the window system); unpredictable results may occur. To run **afbconfig** with the **now** suboption, first bring the window system down. If the **now** suboption is used within a window system session, the video mode will be changed immediately, but the width and height of the affected screen won't change until the window system is exited and reentered again. In addition, the system may not recognize changes in stereo mode. Consequently, this usage is strongly discouraged.

noconfirm Using the **-res** option, the user could potentially put the system into an usable state, a state where there is no video output. This can happen if there is ambiguity in the monitor sense codes for the particular code read. To reduce the chance of this, the default behavior of **afbconfig** is to print a warning message to this effect and to prompt the user to find out if it is okay to continue. The **noconfirm** option instructs **afbconfig** to bypass this confirmation and to program the requested video mode anyway. This option is useful when **afbconfig** is being run from a shell script.

nocheck If present, the normal error checking based on the monitor sense code (described above) will be suspended. The video mode specified by the user will be accepted regardless of whether it is

appropriate for the currently attached monitor. (This option is useful if a different monitor is to be connected to the AFB device). *Use of this option implies noconfirm well.*

try If present, the specified video mode will be programmed on a trial basis. The user will be asked to confirm the video mode by typing 'y' within 10 seconds. Or the user may terminate the trial before 10 seconds are up by typing any character. Any character other than 'y' or carriage return is considered a no and the previous video mode will be restored and **afbconfig** will not change the video mode in the OWconfig file (other options specified will still take effect). If a carriage return is typed, the user is prompted for a yes or no answer on whether to keep the new video mode. This option implies the now suboption (see the warning note on the now suboption).

AFB possesses two types of visuals: linear and nonlinear. Linear visuals are gamma corrected and nonlinear visuals are not. There are two visuals that have both linear and nonlinear versions: 24-bit TrueColor and 8-bit StaticGray. If true, the default visual is set to the linear visual that satisfies other specified default visual selection options (specifically, the Xsun(1) defdepth and defclass options described in the OpenWindows Reference Manual). If false, or if there is no linear visual that satisfies the other default visual selection options, the non-linear visual specified by these other options will be chosen to be the default. This option cannot be used when the **-defoverlay option is present, because AFB doesn't possess a linear overlay visual.**

-defoverlay true | false

The AFB provides an 8-bit PseudoColor visual whose pixels are disjoint from the rest of the AFB visuals. This is called the overlay visual. Windows created in this visual will not damage windows created in other visuals. The converse, however, is not true. Windows created in other visuals will damage overlay windows. The number of colors available to the windows created using this visual depends on the settings for the extovl option. If the extovl is enabled, extended overlay with 256 opaque color values is available. (refer to the **-extovl** option). If extovl is disabled, extended overlay is not available and this visual has (256 - maxwids) number of opaque color values (refer to the **-maxwids** option).

If the value of this option is true, the overlay visual will be made the default visual.

If false, the nonoverlay visual that satisfies the other default visual selection options, such as defdepth and defclass, will be chosen as the default visual. See the Xsun(1) manual page in the OpenWindows Reference Manual.

Whenever **-defoverlay true** is used, the default depth and class chosen on the openwin command line must be 8-bit PseudoColor. If not, a warning message will be printed and the **-defoverlay** option will be treated as false.

This option cannot be used when the **-deflinear** option is present, because AFB doesn't possess a linear overlay visual.

-linearorder first | last

If true, linear visuals will come before their non-linear counterparts on the X11 screen visual list for the AFB screen. If false, the nonlinear visuals will come before the linear ones.

-overlayorder first | last

If true, the depth 8 PseudoColor Overlay visual will come before the non-overlay visual on the X11 screen visual list for the AFB screen. If false, the non-overlay visual will come before the overlay one.

-expvis enable | disable

If enabled, OpenGL Visual Expansion will be activated. Multiple instances of selected visual groups (8-bit PseudoColor, 24-bit TrueColor ... etc) can be found in the screen visual list.

-sov enable | disable

If enabled, the root window's `SERVER_OVERLAY_VISUALS` property will be advertised. SOV visuals will be exported and their transparent types, values and layers can be retrieved through this property. If disabled, the `SERVER_OVERLAY_VISUALS` property will not be defined. SOV visuals will not be exported.

-maxwids *n*

This option is available only if `extovl` is disabled. It specifies the maximum number of AFB X channel pixel values that are reserved for use as window IDs (WIDs). The remainder of the pixel values in overlay colormaps are used for normal X11 opaque color pixels.

The reserved WIDs are allocated on a first-come first-serve basis by 3D graphics windows (such as XGL), MBX windows, and windows that have a non-default visual.

The X channel codes 0 to $(255 - n)$ will be opaque color pixels. The X channel codes $(255 - n + 1)$ to 255 will be reserved for use as WIDs. Legal values: 1, 2, 4, 8, 16, 32, 64

-extovl enable | disable

If enabled, extended overlay is available. The overlay visuals will have 256 opaque colors. The SOV visuals will have 255 opaque colors and 1 transparent color. Also, this option enables hardware supported transparency, thus provides better performance for windows using the SOV visuals.

-g *gamma-correction value*

This option allows changing the gamma correction value. All linear visuals provide gamma correction. By default the gamma correction value is 2.22. Any value less than zero is illegal.

This option can be used while the window system is running. Changing the gamma correction value will affect all the windows being displayed using the linear visuals.

-gfile *gamma-correction file*

This option loads gamma correction table from the specified file. This file should be formatted to provide the gamma correction values for R, G and B channels on each line. Each of these values should be in hexadecimal format and separated from each other by at least 1 space. Also this file should provide 256 such triplets. An example of this file is as follows.

```
0x00 0x00 0x00
0x01 0x01 0x01
0x02 0x02 0x02
...
...
0xff 0xff 0xff
```

Using this option, the gamma correction table can be loaded while the window system is running. The new gamma correction will affect all the windows being displayed using the linear visuals. Note, when gamma correction is being done using user specified table, the gamma correction value is undefined.

By default, the window system assumes a gamma correction value of 2.22 and loads the gamma table it creates corresponding to this value.

-defaults

Resets all option values to their default values.

-propt Prints the current values of all AFB options in the OWconfig file specified by the **-file** option for the device specified by the **-dev** option. Prints the values of options as they will be in the OWconfig file after the call to **afbconfig** completes. This is a typical display:

```
--- OpenWindows Configuration for /dev/fbs/afb0 ---
OWconfig: machine
Video Mode: 1280x1024x76
Default Visual: Non-Linear Normal Visual
Visual Ordering: Linear Visuals are last
                  Overlay Visuals are last
OpenGL Visual Expansion: enabled
Server Overlay Visuals: enabled
Extended Overlay: enabled
Underlay WIDs: 64 (not configurable)
Overlay WIDs: 4 (not configurable)
Gamma Correction Value: 2.220000
Gamma Correction Table: Available
```

-prconf

Prints the AFB hardware configuration. This is a typical display:

```
--- Hardware Configuration for /dev/fbs/afb0 ---
Type: double-buffered AFB with Z-buffer
```

Board: rev 0 (Horizontal)
PROM Information: @(#)afb.fth x.xx xx/xx/xx
FBC: version 0x101df06d
DAC: Brooktree 9070, version 1 (Pac2)
3DRAM: Mitsubishi 130a, version x
EDID Data: Available - EDID version 1 revision x
Monitor Sense ID: 4 (Sun 37x29cm RGB color monitor)
Monitor possible resolutions: 1024x768x77, 1024x800x84, 1152x900x66,
1152x900x76, 1280x1024x67, 1280x1024x76, 960x680x112s, 960x680x108s
Current resolution setting: 1280x1024x76

-help Prints a list of the **afbconfig** command line options, along with a brief explanation of each.

DEFAULTS

For a given invocation of **afbconfig** command line if an option does not appear on the command line, the corresponding OWconfig option is not updated; it retains its previous value.

When the window system is run, if an AFB option has never been specified via **afbconfig**, a default value is used. The option defaults are as follows:

Option	Default
-dev	/dev/fbs/afb0
-file	machine
-res	none
-deflinear	false
-defoverlay	false
-linearorder	last
-overlayorder	last
-expvis	enabled
-sov	enabled
-maxwids	32
-extovl	enabled
-g	2.22

The default for the **-res** option of none means that when the window system is run the screen resolution will be the video mode that is currently programmed in the device.

Note – This provides compatibility for users who are used to specifying the device resolution through the PROM. On some devices (e.g. GX) this is the only way of specifying the video mode. This means that the PROM ultimately determines the default AFB video mode.

EXAMPLES

The following example switches the monitor type to the resolution of 1280 × 1024 at 76 Hz:

```
example% /usr/sbin/afbconfig -res 1280x1024x76
```


FILES	/dev/fbs/afb0	device special file
SEE ALSO	mmap(2), fbio(7I), afb(7D)	

NAME	cfgadm – configuration administration
SYNOPSIS	<pre> /usr/sbin/cfgadm [-f] [-y -n] [-v] [-o hardware_options] -c function ap_id [ap_id...] /usr/sbin/cfgadm [-f] [-y -n] [-v] [-o hardware_options] -x hardware_function ap_id [ap_id...] /usr/sbin/cfgadm [-v] [-s listing_options] [-o hardware_options] [-l [ap_id ap_type...]] /usr/sbin/cfgadm [-v] [-o hardware_options] -t ap_id [ap_id...] </pre>
AVAILABILITY	SUNWcsu
DESCRIPTION	<p>The cfgadm command provides configuration administration operations on dynamically reconfigurable hardware resources. These operations include displaying status, (-l), initiating testing, (-t), invoking configuration state changes, (-c), and invoking hardware specific functions that do not change state, (-x). Configuration administration is performed at <i>attachment points</i> which are places where system software supports dynamic reconfiguration of hardware resources during continued operation of Solaris.</p> <p>Configuration administration makes a distinction between hardware resources that are physically present in the machine and hardware resources that are configured and visible to Solaris. The nature of configuration administration functions are hardware specific, and are performed by calling hardware specific libraries.</p> <p>Configuration administration operates on an <i>attachment point</i>. Hardware resources located at attachment points may or may not be physically replaceable during system operation, but are dynamically reconfigurable via the configuration administration interfaces. Attachment points are represented in the device tree by a unique nodetype.</p> <p>An attachment point defines two unique elements, which are distinct from the hardware resources that exist beyond the attachment point. The two elements of an attachment point are a <i>receptacle</i> and an <i>occupant</i>. Physical insertion or removal of hardware resources occurs at attachment points and results in a receptacle gaining or losing an occupant. Configuration administration supports the physical insertion and removal operations as well as other configuration administration functions at an attachment point.</p> <p>Attachment points have associated <i>state</i> and <i>condition</i> information. The configuration administration interfaces provide control for transitioning attachment point states. A receptacle can exist in one of four states: empty, prepped, disconnected or connected, while an occupant exist in one of two states: configured or unconfigured.</p> <p>A receptacle must provide the empty state, which is the normal state of a receptacle when the attachment point has no occupants. A receptacle may provide the prepped state which prepares the hardware for the physical insertion or removal of occupants. This involves hardware specific functions that may temporarily suspend activity on portions of the running system. A receptacle may provide the disconnected state if it has the capability of isolating its occupants from normal system access. Typically this state is used for various hardware specific testing prior to bringing the occupant's resources into full use by the system, or as a step in preparing an occupant for</p>

physical removal or reconfiguration. A receptacle in the disconnected state isolates its occupant from the system as much as its hardware allows, but may provide access for testing and setup. A receptacle must provide the **connected** state, which allows normal access to hardware resources contained on any occupants. The connected state is the normal state of a receptacle that contains an occupant and that is not currently undergoing configuration administration operations.

The hardware resources contained on an occupant in the **unconfigured** state are not represented by normal Solaris data structures (such as device tree nodes) and are thus not available for use by Solaris. Operations allowed on an unconfigured occupant are limited to configuration administration operations. The hardware resources of an occupant in the **configured** state are represented by normal Solaris data structures and thus some or all of those hardware resources may be in use by Solaris. An occupant is required to provide both the **configured** and **unconfigured** states,

An attachment point may be in one of five *conditions*: **unknown**, **ok**, **failing**, **failed** and **unusable**. An attachment point can enter the system in any condition depending upon results of power-on tests and non-volatile record keeping.

An attachment point with an occupant in the **configured** state will be in one of four conditions: **unknown**, **ok**, **failing** or **failed**. If the condition is not **failing** or **failed** an attachment point may change to **failing** during the course of operation if a hardware dependent recoverable error threshold is exceeded. If the condition is not **failed** an attachment point may change to **failed** during operation as a result of an unrecoverable error.

An attachment point with an occupant in the **unconfigured** state can be in any of the defined conditions. The condition of an attachment point with an **unconfigured** occupant may decay from **ok** to **unknown** after a machine dependent time threshold. Initiating a test function will change the attachment point's condition to **ok**, **failing** or **failed** depending on the outcome of the test. An attachment point that does not provide a test function may leave the attachment point in the **unknown** condition. If a test is interrupted, the attachment point's condition may be set to the previous condition, **unknown** or **failed**. An attachment point in the **unknown**, **ok**, **failing** or **failed** conditions can be re-tested.

An attachment point may exist in the **unusable** condition for a variety of reasons, such as inadequate power or cooling for the receptacle, an occupant that is unidentifiable, unsupported, incorrectly configured, etc. An attachment point in the **unusable** condition can never be used by the system. It will typically remain in this condition until the physical cause is remedied.

An attachment point also maintains an activity field that indicates when the condition is being reevaluated, **reevaluating condition**, is in the process of a state change, **state changing**, or executing a private function, **executing private**.

Attachment points are referred to using hardware specific identifiers (*ap_id*) that are related to the type and location of the attachment points in the system device hierarchy. An *ap_id* may not be ambiguous, it must identify a single attachment point. Two types of *ap_id* specifications are supported: physical and logical. A physical *ap_id*

contains a fully specified pathname, while a logical *ap_id* contains a shorthand notation to identify an attachment point in a more user-friendly way. Both types of *ap_ids* share a common format, with the name and instance forming the initial part followed by a ":" and then the specific attachment point. For example, a receptacle representing a system's backplane slot number 7 might have a physical *ap_id* of `/central/fhc/sysctrl:slot7` while the logical *ap_id* might be `system:slot7`. Another example, the third receptacle on the second PCI I/O bus on a system might have a logical *ap_id* of `pci2:plug3`.

The `cfgadm` command parses an *ap_id* and uses the name portion to locate and dynamically load the hardware specific library that supports that type of attachment point. The *ap_id* is passed on to the hardware specific library to perform operations. The hardware specific library validates that the *ap_id* is complete and identifies a single attachment point to operate on.

An *ap_type* is a partial form of an *ap_id* that may be ambiguous and not specify a particular attachment point. The *ap_type* is used by the list function to allow listing of all attachment points of the same type. It consists of the name portion of an *ap_id* and may omit the instance, the colon separator and the specific attachment point identifier. For example, a logical *ap_id* of `pci` would show all attachment points supported by the library identified by the name `pci`.

The `cfgadm` command parses an *ap_type* and uses the name portion to locate and dynamically load the hardware specific library that supports attachment points of that type. The *ap_type* is passed to the hardware specific library to perform listing operations.

The `cfgadm` command interacts primarily with hardware dependent functions contained in hardware specific libraries and thus its behavior is hardware dependent.

For each configuration administration operation a service interruption may be required. Should the completion of the function requested require a noticeable (to interactive users) service interruption, a prompt will be output on the standard error output for confirmation on the standard input before the function is started. Confirmation can be overridden using the `-y` or `-n` flags to always answer yes or no respectively. Hardware specific options, such as test level, are supplied as sub-options using the `-o` flag.

Operations that change the state of the system configuration are audited by the system log daemon `syslogd(1M)`.

The arguments for this command conform to the `getopt(3C)` and `getsubopt(3C)` syntax convention.

OPTIONS

`-c function`

Performs the specified state change *function* on the attachment point specified by *ap_id*. The available *functions* are `prep`, `load`, `unload`, `resume`, `disconnect`, `connect`, `configure` and `unconfigure`. These functions cause state transitions at the attachment point by calling hardware specific library routines.

The `prep` function performs hardware specific operations to prepare a

receptacle for the physical addition or removal of an occupant. Various hardware specific safeguards may cause this function to fail and set the receptacle condition to **unusable**.

The **load** function performs operations to activate hardware supplied insertion hardware that will perform the physical addition of an occupant. Various hardware specific errors may cause this function to fail and set the receptacle condition to **unusable**.

The **unload** function performs operations to activate hardware supplied removal hardware that will perform the physical removal of an occupant. Various hardware specific errors may cause this function to fail and set the receptacle condition to **unusable**.

The **resume** function performs hardware specific operations to transition a receptacle from the **prepped** state to the **empty** state when all occupants have been removed, or to the **disconnected** state, if provided, when an occupant has been added. If the attachment point does not support the **disconnected** state the transition will be to **connected**.

The **disconnect** function performs hardware specific operations to put a receptacle in the disconnected state, which may prevent an occupant from operating in a normal fashion through the receptacle.

The **connect** function performs hardware specific operations to put the receptacle in the **connected** state, which allows an occupant to operate in a normal fashion through the receptacle.

The **configure** function performs hardware specific operations that allow an occupant's hardware resources to be usable by Solaris. Occupants that are configured are part of the system configuration and will be available for manipulation by Solaris device manipulation maintenance commands (eg: **psradm(1M)**, **mount(1M)**, **ifconfig(1M)**).

The **unconfigure** function performs hardware specific operations that logically remove an occupant's hardware resources from the system. The occupant must currently be configured and its hardware resources must not be in use by Solaris.

State transition functions may fail due to the condition of the attachment point or other hardware dependent considerations. All state change *functions* in the direction of adding resources, are passed onto the hardware specific library when the attachment point is in the **ok** or **unknown** condition. All other conditions require the use of the force option to allow *functions* in the direction of adding resources, to be passed on to the hardware specific library. Attachment point condition does not gate transitions related to removal of hardware resources from the system. Hardware specific libraries may reject state change *functions* if the attachment point is in the **unknown** condition.

The condition of an attachment point is not necessarily changed by the state change functions, however errors during state change operations can change the attachment point condition. An attempt to override a condition and force a state change that

would otherwise fail can be made by specifying the force flag (**-f**). Hardware specific safety and integrity checks may prevent the force flag from having any effect.

- f** Force the specified action to occur. Typically, this is a hardware dependent override of a safety feature. Forcing a state change operation may allow use of the hardware resources of occupant that is not in the **ok** or **unknown** conditions, at the discretion of any hardware dependent safety checks.
- l** List the state and condition of attachment points. If any *ap_types* are specified, the listing will be limited to attachment points of those types. If any *ap_ids* are specified the listing is limited to those particular attachment points. Invoking the **cfgadm** command without one of the action flags is equivalent to **-l** without an *ap_id* or an *ap_type* argument. The format of the display is controlled by the **-v** and **-s** options.
- n** Suppress any interactive confirmation and assume that the answer is *no*. If neither **-n** or **-y** is specified, interactive confirmation is obtained through the standard error output and the standard input. If either of these standard channels does not correspond to a terminal (as determined by **isatty(3C)**) then the **-n** option is assumed.
- o hardware_options**
Supply hardware specific options to the main command option. The format and content of the hardware option string is completely hardware specific. The option string *hardware_options* conforms to the **getsubopt(3C)** syntax convention.
- s listing_options**
Supply listing options to the list (**-l**) command. The option string *listing_options* conforms to the **getsubopt(3C)** syntax convention. The sub-options are used to control the order of the listing (**sort=field_spec**), the data that is displayed (**cols=field_spec** and **cols2=field_spec**), the column delimiter (**delim=string**) and whether to suppress column headings (**noheadings**). A *field_spec* is one or more *data-fields* concatenated using **:** (colon) as in *data-field:data-field:data-field*. A *data-field* is one of **ap_id**, **physid**, **r_state**, **o_state**, **condition**, **activity**, **type**, **status_time**, **status_time_p** and **info**. The **status_time_p** field is a parsable version of the **status_time** field. The order of the fields in *field_spec* is significant: For the **sort** sub-option, the first field given is the primary sort key. For the **cols** and **cols2** sub-options, the fields are printed in the order requested. The fields in **cols** are always printed. The fields in **cols2** are printed on a second line only if specified. The order of sorting on a *data-field* may be reversed by placing a **-** (minus) before the *data-field* name within the *field_spec* for the **sort** sub-option. The default value for **sort** is **ap_id**. The default values for **cols** and **cols2** depend on whether the **-v** option is given: Without it **cols** is **ap_id:r_state:o_state:condition** and **cols2** is not set. With **-v** **cols** is **ap_id:r_state:o_state:condition:info** and **cols2** is **status_time:type:activity:physid**. The default value for **delim** is a single space. The value of **delim** may be a string of arbitrary length. The delimiter cannot include comma character, see **getsubopt(3C)**. These listing options may be

used to create parsable output - see NOTES below.

- t Perform a test of one or more attachment points. The test function is used to re-evaluate the condition of the attachment point. Without a test level specifier in *hardware_options*, the fastest test that will identify hard faults will be used. More comprehensive tests are hardware specific and are selected using the *hardware_options*.
The results of the test will be used to update the condition of the specified occupant to either **ok** if no faults are found, **failing** if recoverable faults are found or **failed** if any unrecoverable faults are found.
If a test is interrupted, the attachment point's condition may be restored to its previous value or set to **unknown** if no errors were found or **failing** if only recoverable errors were found or to **failed** if any unrecoverable errors were found. The attachment point should only be set to **ok** when upon normal completion of testing with no errors.
- v Verbose option. For the -c, -t and -x options output a message giving the results of each attempted operation. For the -l option output full information for each attachment point.
- x *hardware_function*
Performs hardware specific functions. These private hardware specific functions are not allowed to change the state of a receptacle or occupant. Attachment point conditions may change as the result of errors encountered during private hardware specific functions. The format and content of the *hardware_function* string is completely hardware specific. The option string *hardware_function* conforms to the **getsubopt(3C)** syntax convention.
- y Suppress any interactive confirmation and assume that the answer is yes.

USAGE

The required privileges to use this command are hardware dependent. Typically, a default system configuration will restrict all but the list option to the superuser.

EXAMPLES

List current configurable hardware information

```
example# cfgadm
```

Ap_Id	Receptacle	Occupant	Cond
system:slot0	connected	configured	ok
system:slot1	connected	configured	ok
system:slot2	connected	configured	ok
system:slot3	connected	unconfigured	unknown
system:slot4	connected	configured	failing
system:slot5	connected	configured	ok
system:slot6	disconnected	unconfigured	unusable
system:slot7	empty		unconfigured

List current configurable hardware information in verbose mode

```
example# cfgadm -v -l system
```

```
Status of system configuration at Wed Nov 13 17:26:17 PST 1996
```

Ap_Id	Receptacle When	Occupant Type	Cond Activity	Info Physid
system:slot0	connected Nov 5	configured CPU	ok	SUNW,UltraSPARC,168 MHz /central/fhc/sysctrl:slot0
system:slot1	connected Nov 5	configured MEMORY	ok	512mb, 2 way interleaved /central/fhc/sysctrl:slot1
system:slot2	connected Nov 5	configured IO	ok	PCI /central/fhc/sysctrl:slot2
system:slot3	connected Nov 5	unconfigured MEMORY	failing reevaluating_condition	512mb, 2 way interleaved /central/fhc/sysctrl:slot3
system:slot4	connected Nov 5	configured MEMORY	failing	512mb, 2 way interleaved /central/fhc/sysctrl:slot4
system:slot5	connected Nov 5	configured IO	ok state_changing	PCI /central/fhc/sysctrl:slot5
system:slot6	disconnected Nov 5	unconfigured	unusable	unsupported option /central/fhc/sysctrl:slot6
system:slot7	empty Nov 5	unconfigured	ok	/central/fhc/sysctrl:slot7

Test two occupants using the hardware specific **extended** test

```
example# cfgadm -v -o extended -t system:slot3 system:slot5
Testing attachment point system:slot3 ... ok
Testing attachment point system:slot5 ... ok
```

Configure an occupant in the **failing** state to the system using the force option

```
example# cfgadm -f -c configure system:slot3
```

Unconfigure an occupant from the system

```
example# cfgadm -c unconfigure system:slot4
```

ENVIRONMENT

See **environ(5)** for descriptions of the following environment variables that affect the execution of **cfgadm**: **LC_TIME**, **LC_MESSAGES**, **NLSPATH** and **TZ**.

LC_MESSAGES

Determines how **cfgadm** displays column headings and error messages. Listing output data is not affected by the setting of this variable.

LC_TIME

Determines how **cfgadm** displays human readable status changed time (**status_time**).

TZ Specifies the timezone used when converting the status changed time. This applies to both the human readable (**status_time**) and parsable (**status_time_p**) formats.

EXIT STATUS

The following exit values are returned:

- 0** The operation completed successfully.
- 1** The operation failed.

- 2 Configuration administration not supported on specified target.
- 3 Usage error.

SEE ALSO

prtdiag(1M), **psradm(1M)**, **syslogd(1M)**, **getopt(3C)**, **getsubopt(3C)**, **config_admin(3X)**.

DIAGNOSTICS

Diagnostic messages will appear on the standard error output. Other than options and usage errors, the following may be seen:

cfgadm: Configuration administration not supported on *ap_id*

cfgadm: No library found for *ap_id*

cfgadm: *ap_id* is ambiguous

cfgadm: operation: Insufficient privileges

cfgadm: attachment point is busy, try again

cfgadm: System is busy, try again

cfgadm: operation: Operation requires a service interruption

cfgadm: operation: Data error: *error_text*

cfgadm: operation: Hardware specific failure: *error_text*

See **config_admin(3X)** for additional error message detail.

NOTES

Hardware resources will enter the unconfigured pool in a hardware specific manner. This can occur at various times such as: system initialization or as a result of an unconfigure operation. An occupant that is in the **unconfigured** state is not available for use by the system until specific intervention occurs. This intervention may be manifested as an operator initiated command or it may be via an automatic configuring mechanism.

The listing option of the **cfgadm** command can be used to provide parsable input for another command, for example within a shell script. The **-s** option can be used to select the fields required and suppress the column headings. The following fields will always produce parsable output: **ap_id**, **physid**, **r_state**, **o_state**, **condition**, **activity**, **status_time_p** and **type**. Parsable output will never have white-space characters embedded in the field value. Here is a shell script fragment to find the first good **unconfigured** occupant of type CPU.

```
found=
cfgadm -l -s "noheadings,cols=ap_id:r_state:condition:type" | \
while read ap_id r_state cond type
do
    if [ "$r_state" = unconfigured -a "$cond" = ok -a "$type" = CPU ]
    then
        if [ -z "$found" ]
        then
            found=$ap_id
        fi
    fi
fi
```

```
done
if [ -n "$found" ]
then
    echo "Found CPU $found"
fi
```

The format of the parsable time field (**status_time_p**) is *YYYYMMDDhhmmss*, giving the year, month, day, hour, minute and second in a form suitable for string comparison.

Reference should be made to the hardware specific documentation for details of System Configuration Administration support.

NAME	cvcd – virtual console daemon
DESCRIPTION	<p>cvcd is a server that resides on an Enterprise 10000 host or domain. It accepts connections from netcon_server(1M) on an SSP to create a Network Console Window on that SSP. The Network Console Window is able to read data from, and possibly send data to, the host or domain. This process takes place via the SSP command netcon(1M). See netcon_server(1M) and netcon(1M) in <i>man Pages(1M): Ultra Enterprise 10000 SSP Administration Commands</i>.</p> <p>When you execute netcon(1M) in an SSP Window, netcon_server(1M) connects with the cvcd daemon running on the host or domain specified in the SSP's <code>SUNW_HOSTNAME</code> environment variable, and the window becomes a Host Console Window.</p> <p>The console session ends when you exit the session, netcon_server terminates, or a network failure occurs. If cvcd dies, netcon gets data from JTAG through the control board.</p> <p>cvcd is normally started during boot. Only one cvcd process at a time can run on the host.</p> <p>Caution: cvcd uses the file ssphostname, which resides on the host. If the SSP has been renamed, ssphostname must be edited to reflect that change.</p>
SEE ALSO	<p><i>Ultra Enterprise 10000 SSP User's Guide</i></p> <p>cvc(7), cvcredir(7), netcon(1M), netcon_server(1M), services(4)</p>

NAME	dr_daemon – dynamic reconfiguration daemon
SYNOPSIS	dr_daemon [-a]
DESCRIPTION	The dr_daemon is an RPC program that provides the interface to the Dynamic Reconfiguration (DR) driver, /dev/dr . The Hostview and DR applications provide the user interface to DR. See hostview(1M) in <i>man Pages(1M): Ultra Enterprise 10000 SSP Administration Commands</i> and dr(1M) in <i>man Pages(1M): DR Administration Commands</i> .
OPTIONS	-a Disable communications with the Alternate Pathing daemon. See ap_daemon(1M) in <i>man Pages(1M): Alternate Pathing Administration Commands</i> .
Configuration Information	<p>The /usr/platform/sun4u1/sbin/dr_daemon RPC program name is DRPROG, its RPC program number is 300326, and its underlying protocol is TCP. It is invoked as an inetd server using the TCP transport. The UID required for access to the daemon is ssp. This UID can be a non-login UID.</p> <p>The entry for the daemon in the /etc/inetd.conf file is:</p> <pre>300326/4 tli rpc/tcp wait root /usr/platform/sun4u1/sbin/dr_daemon dr_daemon</pre> <p>The daemon's only clients are Hostview and DR. Hostview provides a GUI interface; dr1M is a command-line interface for non-windowing environments. The DR daemon uses syslog(3) to report status and error messages, which are logged with the LOG_DAEMON facility and the LOG_ERR and LOG_NOTICE priorities.</p> <p>The dr_daemon communicates via RPC with the Alternate Pathing (AP) daemon (see ap_daemon(1M) in <i>man Pages(1M): Alternate Pathing Administration Commands</i>) to notify the AP software when controllers are attached to and detached from the system, or to gather information about the system configuration.</p>
SEE ALSO	<p><i>Dynamic Reconfiguration User's Guide</i> <i>Alternate Pathing User's Guide</i></p> <p>dr(7) in this reference manual</p> <p>ap(1M), ap_daemon(1M) in <i>man Pages(1M): Alternate Pathing Administration Commands</i></p> <p>dr(1M) in <i>man Pages(1M): DR Administration Commands</i></p> <p>hostview(1M), hpost(1M) in <i>man Pages(1M): Ultra Enterprise 10000 SSP Administration Commands</i></p> <p>add_drv(1M), drvconfig(1M), devlinks(1M), disks(1M), inetd(1M), ports(1M), tapes(1M), prtconf(1M), syslog(3) in <i>man Pages(1M): System Administration Commands</i></p>

NAME	luxadm – administration program for the Sun Enterprise Network Array (SENA), RSM and SPARCstorage Array (SSA) subsystems
SYNOPSIS	luxadm [<i>options ...</i>] <i>subcommand</i> [<i>options ...</i>] <i>enclosure</i> [, <i>dev</i>] <i>pathname ...</i>
DESCRIPTION	<p>The luxadm program is an administrative command that manages the SENA, RSM, and SPARCstorage Array subsystems. luxadm performs a variety of control and query tasks depending on the command line arguments and options used.</p> <p>The command line must contain a subcommand. The command line may also contain options, usually at least one enclosure name or pathname, and other parameters depending on the subcommand. You need specify only as many characters as are required to uniquely identify a subcommand.</p> <p>Specify the device that a subcommand interacts with by entering a pathname. For the SENA subsystem, a disk device or enclosure services controller may instead be specified by entering the World Wide Name (WWN) for the device or a port to the device. The device may also be specified by entering the name of the SENA enclosure, and an optional identifier for the particular device in the enclosure.</p>
Pathname	<p>Specify the device or controller by either a complete physical pathname or a complete logical pathname.</p> <p>For SENA, a typical physical pathname for a device is:</p> <pre style="margin-left: 40px;">/devices/sbus@1f,0/SUNW,socal@1,0/sf@0,0/ssd@w2200002037000f96,0:a,raw</pre> <p>or</p> <pre style="margin-left: 40px;">/devices/io-unit@f,e0200000/sbi@0,0/SUNW,socal@2,0/sf@0,0/ssd@34,0:a,raw</pre> <p>For all SENA IBs (Interface Boards) on the system, a logical link to the physical paths is kept in the directory /dev/es. An example of a logical link is /dev/es/ses0.</p> <p>For SENA, the WWN may be used in place of the pathname to select a device or SENA subsystem IB. The WWN is a unique 16 hexadecimal digit value that specifies either the port used to access the device or the device itself. A typical WWN value is:</p> <pre style="margin-left: 40px;">2200002037000f96</pre> <p>See NOTES for more information on the WWN formats.</p> <p>For the SPARCstorage Array controller, a typical physical pathname is:</p> <pre style="margin-left: 40px;">/devices/.../.../SUNW,soc@3,0/SUNW,pln@axxxxxxx,xxxxxxx:ctrl</pre> <p>whereas, a typical physical pathname for an RSM controller might be:</p> <pre style="margin-left: 40px;">/devices/sbus@1f,0/QLGC,isp@1,1000:devctl</pre> <p>In order to make it easier to address the SPARCstorage Array or RSM controller, a logical pathname of the form cN is supported, where <i>N</i> is the logical controller number. luxadm uses the cN name to find an entry in the /dev/rdisk directory of a disk that is attached to the SPARCstorage Array or RSM controller. The /dev/rdisk entry is then used to determine the physical name of the SPARCstorage Array or RSM controller.</p>

For a SPARCstorage Array disk, a typical physical pathname is:

```
/devices/.../.../SUNW,soc@3,0/SUNW,pln@axxxxxxx,xxxxxxx/ssd@0,0:c,raw
```

and a typical logical pathname is:

```
/dev/rdisk/c1t0d0s2
```

For an RSM a typical physical pathname might be:

```
/devices/sbus@1f,0/QLGC,isp@1,10000/sd@8,0:c,raw
```

and a typical logical pathname might be:

```
/dev/rdisk/c2t8d0s2
```

Enclosure

For SENA, a device may be identified by its enclosure name and slotname:

```
box_name[,fslot_number]
```

```
box_name[,rslot_number]
```

box_name is the name of the SENA enclosure, as specified by the **enclosure_name** subcommand. When used without the optional *slot_number* parameter, the *box_name* identifies the SENA subsystem IB.

f or **r** specifies the front or rear slots in the SENA enclosure.

slot_number specifies the slot number of the device in the SENA enclosure, **0-6** or **0-10**.

See **disks(1M)** and **devlinks(1M)** for additional information on logical names for disks and subsystems.

OPTIONS

The following options are supported by all subcommands:

-e Expert mode. This option is not recommended for the novice user.

-v Verbose mode.

Options that are specific to particular subcommands are described with the subcommand in the **USAGE** section.

OPERANDS

The following operands are supported:

enclosure The *box_name* of the SENA.

pathname The logical or physical path of a SENA IB, SPARCstorage Array or RSM controller (*cN* name) or disk device. *pathname* can also be the WWN of a SENA IB or SENA disk.

USAGE

Subcommands

```
display enclosure[,dev]... | pathname...
```

```
display -p pathname...
```

```
display -r enclosure[,dev]... | pathname...
```

```
display -v enclosure[,dev]... | pathname...
```

Displays enclosure or device specific data.

Subsystem data consists of enclosure environmental sense information and

status for all subsystem devices, including disks.

Disk data consists of inquiry, capacity, and configuration information.

- p** Displays performance information for the device or subsystem specified by *pathname*. This option only applies to subsystems that accumulate performance information.
- r** Displays error information for the device specified by the *pathname*, or, if the path is a SENA, for all devices on the loop. The -**r** option only applies to SENA subsystems.
- v** Displays in verbose mode, including mode sense data.

probe [-**p**]

Finds and displays information about all attached SENA subsystems, including the logical pathname, the WWNs, and enclosure names. This subcommand warns the user if it finds different SENAs with the same enclosure names.

- p** Includes the physical pathname in the display.

download [-**s**] [-**w** *WWN*] [-**f** *filename_path*] *enclosure...* | *pathname...*

Download the prom image pointed to by *filename_path* to the SENA subsystem Interface Board unit or the SPARCstorage Array controllers specified by the enclosure or pathname. The SPARCstorage Array must be reset in order to use the downloaded code.

When the SENA's download is complete, the SENA will be reset and the downloaded code executed. If no filename is specified, the default prom image will be used. The default prom image for the SPARCstorage Array controller is in **usr/lib/firmware/ssa/ssafirmware**. The default prom image for the SENA is in the directory **usr/lib/locale/C/LC_MESSAGES** and is named **ibfirmware**. The SENA firmware is language dependent so The **LANG** environment variable is used to find the directory that contains the firmware. The default directory is **C**.

- s** Save. The -**s** option is used to save the downloaded firmware in the FEPROM. If -**s** is not specified, the downloaded firmware will not be saved across power cycles. The -**s** option does not apply to the SPARCstorage Array controller as it *always* writes the downloaded firmware into the FEPROM. When using the -**s** option, the **download** subcommand modifies the FEPROM on the subsystem and should be used with *caution*.

- w** *WWN*

Change the SPARCstorage Array controller's World Wide Name.

WWN is a 12-digit hex number; leading zeros are required. The -**w** option applies only to the SPARCstorage Array. The new SPARCstorage Array controller's image will have the least significant 6 bytes of the 8-byte World Wide Name modified to *WWN*.

enclosure_name *new_name enclosure* | *pathname*

Change the enclosure name of the enclosure or enclosures specified by the enclosure or pathname. The new name (*new_name*) must be 16 or less

characters. Only alphabetic or numeric characters are acceptable. This subcommand applies only to the SENA.

fc_s_download [-F] [-f *fcode-file*]

Download the fcode contained in the file *fcode-file* into *all* the FC/S Sbus Cards. This command is interactive and expects user confirmation before downloading the fcode. When invoked without the *-f fcode-file* option, the current version of the fcode in each FC/S Sbus card is printed. When the *-F* option is used, the fcode is forcibly downloaded, but the command still expects user confirmation before the download. The version of the FC/S Sbus Cards fcode that was released with this version of the Operating System is kept in the directory **usr/lib/firmware/fc_s** and is named **fc_s_fcode**.

Use **fc_s_download** *only* in single-user mode. Using **fc_s_download** to update a host adapter while there is I/O activity through that adapter *will* cause the adapter to reset.

fc100_s_download [-f *fcode-file*]

Download the fcode contained in the file *fcode-file* into *all* the FC100/S Sbus Cards. This command is interactive and expects user confirmation before downloading the fcode. When invoked without the *-f* option, the current version of the fcode in each FC100/S Sbus card is printed. The version of the FC100/S Sbus Cards fcode that was released with this version of the operating system is kept in the directory **usr/lib/firmware/fc_s** and is named **fc100_s_fcode**.

Use **fc100_s_download** *only* in single-user mode. Using **fc100_s_download** to update a host adapter while there is I/O activity through that adapter *will* cause the adapter to reset.

inquiry *enclosure[,dev]... | pathname...*

Display the inquiry information for the selected device specified by the enclosure or pathname.

insert_device [*enclosure,dev...*] | *pathname...*

Assist the user in the hot insertion of a new device or a chain of new devices. Refer to **NOTES** for limitations on hotplug operations. This subcommand applies only to the SENA and the RSM subsystems. For the SENA, if more than one enclosure has been specified, concurrent hot insertions on multiple busses can be performed. With no arguments to the subcommand, entire enclosures can be inserted. For the RSM, only one controller can be specified. For the SENA, this subcommand guides the user interactively through the hot insertion steps of a new device or chain of devices. If a list of disks was entered it will ask the user to verify the list of devices to be inserted is correct, at which point the user can continue or quit. It then interactively asks the user to insert the disk(s) or enclosure(s) and then creates and displays the logical pathnames for the devices.

For the RSM, the following steps are taken:

- Quiesce the bus or buses which support quiescing and

unquiescing.

- Inform the user that the device can be safely inserted .
- Request confirmation from the user that the device has been inserted.
- Unquiesce the bus or buses which support quiescing and unquiescing.
- Create the logical device name for the new device.

led *enclosure,dev ... | pathname...*

Display the current state of the LED associated with the disk specified by the enclosure or pathname. This subcommand only applies to subsystems that support this functionality.

led_blink *enclosure,dev ... | pathname ...*

Requests the subsystem to start blinking the LED associated with the disk specified by the enclosure or pathname. This subcommand only applies to subsystems that support this functionality.

led_off *enclosure,dev ... | pathname ...*

Requests the subsystem to disable (turn off) the LED associated with the disk specified by the enclosure or pathname. On a SENA subsystem, this may or may not cause the LED to turn off or stop blinking depending on the state of the SENA subsystem. Refer to the SENA Array Installation and Service Manual (p/n 802-7573). This subcommand only applies to subsystems that support this functionality.

led_on *pathname ...*

Requests the subsystem to enable (turn on) the LED associated with the disk specified by the enclosure or pathname. This subcommand only applies to subsystems that support this functionality.

power_off *enclosure[,dev]... | pathname [enclosure-port]... | controller tray-number*

When a SENA is addressed, this subcommand causes the SENA subsystem to go into the power-save mode. The SENA drives are not available when in the power-save mode. When an Enclosure Services card within the SPARCstorage Array is addressed, the RSM tray is powered down. When a drive in a SENA is addressed the drive is set to the drive off/unmated state. In the drive off/unmated state, the drive is spun down (stopped) and in bypass mode.

power_on *enclosure[,dev]... | pathname ...*

Causes the SENA subsystem to go out of the power-save mode, when this subcommand is addressed to a SENA. There is no programmatic way to power on the SPARCstorage Array RSM tray. When this subcommand is addressed to a drive the drive is set to its normal start-up state.

release *pathname*

Release a reservation held on the specified disk. If the pathname is of the SPARCstorage Array controller, then all of the disks in the SPARCstorage

Array will be released.

remove_device *enclosure[,dev]... | pathname...*

Assists the user in hot removing a device or a chain of devices. This subcommand can also be used to remove entire enclosures. This subcommand applies to the SENA and the RSM. Refer to **NOTES** for limitations on hot-plug operations. For the SENA, this subcommand guides the user through the hot removal of a device or devices. During execution it will ask the user to verify the list of devices to be removed is correct, at which point the user can continue or quit. It then prepares the disk(s) or enclosure(s) for removal and interactively asks the user to remove the disk(s) or enclosure(s).

For the RSM, the steps taken are:

- Take the device offline.
- Quiesce the bus or buses which support quiescing and unquiescing.
- Inform user that the device can be safely removed.
- Request confirmation from the user that the device has been removed.
- Unquiesce the bus or buses which support quiescing and unquiescing.
- Bring the (now removed) device back online.
- Remove the logical device name for the removed device.

replace_device *pathname*

This subcommand applies only to the RSM. Refer to **NOTES** for limitations on hotplug operations. This subcommand guides the user interactively through the hot replacement of a device.

For the RSM, the steps taken are:

- Take the device offline.
- Quiesce the bus or buses which support quiescing and unquiescing.
- Inform user that the device can be safely replaced.
- Request confirmation from the user that the device has been replaced.
- Unquiesce the bus or buses which support quiescing and unquiescing.
- Bring the device back online.

reserve *pathname*

Reserve the specified disk for exclusive use by the issuing host. If the pathname is of the SPARCstorage Array controller, then all of the disks in the SPARCstorage Array will be reserved.

set_boot_dev [-y] *pathname*

Set the boot-device variable in the system PROM to the physical device name specified by *pathname*, which can be a block special device or a mount-point. The command normally runs interactively requesting

SPARCstorage Array
Subcommands

confirmation for setting the default boot-device in the PROM. The `-y` option can be used to run it non-interactively, in which case no confirmation is requested or required.

start [`-t` *tray-number*] *pathname* . . .

Spin up the specified disk(s). If *pathname* specifies the SPARCstorage Array controller, this action applies to all disks in the SPARCstorage Array.

`-t` Spin up all disks in the tray specified by *tray-number*. *pathname* must specify the SPARCstorage Array controller.

stop [`-t` *tray-number*] *pathname* . . .

Spin down the specified disk(s). If *pathname* specifies the SPARCstorage Array controller, this action applies to all disks in the SPARCstorage Array.

`-t` Spin down all disks in the tray specified by *tray-number*. *pathname* must specify the SPARCstorage Array controller.

fast_write [`-s`] `-c` *pathname*

fast_write [`-s`] `-d` *pathname*

fast_write [`-s`] `-e` *pathname*

Enable or disable the use of the NVRAM to enhance the performance of writes in the SPARCstorage Array. *pathname* refers to the SPARCstorage Array controller or to an individual disk.

`-s` Cause the SPARCstorage Array to save the change so it will persist across power-cycles.

`-c` Enable fast writes for synchronous writes only.

`-d` Disable fast writes.

`-e` Enable fast writes.

nvrn_data *pathname*

Display the amount of fast write data in the NVRAM for the specified disk. This command can only be used for an individual disk.

perf_statistics `-d` *pathname*

perf_statistics `-e` *pathname*

Enable or disable the accumulation of performance statistics for the specified SPARCstorage Array controller. The accumulation of performance statistics must be enabled before using the display `-p` subcommand. This subcommand can be issued only to the SPARCstorage Array controller.

`-d` Disable the accumulation of performance statistics.

`-e` Enable the accumulation of performance statistics.

purge *pathname*

Purge any fast write data from NVRAM for one disk, or all disks if the controller is specified. This option should be used with caution, usually only when a drive has failed.

sync_cache *pathname*

Flush all outstanding writes for the specified disk from NVRAM to the media. If *pathname* specifies the controller, this action applies to all disks in the SPARCstorage Array subsystem.

**Enclosure Services
Card Subcommands**

The **env_display** and **alarm*** subcommands apply only to an Enclosure Services Card (SES) in a RSM tray in a SPARCstorage Array. The RSM tray is addressed by using the logical or physical path of the SES device or by specifying the controller followed by the tray number. The controller is addressed by *cN* or the physical path to the SSA's controller.

alarm *pathname* | *controller tray_number*

Display the current state of audible alarm.

alarm_off *pathname* | *controller tray_number*

Disable the audible alarm for this RSM tray.

alarm_on *pathname* | *controller tray_number*

Enable the audible alarm for this RSM tray.

alarm_set *controller-pathname* | *controller tray_number* [*seconds*]

Set the audible alarm setting to seconds.

env_display *pathname* | *controller tray_number*

Display the environmental information for the specified unit.

**SENA Expert Mode
Subcommands**

The following subcommands are for expert use only, and are applicable only to the SENA subsystem. They should only be used by users that are knowledgeable about the SENA subsystem and fiber channel loops.

For the following subcommands that work on a bus if a disk is specified then the bus that disk attached to is used.

– **e forcelp** *enclosure[,dev]* ... | *pathname* ...

Force the link to reinitialize, using the Loop Initialization Primitive (LIP) sequence. The enclosure or pathname can specify any device on the loop. This is an expert only command and should be used with caution. It will reset all ports on the loop.

– **e rdls** *enclosure[,dev]* ... | *pathname* ...

Read and display the link error status information for all available devices on the loop that contains the device specified by the enclosure or pathname.

**Other Expert Mode
Subcommands**

See **NOTES** for limitations of these subcommands. They should only be used by users that are knowledgeable about the systems they are managing.

– **e bus_getstate** *pathname*

Get and display the state of the specified bus.

– **e bus_quiesce** *pathname*

Quiesce the specified bus.

– **e bus_reset** *pathname*

Reset the specified bus.

– **e bus_resetall** *pathname*

Reset the specified bus.

– **e bus_unquiesce** *pathname*

Unquiesce the specified bus. the specified device.

- e **dev_getstate** *pathname*
Get and display the state of the specified device.
- e **dev_reset** *pathname*
Reset the specified device.
- e **offline** *pathname*
Take the specified device offline.
- e **online** *pathname*
Put the specified device online.

EXAMPLES

The following example finds and displays all of the SENAs on a system:

```
example% luxadm probe
```

The following example displays an SSA:

```
example% luxadm display c1
```

The following example displays a SENA:

```
example% luxadm display /dev/es/ses0
```

The following example displays of two subsystems using the enclosure names:

```
example% luxadm display BOB system1
```

The following example displays information about the first disk in the front of the enclosure named **BOB**. Use **f** to specify the front disks. Use **r** to specify the rear disks.

```
example% luxadm display BOB,
```

The following example displays information about a SENA disk or enclosure with the port WWN of **2200002037001246**:

```
example% luxadm display 2200002037001246
```

The following example uses only as many characters as are required to uniquely identify a subcommand:

```
example% luxadm disp BOB
```

The following example displays error information about the loop that the enclosure **BOB** is on:

```
example% luxadm display –r BOB
```

The following example downloads new firmware into the Interface Board in the enclosure named **BOB** (that this is using the default path for the file to download):

```
example% luxadm download –s BOB
```

The following example displays information from the SCSI inquiry command from all individual disks on the system, using only as many characters as necessary to uniquely identify the inquiry subcommand:

```
example% luxadm inq /dev/rdisk/c?t?d?s2
```

The following example hotplugs a new drive into the first slot in the front of the enclosure named **BOB**:

```
example% luxadm insert_device BOB,
```

The following example runs an expert subcommand. The subcommand forces a loop initialization on the loop that the enclosure BOB is on:

```
example% luxadm -e forcelp BOB
```

An example of using the expert mode hot plugging subcommands to hot remove a disk on a SSA follows. See **NOTES** for hot plugging limitations.

The first step reserves the SCSI device so that it can't be accessed by way of its second SCSI bus:

```
example# luxadm reserve /dev/rdisk/c1t8d0s2
```

The next two steps take the disk to be removed offline then quiesce the bus:

```
example# luxadm -e offline /dev/rdisk/c1t8d0s2
```

```
example# luxadm -e bus_quiesce /dev/rdisk/c1t8d0s2
```

The user then removes the disk and continues by unquiescing the bus, putting the disk back online, then unreserving it:

```
example# luxadm -e bus_unquiesce /dev/rdisk/c1t8d0s2
```

```
example# luxadm -e online /dev/rdisk/c1t8d0s2
```

```
example# luxadm release /dev/rdisk/c1t8d0s2
```

ENVIRONMENT

See **environ(5)** for a description of the **LANG** environment variable that affects the execution of **luxadm**.

EXIT STATUS

The following exit values are returned:

```
0          Successful completion.
-1         An error occurred.
```

FILES

```
usr/lib/firmware/fc_s/fcal_s_fcode
usr/lib/firmware/fc_s/fc_s_fcode
usr/lib/firmware/ssa/ssafirmware
usr/lib/locale/C/LC_MESSAGES/ibfirmware
```

ATTRIBUTES

usr/sbin

See **attributes(5)** for descriptions of the following attributes:

ATTRIBUTE TYPE	ATTRIBUTE VALUE
Availability	SUNWluxop

SEE ALSO

devlinks(1M), **disks(1M)**, **ssaadm(1M)**, **attributes(5)**, **environ(5)**, **ses(7D)**
 Snively, R., *Tutorial for SCSI use of IEEE company_ID*, X3T10/97-101r2,
 February 25, 1996.
SENA Array Installation and Service Manual (p/n 802-7573).

NOTES

See the *SENA Array Installation and Service Manual* for additional information on the SENA. Refer to *Tutorial for SCSI use of IEEE Company_ID*, R. Snively, for additional information regarding the IEEE extended WWN. See **SEE ALSO**. Currently, only some device drivers support hot plugging. If hot plugging is attempted on a disk or bus where it is not supported, an error message of the form:

```
luxadm: can't acquire "PATHNAME": No such file or directory
will be displayed.
```

You must be careful not to quiesce a bus that contains the root or the **/usr** filesystems or any swap data. If you do quiesce such a bus a deadlock can result, requiring a system reboot.

NAME sm_configd – Solstice SyMON configuration reader

SYNOPSIS /opt/SUNWsymon/sbin/sm_configd [-D *debug-value*] [-T *file*] [-i *interval*]

AVAILABILITY SUNWsymon

DESCRIPTION Monitors the physical configuration of a machine and reports on the status of components. For further details, please see the *Solstice SyMON User's Guide*.

OPTIONS

- D Set a debug option for AIL.
- T Run the configuration from a file; for testing purposes.
- i Set the polling interval for the Config Reader.

FILES

- cfg_sun4d.so.1
- cfg_sun4u.so.1
- cfg_sun4ul.so.1

SEE ALSO symon(1), sm_confsymon(1M), sm_control(1M), sm_egd(1M), sm_krd(1M), sm_logscand(1M), sm_symond(1M), auth_checker.tcl(4), auth_list.tcl(4), event_gen.tcl(4), logscan.tcl(4), rules.tcl(4), sm_symond.conf(4)

NAME	sm_confsymon – configures the agent host and event monitor host machines running Solstice SyMON software
SYNOPSIS	<p>sm_confsymon -s <i>event_host</i> [-v] [-k <i>polling_time</i>] [-c <i>polling_time</i>] [-p] [-i <i>sampling_time</i>] [-U <i>user_name</i>]</p> <p>sm_confsymon -e <i>server_host</i> [-M <i>max_events</i>] [-i <i>sampling_time</i>] [-S <i>SNMP_hostname</i>] [-P <i>platform_name</i>] [-d <i>diskbox_name</i>]... [-U <i>user_name</i>]</p> <p>sm_confsymon -D</p>
AVAILABILITY	SUNWsymon
DESCRIPTION	<p>sm_confsymon configures machines that are running Solstice SyMON software as an agent host (the server that is being monitored) and as the event monitor host (the machine that is monitoring the agent host).</p> <p>This command is run on the respective machines used as agent host and event monitor host.</p> <p>For further details on the operation of sm_confsymon please see the <i>Solstice SyMON User's Guide</i>.</p>
OPTIONS	<p>-s Configures the server being monitored so it will identify the machine that is being used as the event monitor host. The machine name of monitoring machine is specified as <i>event_host</i>.</p> <p>-v Selects verbose mode, in which the system will echo all actions performed.</p> <p>-k Sets polling interval time for sm_krd to the number of seconds given as <i>polling_time</i> (default is 10 seconds).</p> <p>-c Sets polling interval time for sm_configd to the number of seconds given as <i>polling_time</i> (default is 10 seconds).</p> <p>-p Modifies disk error message level in kernel and in <i>/etc/system</i> to log soft errors for PFA.</p> <p>-i Sets sampling interval time to the number of seconds given as <i>sampling_time</i> (default is 10 seconds).</p> <p>-U Sets the user ID used by sm_logscand (when included with the -s option) or sets the user ID used by sm_egd (when included with the -e option). The user ID is automatically generated when you provide the user name as the value of <i>user_name</i>.</p> <p>-e Configures the machine doing the monitoring so it will identify the server that it is monitoring. The machine name of the monitored machine is specified as <i>server_host</i>.</p> <p>-M Sets the maximum number of events, given as <i>max_errors</i>, before trimming (default is 1000 events).</p> <p>-S Causes SNMP traps to be sent to the machine given as <i>hostname</i>.</p>

- P Specifies the type of platform that is being monitored. This value, *platform_name*, is the result of running the **uname -i** command on the server being monitored (such as **SUNW,SPARCserver-1000**).
If you do not specify this option, **sm_symonconfig** will prompt you to enter the number of a platform type from a list it displays. Configuration will not continue until you specify the platform type. You can enter the number 0 to exit at this point.
- d Specifies the type of disk storage box that is being monitored.
- D Completely removes the currently installed Solstice SyMON configuration.

SEE ALSO

symon(1), **sm_configd(1M)**, **sm_control(1M)**, **sm_egd(1M)**, **sm_krd(1M)**, **sm_logscand(1M)**, **sm_symond(1M)**, **auth_checker.tcl(4)**, **auth_list.tcl(4)**, **event_gen.tcl(4)**, **logscan.tcl(4)**, **rules.tcl(4)**, **sm_symond.conf(4)**

NAME	sm_control – starts or stops Solstice SyMON software on the server subsystem host or on the event generator machine.
SYNOPSIS	sm_control [start] [stop]
AVAILABILITY	SUNWsymon
DESCRIPTION	<p>sm_control starts Solstice SyMON software on the server subsystem host machine or the event generator machine without needing to reboot the machine. It also can shut down the program on the machine. In either case, sm_control must be run as superuser on that machine.</p> <p>For further details on the operation of sm_control please see the <i>Solstice SyMON User's Guide</i>.</p>
OPTIONS	<p>start Starts Solstice SyMON software on a machine that has been configured as the server being monitored or the machine doing the monitoring.</p> <p>stop Shuts down the Solstice SyMON software.</p>
SEE ALSO	<p>symon(1), sm_configd(1M), sm_confsymon(1M), sm_egd(1M), sm_krd(1M), sm_logscand(1M), sm_symond(1M), auth_checker.tcl(4), auth_list.tcl(4), event_gen.tcl(4), logscan.tcl(4), rules.tcl(4), sm_symond.conf(4)</p>

NAME	sm_egd – Solstice SyMON event generator
SYNOPSIS	<code>/opt/SUNWsymon/sbin/sm_egd [-i interval] [-d debug-level] [-h log-file] [-H event-history-file] [-R rules-file] [-I init-file] [-l shared-object -f shared-function] [-r export-root] [-D AIL-debug-value] [-B event-directory] [-t target-machine] [-S] [P] [-L Tcl-directory] [-U username] [-n RPC-number] [-V run-directory]</code>
AVAILABILITY	SUNWsymon
DESCRIPTION	Monitors other symon agents and reports events based on Tcl rules defined in rules files.
OPTIONS	<p>-i Specify the polling interval (in seconds) when data is collected and rules are run.</p> <p>-d Specify a debug flag for the event generator. The following numbers can be added together to specify several debug options: 1=Provides debugging on the initialization. 2=Provides some basic Tcl debugging. 4=Provides debuggin information on basic calls to rules and AIL. 8=Provides data on the rules as understood by the event generator. 16=Provides debugging on AIL callbacks. 32=Provides debugging on building match lists for MULTI rules. 64=Provides debugging on agent births and deaths.</p> <p>-h Specify the location of the event generator logfile.</p> <p>-H Specify a file used by the event generator to track event numbers.</p> <p>-R Specify a rules file. This file must contain the Rules variable in Tcl.</p> <p>-I Specify a file to initialize Tcl procedures.</p> <p>-l Specify a shared object to be loaded. This option must be used in conjunction with the -f option.</p> <p>-f Specifies the function within a shared object that will be called when this object is loaded. This option must be used in conjunction with the -l option.</p> <p>-r Specifies the name of the root for the outgoing hierarchy..</p> <p>-D Specifies an AIL debugging flag. The following numbers can be added together to specify several AIL debug options: 1=Print AIP version. 2=List of hierarchy updates. 4=Trace requests and connections. 8=Tell if replacing an existing node. 16=Debug pruning.</p>

- 32=Trace memory use.
- 64=Report **sm_symond** traffic.
- 128=Sleep 30 seconds before starting.
- 256=Fake server death if **/tmp/dead** exists.
- 512=Print out strings used.
- 1024=Print messages showing time for AIP transactions.
- B** Specifies the directory for storing the event database.
- t** Specifies the target machine to be polled.
- S** Specifies that core dumps are allowed.
- P** Specifies that process data should be polled.
- L** Specifies the location of a Tcl library.
- U** Specifies a user name under which to run the event generator program.
- Specifies an RPC number for connecting to symond.**
- V** Specifies a directory for running the event generator. (This can override the location set by the **-t** option. However, the **-h**, **-H**, or **-B** flag can override the location specified in the **-V** flag.)

FILES	<p>rules.tcl Specifies the rules, in Tcl, for the event generator. Located in /etc/opt/SUNWsymon.</p> <p>event_gen.tcl The initialization file for the event generator. Located in /etc/opt/SUNWsymon.</p> <p>event_log The log file for events. Located in /var/opt/SUNWsymon/target.</p> <p>EG_events Stores the last event number. Located in /var/opt/SUNWsymon/target.</p> <p>events/* Each event in the all events hierarchy. Located in /var/opt/SUNWsymon/target.</p>
--------------	---

SEE ALSO **symon(1)**, **sm_configd(1M)**, **sm_confsymon(1M)**, **sm_control(1M)**, **sm_krd(1M)**, **sm_logscand(1M)**, **sm_symond(1M)**, **auth_checker.tcl(4)**, **auth_list.tcl(4)**, **event_gen.tcl(4)**, **logscan.tcl(4)**, **rules.tcl(4)**, **sm_symond.conf(4)**

NAME	sm_krd – Solstice SyMON kernel reader
SYNOPSIS	<code>/opt/SUNWsymon/sbin/sm_krd [-d] [-D AIL-debug-flag] [-v] [-t] [-r] [-R] [-U kernel-file] [-M kmem-file] [-S swap-file] [-i interval] [-P count] [-T] [count]</code>
AVAILABILITY	SUNWsymon
DESCRIPTION	sm_krd monitors the kernel on an active machine, and reports data to clients. For more information, please see the <i>Solstice SyMON User's Guide</i> .
OPTIONS	<ul style="list-style-type: none"> -d Activate Kernel Reader debugging. -D Specify an AIL debugging level (values can be added together for combinations of debug output): <ul style="list-style-type: none"> 1=print AIP version 2=list of hierarchy updates 4=trace requests and connections 8=tell if replacing an existing node 10=debug pruning 20=trace memory use 40=report sm_symond traffic 80=sleep 30 seconds before starting 100=fake server death if /tmp/dead exists -v Run the kernel reader in verbose mode. -t Set the timer flag. -r Set the resource information flag. -R Set the resource information summary flag. -U Specify the name of the kernel file. -M Specify the name for the kmem file. -S Specify the name of the swap file. -i Specify the polling interval. -P Run for the specified number of intervals, then quit. -T Build the tree for debugging. <i>count</i> Automatically report data for every <i>count</i> intervals.
SEE ALSO	symon(1) , sm_configd(1M) , sm_confsymon(1M) , sm_control(1M) , sm_egd(1M) , sm_logscand(1M) , sm_symond(1M) , auth_checker.tcl(4) , auth_list.tcl(4) , event_gen.tcl(4) , logscan.tcl(4) , rules.tcl(4) , sm_symond.conf(4)

NAME	sm_logscand – Solstice SyMON log file scanner
SYNOPSIS	/opt/SUNWsymon/sbin/sm_logscand [-i <i>interval</i>] [-L <i>TCL-library</i>] [-U <i>user-name</i>] <i>log-definition-file</i>
AVAILABILITY	SUNWsymon
DESCRIPTION	Scans the log files, as described in the log definition file.
OPTIONS	-i Set the polling interval to update log files. -L Specify the location of the Tcl library. -U Specify a user name for running the program.
FILES	<i>log-definition-file</i> Initialization file for the log scanner. Located in /etc/opt/SUNWsymon.
SEE ALSO	symon(1), sm_configd(1M), sm_confsymon(1M), sm_control(1M), sm_egd(1M), sm_krd(1M), sm_symond(1M), auth_checker.tcl(4), auth_list.tcl(4), event_gen.tcl(4), logscan.tcl(4), rules.tcl(4), sm_symond.conf(4)

NAME	sm_symond – Solstice SyMON process controller
SYNOPSIS	<pre> /opt/SUNWsymon/sbin/sm_symond [-n RPC-number] [-d debug-level] [-D AIL-debug-level] [-p output-level] [-P minutes] [-i intervals] [-A file] [-C file] [-E directory] [-H directory] [-I directory] [-L file] </pre>
AVAILABILITY	SUNWsymon
DESCRIPTION	<p>sm_symond is a tool to manage Solstice SyMON processes. Its primary role is to start the program's agents, monitor those agents for crashes, and provide RPC information to clients that wish to access any of those agents.</p> <p>The primary repository for agent data is the file <code>/etc/opt/SUNWsymon/sm_symond.conf</code> (see <code>sm_symond.conf(4)</code>).</p> <p>When sm_symond is run, it first reads <code>/etc/opt/SUNWsymon/sm_symond.conf</code> to determine the local agents to be spawned. It then spawns those agents. If an entry indicates that an agent may exist on a remote system, sm_symond will poll that system looking for another symond to get information on that agent.</p> <p>Symond serves a hierarchy of information via RPC to any requesting client. Each agent should produce a hierarchy that is readable.</p> <p>sm_symond is also responsible for looking at the <code>auth_checker.tcl</code> and <code>auth_list.tcl</code> scripts to determine if a Solstice SyMON user has access to the symon data.</p>
OPTIONS	<ul style="list-style-type: none"> -n Specify a custom RPC number for this program (the default is 100244). If you use this option to specify a different number for the monitored host, you must also supply it to any client programs, such as symon or sm_egd. This option does not dissociate process and child agents. -d Debugging level for sm_symond. These values can be added together for combinations of debug output: <ul style="list-style-type: none"> 1=trace 2=callbacks 4=rpc 8=spawn info 16=debug access control 32=config file info -D Debugging level for AIL for hierarchy transport. -p Print hierarchy level: <ul style="list-style-type: none"> 1=nodes 5=nodes and prop 10=nodes, prop, and data -P Turn on profiling to dump after specified number of minutes. -i Sampling interval for checking if the agents are still alive.

- A Specifies alternative authorization checking file (default is **auth_checker.tcl**).
- C Specifies alternative configuration file (default is **sm_symond.conf**).
- E Specifies an alternative “etc” directory (default is **/etc/opt/SUNWsymon**).
- H Specifies an alternative “home” directory (default is **/var/opt/SUNWsymon**). **sm_symond** will run from inside a subdirectory called *hostname* under this directory. Any core file or debug file that is generated will reside there.
- I Specifies an alternative install directory (default is **/opt/SUNWsymon**). This contains a subdirectory called **etc** containing authorization files that are used if no authorization files are found in the directory specified by the **-E** option. This also contains a subdirectory called **lib/tcl** that contains the Tcl library.
- L Specifies an alternative authorization list file (default is **auth_list.tcl**).

FILES **/etc/opt/SUNWsymon/sm_symond.conf**
list of agents for invocation.

SEE ALSO **symon(1)**, **sm_configd(1M)**, **sm_confsymon(1M)**, **sm_control(1M)**, **sm_egd(1M)**, **sm_krd(1M)**, **sm_logscand(1M)**, **auth_checker.tcl(4)**, **auth_list.tcl(4)**, **event_gen.tcl(4)**, **logscan.tcl(4)**, **rules.tcl(4)**, **sm_symond.conf(4)**

NOTES **sm_symond** can only be run by root.

NAME	ftpd – FTP daemon that runs on the Sun MediaCenter. Enables use of standard ftp commands for moving content.
SYNOPSIS	ftp [-dgintv] [<i>hostname</i>]
AVAILABILITY	Available with the Sun MediaCenter server software. On a Sun MediaCenter server, this binary replaces the ftpd that is shipped with Solaris.
DESCRIPTION	<p>ftpd is the FTP daemon shipped with the Sun MediaCenter server. It supports all standard ftp commands, plus commands (of the same names as standard commands) that support the movement of video content between a local file system and the Media File System (MFS) on a Sun MediaCenter server. This means that you can load content onto a Sun MediaCenter server from any platform that has an FTP-protocol-conformant ftp client.</p> <p>Note: The FTP daemon described here is a superset of the standard FTP daemon. Thus, this man page supplements the ftpd (1M) man page that is shipped with Solaris.</p> <p>The video-file functions of the FTP daemon are invoked with the keyword smc: For example, you enter a command such as the following to obtain a listing of all titles on a Sun MediaCenter server:</p> <pre>ftp> ls smc:title=*</pre> <p>Note that you must use a backslash (\) to escape the asterisk.</p>
OPTIONS	See the ftp (1) man page for a description of that program's options. The Sun MediaCenter FTP daemon supports all of the standard ftp options, on all platforms.
VIDEO FILE ATTRIBUTES	<p>Video content is stored on the Sun MediaCenter server in data and index files that collectively make up a <i>title</i>. A title is identified by a string of the format:</p> <pre>smc:attr_name=value,[attr_name=value] ...</pre> <p>A fully-qualified title identifier has the form:</p> <pre>smc:name=name,speed=speed,type=[data index],rate=rate,format=format</pre> <p>Title attributes are described as follows:</p> <p>name</p> <p>Name of the movie or video clip. There is no default value.</p> <p>speed</p> <p>Refers to the speed and play direction of the title's bit stream, as compared to normal-play, forward direction. The default is 1000, meaning normal play speed, forward direction.</p>

type

"Data" or "index". A data file contains an MPEG bit stream. An index file identifies splice points within a bit stream. The default is "data".

rate

Rate at which the file containing the video bit stream was encoded, expressed in bits per second. Applies only to data files, not index files. There is no default value.

format

Format of the bit stream. Can be either MPEGTS or MPEG1SYS. Other stream formats are supported by the server, but not by the FTP daemon. Note that for MPEGTS-format titles, the FTP daemon automatically generates index files for titles that contain trick play streams.

FTP COMMANDS

Listed below are the **ftp** commands for video files supported by the Sun MediaCenter FTP daemon. These commands accept video file attributes as arguments. Some use only a name; others require a name plus other attributes.

FTP allows the use of the asterisk (*) wildcard character in specifying filenames. You must use a backslash (\) to escape the asterisk. (Some PC-based implementations of FTP clients do not require a backslash.) For video files, the asterisk stands for "all video files," including both data and index files.

The video-file commands have the same semantics as the Solaris implementation of the **ftp** commands.

The example commands assume that the user has successfully established an FTP connection with a Sun MediaCenter server.

You should always use binary mode when transferring video files.

delete

```
ftp> del smc:title=title_name
```

dir

```
ftp> dir smc:title=title_name
```

get

```
ftp> get smc:title=title_name,speed=speed,type=[data|index] path_to_local_file
```

For **get**, you should specify, in addition to name, the speed and type attributes. If you do not specify speed and type, they take default values, which might not be appropriate for your title. The rate and format attributes are recommended, especially if you might later need to **put** files back on a Sun MediaCenter server. For example, if you use **get** to backup titles, specify rate and format so that, if you ever need to restore titles (using **put**), the values for those attributes will be available.

ls

```
ftp> ls smc:title=title_name
```

mget

```
ftp> mget smc:title=\* path_to_local_file
```

mls

```
ftp> mls smc:title=title_name [smc:title=title_name]... output_file
```

For *output file*, you can use a hyphen (-) to indicate **stdout**.

mput

```
ftp> mput local_files
```

For **mput**, *local_files* must have the same format as used for the destination argument for **put**. See the following command.

put

```
ftp> put local_file smc:title=title_name,speed=speed,\  
type=[data | index],rate=rate,format=format
```

If you do not specify speed and type attributes for **put**, the default values are used. You must specify the rate and format attributes for this command.

rename

```
ftp> rename smc:title=title_name
```

rename accepts only a name attribute. You are prompted for a new name after entering the command.

EXAMPLES

All examples assume a successful FTP connection with a Sun MediaCenter server.

```
ftp> dir smc:
```

```
ftp> ls smc:title=\*
```

The two preceding commands return a list of the titles stored on the server, with their attributes.

```
ftp> get smc:title=bambi,speed=1000,type=data,rate=3000000 \  
/home/backup/bambi.data
```

The preceding command copies the title "Bambi", with relevant attributes, to a file in the local file system.

```
ftp> put /home/backup/batman.data \  
smc:title=bambi,speed=1000,type=data,rate=3000000,format=MPEG1SYS
```

The preceding command copies the data file for "Bambi" from a local file system to a Sun MediaCenter server.

The following sequence might be used to backup and restore video files on a Sun MediaCenter server:

1. Establish FTP connection to Sun MediaCenter server:

```
# ftp server_name
```

Logon as root.

2. Check on titles:

```
ftp> ls smc:title=* smc:title=bambi,format=MPEGTS,speed=1000,type=data,rate=3072000
```

3. Use output from previous command to backup titles:

```
ftp> get smc:title=bambi,format=MPEGTS,speed=1000,type=data,rate=3072000 \  
/home/backup/bambi.vid
```

You might also use: `mget smc:title=*`

```
ftp> put /home/backup/bambi.vid \  
smc:title=bambi,format=MPEGTS,rate=3072000
```

In the preceding command, note that the speed and type attributes are not specified. Speed defaults to 1000 and type defaults to data, which are appropriate choices for this example. Also note that format and rate *are* specified, which is a requirement for a **put** command.

SEE ALSO

The *Sun MediaCenter Administrator's Guide*

smc_copy (1), **smc_tar (1)**, **smc_ls (1)**, **smc_rm (1)**

NAME	<code>smc_gettacl</code> – obtain access control list for titles on Sun MediaCenter server
SYNOPSIS	<code>smc_gettacl</code> [<i>server:</i>] < <i>titlename</i> >...
AVAILABILITY	Available with the Sun MediaCenter Server software. <code>smc_gettacl</code> is a companion command to <code>smc_settacl</code> (1M)
DESCRIPTION	<code>smc_gettacl</code> allows you to obtain the access control list (ACL) associated with a title on a Sun MediaCenter server. Output from <code>smc_gettacl</code> is suitable as input for the <code>-f</code> option of <code>smc_settacl</code> . It is useful to pipe output from <code>smc_gettacl</code> to <code>smc_settacl</code> to set the ACL for a title to be the same as another title's ACL.
OPTIONS	<code>smc_gettacl</code> has no options. It accepts as an argument: [<i>server:</i>] < <i>titlename</i> >... You can specify one or more titles, any of which can be local or remote. Specify multiple title names with a space between each pair. For a remote title, you prepend the name of the Sun MediaCenter server and a colon to the title name. You can use an asterisk in the < <i>titlename</i> > field, which means all titles on the server. You must use a backslash (\) to escape the asterisk.
EXAMPLES	The following command obtains the ACL for the local title "bambi" and the remote title "ben_hur", which is stored on the server "nicene". % <code>smc_gettacl bambi nicene:ben_hur</code> The following command pipes output from <code>smc_gettacl</code> to <code>smc_settacl</code> , setting the ACL for "bambi" to match that of "ben_hur". % <code>smc_gettacl nicene:ben_hur smc_settacl -f - bambi</code>
SEE ALSO	<code>smc_tar</code> (1), <code>smc_copy</code> (1), <code>smc_settacl</code> (1M)

NAME	<code>smc_settACL</code> – set title access control list for Sun MediaCenter server
SYNOPSIS	<pre> smc_settACL -s m <acl_entries> [server:] <titlename>... smc_settACL -d <title_users> [server:] <titlename>... smc_settACL -f <filename> [server:] <titlename>... </pre>
AVAILABILITY	Available with the Sun MediaCenter Server software.
DESCRIPTION	<code>smc_settACL</code> allows you to set, modify, or delete the access control list (ACL) associated with a title on a Sun MediaCenter server. After copying a video file (title) to a server, you must use <code>smc_settACL</code> if you want other users to be able copy, append to, or delete that title.
OPTIONS	<pre> -s <acl_entries> [server:] <titlename>... </pre> <p>Replace the current title ACL with an ACL containing the information specified in <code><acl_entries></code>. <code><acl_entries></code> stands for a comma-separated list of items of the form:</p> <pre> u[ser]:<username>:<permissions> </pre> <p><code><username></code> is a Solaris login name; <code><permissions></code> is one or more of r, w, and a (read, write, and admin, respectively). You specify permissions in the order rwa. Replace any permission you are not setting with a hyphen. So, for example, if you are setting only admin permission, you specify <code>--a</code>; if you are setting only read and admin, specify <code>r-a</code>. Permissions are defined in the <i>Sun MediaCenter Server Programmer's Guide</i>.</p> <pre> -m <acl_entries> [server:] <titlename>... </pre> <p>Modify the current title ACL according to <code><acl_entries></code>. If you specify a user who is not in the title ACL, that user is appended to the ACL. If you specify a user who is in the ACL, the permissions for that user are changed to what you specify.</p> <pre> -d <title_users> [server:] <titlename>... </pre> <p>From the ACL for a specified title, deletes users specified in <code><title_users></code>, which is a comma-separated list of items of the form:</p> <pre> u[ser]: <username> </pre> <p>where <code><username></code> is a Solaris login name.</p> <pre> -f <filename> [server:] <titlename>... </pre> <p>Set the ACL(s) for the specified title(s) according to the contents of <code><filename></code>, a text file containing a list of entries of the form of <code><acl_entries></code>, above, with one entry per line. You can have comments in the file; comments are indicated by a hash mark in column 1.</p> <p>You cannot use the <code>-s</code> and <code>-f</code> options with any other option. You can combine <code>-m</code> and <code>-d</code>.</p>

For the **-s**, **-m**, and **-d** options and in an entry in a file introduced by **-f**, you can use an asterisk in the user field, which means "any user".

For all options, you can specify one or more titles, any of which can be local or remote. Specify multiple title names with a space between each pair. For a remote title, you prepend the name of the Sun MediaCenter server and a colon to the title name. You can use an asterisk in the title name field to stand for all titles on a server. You must use a backslash (\) to escape the asterisk.

EXAMPLES

The following command replaces an ACL associated with the title "bambi" with an ACL that allows the user "srinivasan" read and admin access.

```
% smc_settacl -s u:srinivasan:r-a bambi
```

The following command modifies the ACL associated with the title "bambi", adding the user "srinivasan", with read and admin access.

```
% smc_settacl -m u:srinivasan:r-a bambi
```

The following command deletes the user "srinivasan" from the ACL for the title "bambi" on the remote server "nicene".

```
% smc_settacl -d u:srinivasan nicene:bambi
```

The following command sets the ACLs for all titles on the remote server "nicene" according to the contents of the file "acl_list".

```
% smc_settacl -f /home/admin/acl_list nicene:\*
```

SEE ALSO

smc_tar (1), **smc_copy (1)**, **smc_gettacl (1M)**

NAME	ssp-config – set initial SSP configuration information on the host
DESCRIPTION	<p>Caution: Never execute this command on the command line.</p> <p>/usr/platform/sbin/bin/ssp-config is normally invoked by the /etc/init.d/sspdefs startup script during boot of the Enterprise 10000 host, but only if the file ./SSP_DEFAULTS exists. ssp-config interactively prompts for information, including the SSP's hostname and IP address. It uses the information to set the initial configuration to allow communication between the server and the SSP.</p> <p>Only super user can run ssp-config.</p>
FILES	<p>./SSP_DEFAULTS /etc/inet/hosts /etc/ssphostname /etc/syslog.conf</p>
SEE ALSO	ssp-unconfig(1M)

NAME	ssp-unconfig – undo SSP and system information on the host
DESCRIPTION	<p>Caution: Only super user can use this command. Exercise extreme caution in its use.</p> <p>When executed on an Enterprise 10000 server <code>/usr/platform/sun4u1/sbin/ssp-unconfig</code> removes configuration information established by the command <code>ssp-config(1M)</code>, then invokes the SunOS command <code>sys-unconfig(1M)</code> to make the system ready to be configured again.</p> <p>The <code>ssp-unconfig</code> command does the following:</p> <ul style="list-style-type: none">• Removes SSP information from the <code>/etc/syslog.conf</code> and <code>/etc/inet/hosts</code> files.• Removes the <code>/etc/ssphostname</code> file. <p>When finished, <code>ssp-unconfig</code>, invokes the SunOS command <code>sys-unconfig(1M)</code>, which performs a system shutdown.</p>
FILES	<code>/.SSP_DEFAULTS</code> <code>/etc/inet/hosts</code> <code>/etc/ssphostname</code> <code>/etc/syslog.conf</code>
SEE ALSO	<code>ssp-config(1M)</code> in this reference manual <code>sys-unconfig(1M)</code> in <i>man Pages(1M): System Administration Commands</i>

NAME	sunvts – Invokes the SunVTS kernel and its user interface
SYNOPSIS	sunvts [-lepqstv] [-o <i>option_file</i>] [-f <i>log_dir</i>] [-h <i>hostname</i>]
AVAILABILITY	SUNWvts
DESCRIPTION	The sunvts command is used to invoke the SunVTS user interface and kernel on the same system. It could be used to start the user interface on the local system and connect to the SunVTS kernel on the remote system. By default, it displays CDE Motif graphic interface for CDE environment, OpenLook graphic interface for OpenWindows environment, or TTY interface for non-windowing system.
OPTIONS	<ul style="list-style-type: none"> -l Displays SunVTS OpenLook graphic interface. -e Disables the security checking feature. -f <i>log_dir</i> Specifies an alternative log_file directory. The default log_file directory is /var/opt/SUNWvts/logs. -h <i>hostname</i> Starts the SunVTS user interface on the local system, which connects to or invokes the SunVTS kernel on the specified host after security checking succeeds. -o <i>option_file</i> Starts the SunVTS kernel with the test options loaded from the specified <i>option_file</i>, which by default is located in /var/opt/SUNWvts/options. -p Starts the SunVTS kernel vtsk (1M) such that it does not probe the test system's devices. -q Automatically quits both the SunVTS kernel and the user interface when testing stops. -s Automatically starts testing from a selected group of tests. The flag must be used with the -o <i>option_file</i> flag. -t Starts vts tty (1M), a TTY based interface, instead of CDE or OpenLook interface. -v Displays version information from vtsui(1M) and vtsk(1M).
NOTES	If vtsk (1M) is already running on the test system, the sunvts command ignores the -e , -o , -f , -q , -p , and -s options.
SEE ALSO	vtsk(1M) , vts tty(1M) , vtsui(1M) , vtsui.ol(1M) , vtsprobe(1M)

NAME	vtsk – SunVTS diagnostic kernel
SYNOPSIS	vtsk [-epqsv] [-o options_file] [-f logfile_directory]
AVAILABILITY	SUNWvts
DESCRIPTION	<p>The vtsk command starts up the SunVTS diagnostic kernel as a background process. There can only be one copy of vtsk running at a time. Only the superuser can execute this command.</p> <p>Normally, vtsk is automatically started up by the sunvts (1M) command if it is not already running. vtsk will also be invoked by inetd (1M) when there is a connection request from vtsui or vtsui.ol. In that case, the security file, .sunvts_sec, will be checked for the permission before running vtsk on the target host specified by vtsui(1M) or vtsui.ol(1M).</p>
OPTIONS	<ul style="list-style-type: none"> -e Enables the security checking for all connection requests. -p Starts SunVTS diagnostic kernel, but does not probe system configuration. -q Quits both the SunVTS diagnostic kernel and the attached User Interfaces when the testing is completed. -s Runs enabled tests immediately after started. -v Display SunVTS diagnostic kernel's version information only. -o options_file Starts the SunVTS diagnostic kernel and sets the test options according to the option file named <i>options_file</i>. -f logfile_directory Specifies an alternative logfile directory, other than the default.
EXIT STATUS	<p>The following exit values are returned:</p> <ul style="list-style-type: none"> 0 Successful completion. -1 An error occurred.
FILES	<ul style="list-style-type: none"> /var/opt/SUNWvts/options default option file directory. /var/opt/SUNWvts/logs default log file directory.
SEE ALSO	sunvts(1M), vtsui(1M), vtsui.ol(1M), vtstty(1M), vtsprobe(1M)

NAME	vtsprobe – prints the device probe information from the SunVTS kernel
SYNOPSIS	vtsprobe [-m] [-h <i>hostname</i>]
AVAILABILITY	SUNWvts
DESCRIPTION	vtsprobe is a utility that displays the device and configuration information contained in the SunVTS kernel. The output includes the SunVTS assigned group for the device, the device name, the device instance, the testname attached to this device, and the configuration information obtained from the device-specific test probe.
OPTIONS	<p>-m Specifies manufacturing mode, which displays the probe information in a format that is easy to read using script files.</p> <p>-h <i>hostname</i> Specifies the <i>hostname</i> to connect to and get the device and configuration information. If not specified, the current host will be used.</p>
USAGE	After the SunVTS kernel is up and running, you may type vtsprobe at the shell prompt to get the probe output. (See the sunvts (1M) man page for more information on how to start up SunVTS.
EXAMPLE	<p>Running vtsprobe on a sun4m SPARCclassic produces the following output:</p> <pre> % vtsprobe Processor(s) system(system) System Configuration=sun4m SPARCclassic System clock frequency=50 MHz SBUS clock frequency=25 MHz fpu(fputest) Architecture=sparc Type=TI TMS390S10 or TMS390S15 microSPARC chip Memory kmem(vmem) Total: 143120KB mem(pmem) Physical Memory size=24 Mb SCSI-Devices(esp0) c0t2d0(rawtest) Capacity: 638.35MB Controller: esp0 Vendor: MICROP SUN Id: 1588-15MBSUN0669 Firmware Rev: SN0C </pre>

```

        Serial Number: 1588-15MB103
c0t2d0(fstest)
        Controller: esp0
c0t3d0(rawtest)
        Capacity: 404.65MB
        Controller: esp0
        Vendor: SEAGATE
        SUN Id: ST1480 SUN0424
        Firmware Rev: 8628
        Serial Number: 00836508
c0t3d0(fstest)
        Capacity: 404.65MB
        Controller: esp0
        Vendor: SEAGATE
        SUN Id: ST1480 SUN0424
        Firmware Rev: 8628
        Serial Number: 00836508
c0t3d0(fstest)
        Controller: esp0
c0t6d0(cdtest)
        Controller: esp0
tape1(tapetest)
        Drive Type: Exabyte EXB-8500 8mm Helical Scan
Network
  isdn0(isdntest)
        NT Port TE Port
  le0(nettest)
        Host_Name: ctech84
        Host Address: 129.146.210.84
        Host ID: 8001784b
        Domain Name: scsict.Eng.Sun.COM
Comm.Ports
  zs0(sptest)
        Port a -- zs0 /dev/term/a : /devices/ ... a
        Port b -- zs1 /dev/term/b : /devices/ ... b
Graphics
  cgthree0(fbtest)

OtherDevices
  bpp0(bpptest)
        Logical name: bpp0
  sound0(audio)
        Audio Device Type: AMD79C30
  sound1(audio)
        Audio Device Type: DBRI Speakerbox

```

spd0(spctest)
Logical name: spd0

NOTES The output of **vtsprobe** is highly dependent on the device being correctly configured into the system (so that a SunVTS probe for the device can be run successfully on it) and on the availability of a device-specific test probe.

If the device is improperly configured or if there is no probing function associated with this device, **vtsprobe** cannot print any information associated with it.

SEE ALSO **sunvts(1M)**, **vtsk(1M)**, **vtsui(1M)**, **vtsui.ol(1M)**, **vtstty(1M)**

NAME	vtstty – TTY interface for SunVTS																
SYNOPSIS	vtstty [-qv] [-h <i>hostname</i>]																
AVAILABILITY	SUNWvts																
DESCRIPTION	vtstty is the default interface for SunVTS in the absence of a windowing environment. It can be used in a non-windowing environment such as a terminal connected to the serial port of the system. However, its use is not restricted to this; vtstty can also be used from shell window.																
OPTIONS	<p>-q The "auto-quit" option automatically quits when the conditions for SunVTS to quit are met.</p> <p>-v Prints the vtstty version. The interface is not started when you include this option.</p> <p>-h <i>hostname</i> Connects to the SunVTS kernel running on the host identified by <i>hostname</i>.</p>																
USAGE	<p>The vtstty screen consists of four panels: main control, status, test groups, and console. The panels are used to display choices that the user can select to perform some function and/or to display information. A panel is said to be "in focus" or in a "selected" state when it is surrounded by asterisks and the current item is highlighted. In order to choose from the items in a panel, the focus should be shifted to that panel first.</p> <p>The following are the different types of selection items that can be present in a panel:</p> <table border="0"> <tr> <td style="padding-right: 20px;">Text string</td> <td>Describes a choice that, when selected, either pops up another panel or performs a function. For example, "stop" will stop the SunVTS testing.</td> </tr> <tr> <td>Data entry field</td> <td>To enter or edit numeric or textual data.</td> </tr> <tr> <td>Checkbox</td> <td>Represented as "[]". Checkboxes are associated with items and indicate whether the associated item is selected or not. A checkbox can be in one of the following two states: Deselected [] or Selected [*].</td> </tr> </table> <p>The key assignments given below describe the keys for shifting focus, making a selection, and performing other functions:</p> <table border="0"> <tr> <td style="padding-right: 20px;">TAB or <CTRL>W</td> <td>Shift focus to another panel</td> </tr> <tr> <td>RETURN</td> <td>Select current item</td> </tr> <tr> <td>Spacebar</td> <td>Toggle checkbox</td> </tr> <tr> <td>Up arrow or <CTRL>U</td> <td>Move up one item</td> </tr> <tr> <td>Down arrow or <CTRL>N</td> <td>Move down one item</td> </tr> </table>	Text string	Describes a choice that, when selected, either pops up another panel or performs a function. For example, "stop" will stop the SunVTS testing.	Data entry field	To enter or edit numeric or textual data.	Checkbox	Represented as "[]". Checkboxes are associated with items and indicate whether the associated item is selected or not. A checkbox can be in one of the following two states: Deselected [] or Selected [*].	TAB or <CTRL>W	Shift focus to another panel	RETURN	Select current item	Spacebar	Toggle checkbox	Up arrow or <CTRL>U	Move up one item	Down arrow or <CTRL>N	Move down one item
Text string	Describes a choice that, when selected, either pops up another panel or performs a function. For example, "stop" will stop the SunVTS testing.																
Data entry field	To enter or edit numeric or textual data.																
Checkbox	Represented as "[]". Checkboxes are associated with items and indicate whether the associated item is selected or not. A checkbox can be in one of the following two states: Deselected [] or Selected [*].																
TAB or <CTRL>W	Shift focus to another panel																
RETURN	Select current item																
Spacebar	Toggle checkbox																
Up arrow or <CTRL>U	Move up one item																
Down arrow or <CTRL>N	Move down one item																

Left arrow	or	<CTRL>P	
			Move left one item
Right arrow	or	<CTRL>R	
			Move right one item
Backspace			Delete text in a data entry field
ESC			Dismiss a pop-up
<CTRL>F			Scroll forward in a scrollable panel
<CTRL>B			Scroll backward in a scrollable panel
<CTRL>X			Quit vtstty but leave the SunVTS kernel running
<CTRL>L			Refresh the vtstty screen

NOTES

1. To run **vtstty** from a telnet session, carry out the following steps:
 - a. Before telnet-ing, determine the values for "rows and "columns". (See **stty(1)**).
 - b. Set term to the appropriate type after telnet-ing(for example, **set term=vt100**).
 - c. Set the values of columns and rows to the value noted above. (See **stty(1)**).
2. Before running **vtstty** ensure that the environment variable describing the terminal type is set correctly.

SEE ALSO

sunvts(1M), **vtsk(1M)**, **vtsui(1M)**, **vtsui.ol(1M)**, **vtsprobe(1M)**

NAME	vtsui – SunVTS Graphic User Interface (CDE)
SYNOPSIS	vtsui [-qv] [-h <i>hostname</i>]
AVAILABILITY	SUNWvts
DESCRIPTION	<p>The vtsui command starts up the CDE Motif version of SunVTS graphic user interface. There can be multiple instances of vtsui running at the same time, all connected to one SunVTS diagnostic kernel, vtsk(1M). The name of the host machine running the diagnostic kernel, vtsk(1M), will be displayed in the title bar of the graphical user interface window.</p> <p>vtsui is automatically started up by the sunvts (1M) command. vtsui can be also used to start vtsk (1M) if inetd (1M) is in operation. In that case, the security file, sunvts_sec, will be checked for the permission before running vtsk on the target host. See the "SunVTS User's Guide" for a complete description on using the graphical user interface.</p>
OPTIONS	<p>-q Quits the SunVTS graphic user interface when testing has terminated.</p> <p>-v Displays graphic user interface version information only.</p> <p>-h <i>hostname</i> Starts the SunVTS graphic user interface and connects to the SunVTS diagnostic kernel running on <i>hostname</i>, or invokes the kernel if not running, after security checking succeeds. If <i>hostname</i> not specified, the local host is assumed.</p>
EXIT STATUS	<p>The following exit values are returned:</p> <p>0 Successful completion.</p> <p>1 An error occurred.</p>
SEE ALSO	sunvts(1M), vtsk(1M), vtsui.ol(1M), vtstty(1M), vtsprobe(1M)

NAME	vtsui.ol – SunVTS Graphic User Interface (OpenLook)
SYNOPSIS	vtsui.ol [-qv] [-h <i>hostname</i>]
AVAILABILITY	SUNWvts
DESCRIPTION	<p>The vtsui.ol command starts up the OpenLook version of SunVTS graphic user interface. There can be multiple instances of vtsui.ol running at the same time, all connected to one SunVTS diagnostic kernel, vtsk(1M). The name of the host machine running the diagnostic kernel, vtsk(1M), will be displayed in the title bar of the graphic user interface window.</p> <p>vtsui.ol can be used to start vtsk(1M) if inetd(1M) is in operation. In that case, the security file, .sunvts_sec, will be checked for the permission before running vtsk on the target host. vtsui.ol is also automatically started up by the sunvts(1M) command. See the "SunVTS User's Guide" for a complete description on using the graphic user interface.</p>
OPTIONS	<p>-q Quits the SunVTS graphic user interface when testing has terminated.</p> <p>-v Displays graphic user interface version information only.</p> <p>-h <i>hostname</i> Starts the SunVTS graphic user interface and connects to the SunVTS diagnostic kernel running on <i>hostname</i>, or invokes the kernel if not running, after security checking succeeds. If <i>hostname</i> not specified, the local host is assumed.</p>
EXIT STATUS	<p>The following exit values are returned:</p> <p>0 Successful completion.</p> <p>1 An error occurred.</p>
SEE ALSO	sunvts(1M), vtsk(1M), vtsui(1M), vtstty(1M), vtsprobe(1M)

NAME	config_change_state, etc. – Configuration administration interface
SYNOPSIS	<pre>cc [flag ...] file ... -lcfgadm -ldl [library...] #include <config_admin.h> cfga_err_t config_change_state(cfga_cmd_t state_change_cmd, int num_ap_ids, char * const *ap_ids, const char *options, struct cfga_confirm *confp, struct cfga_msg *msgp, char **errstring, cfga_flags_t flags); cfga_err_t config_private_func(const char *function, int num_ap_ids, char * const *ap_ids, const char *options, struct cfga_confirm *confp, struct cfga_msg *msgp, char **errstring, cfga_flags_t flags); cfga_err_t config_test(int num_ap_ids, char * const *ap_ids, const char *options, struct cfga_msg *msgp, char **errstring, cfga_flags_t flags); cfga_err_t config_stat(int num_ap_ids, char * const *ap_ids, struct cfga_stat_data *buf, const char *options, char **errstring); cfga_err_t config_list(struct cfga_stat_data **ap_id_list, int *nlist, const char *options char **errstring); cfga_err_t config_ap_id_cmp(const cfga_ap_id_t ap_id1, const cfga_ap_id_t ap_id2); void config_unload_libs(); const char *config_strerror(cfga_err_t cfgernum);</pre>
HARDWARE DEPENDENT LIBRARY SYNOPSIS	<pre>cfga_err_t cfga_change_state(cfga_cmd_t state_change_cmd, const char *ap_id, const char *options, struct cfga_confirm *confp, struct cfga_msg *msgp, char **errstring, cfga_flags_t flags); cfga_err_t cfga_private_func(const char *function, const char *ap_id, const char *options, struct cfga_confirm *confp, struct cfga_msg *msgp, char **errstring, cfga_flags_t flags); cfga_err_t cfga_test(const char *ap_id, const char *options, struct cfga_msg *msgp, char **errstring, cfga_flags_t flags); cfga_err_t cfga_stat(const char *ap_id, struct cfga_stat_data *buf, const char *options char **errstring); cfga_err_t cfga_list(struct cfga_stat_data **ap_id_list, int *nlist, const char *options char **errstring);</pre>

AVAILABILITY	<code>cfga_err_t cfga_ap_id_cmp(const cfga_ap_id_t ap_id1, const cfga_ap_id_t ap_id2);</code> <code>const char *cfga_strerror(cfga_err_t cfgerrnum);</code>
MT-LEVEL	SUNWcsu, SUNWkvm
DESCRIPTION	<p>The config_xxxx routines provide a hardware independent interface to hardware specific system configuration administration functions. The cfga_xxxx routines are provided by hardware specific libraries that are dynamically loaded to handle configuration administration functions in a hardware specific manner.</p> <p>The libcfgadm library is used to provide the services of the cfgadm(1M) command. The libcfgadm hardware specific libraries are located in /usr/lib/cfgadm. The hardware specific library names are obtained from properties in device tree nodes that identify attachment points, or derived from the caller supplied <i>ap_id</i>.</p> <p>The config_change_state routine performs functions that change the state of the system configuration. The <i>state_change_cmd</i> can be one of the following: CFG_CMD_PREP, CFG_CMD_LOAD, CFG_CMD_UNLOAD, CFG_CMD_RESUME, CFG_CMD_DISCONNECT, CFG_CMD_CONNECT, CFG_CMD_CONFIGURE or CFG_CMD_UNCONFIGURE. The <i>state_change_cmd</i> CFG_CMD_PREP is used to prepare a receptacle for physical addition or removal of an occupant. The <i>state_change_cmd</i> CFG_CMD_LOAD is used to activate automatic hardware insertion of an occupant. The <i>state_change_cmd</i> CFG_CMD_UNLOAD is used to activate automatic hardware removal of an occupant. The <i>state_change_cmd</i> CFG_CMD_RESUME is used to exit the CFG_STAT_PREPPED state after the physical addition or removal of an occupant. The <i>state_change_cmd</i> CFG_CMD_DISCONNECT is used to disable normal communication to or from an occupant in a receptacle. The <i>state_change_cmd</i> CFG_CMD_CONNECT is used to enable communication to or from an occupant in a receptacle. The <i>state_change_cmd</i> CFG_CMD_CONFIGURE is used to bring the hardware resources contained on, or attached to, an occupant into the realm of Solaris, allowing use of the occupant's hardware resources by the system. The <i>state_change_cmd</i> CFG_CMD_UNCONFIGURE is used to remove the hardware resources contained on, or attached to, an occupant from the realm of Solaris, disallowing further use of the occupant's hardware resources by the system.</p> <p>The <i>flags</i> argument may contain one or both of the defined flags, CFG_FLAG_FORCE and CFG_FLAG_VERBOSE. If the CFG_FLAG_FORCE flag is asserted certain safety checks will be overridden. For example, this may not allow an occupant in the failed condition to be configured, but might allow an occupant in the failing condition to be configured. Acceptance of a force is hardware dependent. If the CFG_FLAG_VERBOSE flag is asserted hardware specific details relating to the operation are output utilizing the cfga_msg mechanism.</p>

The **config_private_func** routine invokes non-state changing private hardware specific functions.

The **config_test** routine is used to initiate testing of the specified attachment point.

The *num_ap_ids* argument specifies the number of *ap_ids* in the *ap_ids* array. The *ap_ids* argument points to an array of *ap_ids*.

The *ap_id* argument points to a single *ap_id*.

The *function* and *options* strings conform to the **getsubopt(3C)** syntax convention and are used to supply hardware specific function or option information. No generic hardware independent functions or options are defined.

The **cfga_confirm** structure referenced by *confp* provides a call-back interface to get permission to proceed should the requested operation require, for example, a noticeable service interruption. The **cfga_confirm** structure includes the following members:

```
int    (*confirm)(void *appdata_ptr, const char *message);
void   *appdata_ptr;
```

The **confirm** function is called with two arguments: The generic pointer *appdata_ptr* and the message detailing what requires confirmation. The generic pointer *appdata_ptr* is set to the value passed in in the **cfga_confirm** structure member **appdata_ptr** and can be used in a graphical user interface to relate the **confirm** function call to the **config_xxxx** call. The **confirm** function should return one (1) to allow the operation to proceed and zero (0) otherwise.

The **cfga_msg** structure referenced by *msgp* provides a call-back interface to output intermediate messages from a hardware specific library. In the presence of the **CFGA_FLAG_VERBOSE** flag these messages can be informational, otherwise they are restricted to error messages. The **cfga_msg** structure includes the following members:

```
void   (*message_routine)(void *appdata_ptr, const char *message);
void   *appdata_ptr;
```

The **message_routine** function is called with two arguments: The generic pointer *appdata_ptr* and the message. The generic pointer *appdata_ptr* is set to the value passed in in the **cfga_confirm** structure member **appdata_ptr** and can be used in a graphical user interface to relate the **message_routine** function call to the **config_xxxx** call. The messages will be in the native language specified by the **LC_MESSAGES** locale category; see **setlocale(3C)**.

For some generic errors a hardware specific error message can be returned. The storage for the error message string, including the terminating null character, is allocated by the **config_xxxx** functions using **malloc(3C)** and a pointer to this storage returned through *errstring*. If *errstring* is NULL no error message will be generated or returned. If *errstring* is not NULL and no error message is generated, the pointer referenced by *errstring* will be set to NULL. It is the responsibility of the function calling **config_xxxx** to deallocate the returned storage using **free(3C)**. The error messages will be in the native language specified by the **LC_MESSAGES** locale category; see **setlocale(3C)**.

The **config_stat** routine provides a way of getting status for an attachment point. The **cfga_stat_data** structure includes the following members:

```

cfga_ap_id_t ap_log_id;      /* Attachment point logical id */
cfga_ap_id_t ap_phys_id;     /* Attachment point physical id */
cfga_stat_t   ap_r_state;     /* Receptacle state */
cfga_stat_t   ap_o_state;     /* Occupant state */
cfga_cond_t  ap_cond;        /* Attachment point condition */
cfga_activity_t ap_activity; /* Activity indicators */
time_t       ap_status_time; /* Attachment point last change */
cfga_info_t  ap_info;        /* Miscellaneous information */
cfga_type_t  ap_type;        /* Occupant type */

```

The types are defined as follows:

```

typedef char cfga_ap_id_t[CFGA_AP_ID_LEN];
typedef char cfga_info_t[CFGA_INFO_LEN];
typedef char cfga_type_t[CFGA_TYPE_LEN];
typedef enum cfga_cond_t;
typedef enum cfga_stat_t;
typedef enum cfga_activity_t;
typedef int cfga_flags_t;

```

The **ap_log_id** and the **ap_phys_id** fields give the hardware specific logical and physical names of the attachment point. The **ap_activity** field indicates activity that may result in changes to state or condition. The **ap_status_time** field gives the time at which either the **ap_r_state**, **ap_o_state** or **ap_cond** fields of the attachment point, last changed. The field **ap_info** provides additional information, such as speed, that may be available from the hardware dependent code.

The fields **ap_log_id**, **ap_phys_id**, **cfga_info_t** and **cfga_type_t** are null terminated strings. When printing these fields the following format is suggested:

```

printf("%.*s", sizeof(p->ap_log_id), p->ap_log_id);

```

The **config_list** routine provides a way of obtaining the status of all attachment points in the system. The function returns an array of **cfga_stat_data** structures, one for each attachment point in the system. The storage for the array is allocated by the **config_list** function using **malloc(3C)** and a pointer to this storage returned through **ap_id_list**. The number of array elements is returned through **nlist**. It is the responsibility of the function calling **config_list** to deallocate the returned storage using **free(3C)**.

The **config_ap_id_cmp** function performs a hardware dependent comparison on two **ap_ids**, returning an equal to, less than or greater than indication in the manner of **strcmp(3C)**. Each argument is either a **cfga_ap_id_t** or can be a null terminated string. This function can be used when sorting lists of **ap_ids**, for example with **qsort(3C)**, or when selecting entries from the result of a **config_list** function call.

The **config_unload_libs** function unlinks all previously loaded hardware specific libraries.

The **config_strerror** function can be used to map an error return value (see below) to an error message string. The returned string should not be overwritten. **config_strerror** returns NULL if *cfgerrnum* is out-of-range.

RETURN VALUES

The list below gives the possible values returned by **config_xxxx** and **cfga_xxxx** routines. Additional error information may be returned through *errstring*, as defined above, if the return code is not **CFGA_OK**.

CFGA_OK

The command completed as requested.

CFGA_NACK

The command was not completed due to a negative acknowledgement from the *confp->confirm* function.

CFGA_NOTSUPP

System configuration administration is not supported on the specified target.

CFGA_OPNOTSUPP

System configuration administration operation is not supported on this attachment point.

CFGA_PRIV

The caller does not have the required process privileges. For example, if configuration administration is performed through a device driver, the permissions on the device node would be used to control access.

CFGA_BUSY

The command was not completed due to an element of the system configuration administration system being busy.

CFGA_SYSTEM_BUSY

The command required a service interruption and was not completed due to a part of the system that could not be quiesced.

CFGA_LIB_ERROR

A procedural error occurred in the library, including failure to obtain process resources such as memory and file descriptors.

CFGA_NO_LIB

A hardware specific library could not be located using the supplied *ap_id*.

CFGA_ERROR

An error occurred during the processing of the requested operation. This error code includes validation of the command arguments by the hardware specific code.

ERRORS

Many of the errors returned by the system configuration administration functions are hardware specific. The strings returned in *errstring* may include the following:

attachment point *ap_id* not known

The attachment point detailed in the error message does not exist.

unknown hardware option *option* for operation

An unknown option was encountered in the *options* string.

hardware option *option* requires a value

An option in the *options* string should have been of the form *option=value*.

hardware option *option* does not require a value

An option in the *options* string should have been a simple option.

attachment point *ap_id* is not configured

A *config_change_state* command to **CFGA_CMD_UNCONFIGURE** an occupant was made to an attachment point whose occupant was not in the **CFGA_STAT_CONFIGURED** state.

attachment point *ap_id* is not unconfigured

A *config_change_state* command requiring an unconfigured occupant was made to an attachment point whose occupant was not in the **CFGA_STAT_UNCONFIGURED** state.

attachment point *ap_id* condition not satisfactory.

A *config_change_state* command was made to an attachment point whose condition prevented the operation.

attachment point *ap_id* in condition *condition* cannot be used

A *config_change_state* operation with force indicated was directed to an attachment point whose condition fails the hardware dependent test.

SEE ALSO `cfgadm(1M)`, `dlopen(3x)`, `dlsym(3x)`.

NOTES

Applications using this library should be aware that the underlying implementation may use system services which alter the contents of the external variable **errno** and may use file descriptor resources.

The following code shows the intended error processing when **config_change_state**, **config_private_func**, **config_test**, **config_stat** or **config_list** returns a value other than **CFGA_OK**:

```
void
emit_error(int cfgerrnum, char *estrp)
{
    const char *ep;

    ep = config_strerror(cfgerrnum);
    if (ep == NULL)
        ep = gettext("configuration administration unknown error");
    if (estrp != NULL && *estrp != '\0') {
        (void) fprintf(stderr, "%s: %s\n", ep, estrp);
    } else {
        (void) fprintf(stderr, "%s\n", ep);
    }
    if (estrp != NULL)
        free((void *)estrp);
}
```

}

Reference should be made to the Hardware Specific Guide for details of System Configuration Administration support.

NAME	auth_checker.tcl – Parser for handling list of authorized Solstice SyMON users
SYNOPSIS	<code>/opt/SUNWsymon/etc/auth_checker.tcl</code>
DESCRIPTION	This Tcl file parses the list of authorized Solstice SyMON users contained in the <code>auth_list.tcl(4)</code> file. For more information, see the <i>Solstice SyMON User's Guide</i>
SEE ALSO	<code>symon(1)</code> , <code>sm_configd(1M)</code> , <code>sm_confsymon(1M)</code> , <code>sm_control(1M)</code> , <code>sm_egd(1M)</code> , <code>sm_krd(1M)</code> , <code>sm_logscand(1M)</code> , <code>sm_symond(1M)</code> , <code>auth_list.tcl(4)</code> , <code>event_gen.tcl(4)</code> , <code>logscan.tcl(4)</code> , <code>rules.tcl(4)</code> , <code>sm_symond.conf(4)</code>

NAME	auth_list.tcl – List of authorized Solstice SyMON users
SYNOPSIS	<code>/opt/SUNWsymon/etc/auth_list.tcl</code>
DESCRIPTION	<p>This list identifies the users authorized to use the Solstice SyMON software on a system. Users, hosts, and groups can be defined as authorized, readonly, or unauthorized.</p> <p>The data in auth_list.tcl is parsed by auth_checker.tcl(4).</p> <p>For more information, see the <i>Solstice SyMON User's Guide</i></p>
SEE ALSO	symon(1) , sm_configd(1M) , sm_confsymon(1M) , sm_control(1M) , sm_egd(1M) , sm_krd(1M) , sm_logscand(1M) , sm_symond(1M) , auth_checker.tcl(4) , event_gen.tcl(4) , logscan.tcl(4) , rules.tcl(4) , sm_symond.conf(4)

NAME	event_gen.tcl – Defines procedures and variables used by rules in the Solstice SyMON program
SYNOPSIS	<code>/opt/SUNWsymon/etc/event_gen.tcl</code>
DESCRIPTION	<p>When you run the <code>sm_confsymon -e servername</code> command, the <code>event_gen.tcl</code> file is copied to create a file called <code>event_gen.servername.tcl</code> that contains information specific to that machine within the Solstice SyMON program.</p> <p>This information includes the host names of machines that will be sent snmp trap messages.</p> <p>For more information, see the <i>Solstice SyMON User's Guide</i>.</p>
SEE ALSO	<code>symon(1)</code> , <code>sm_configd(1M)</code> , <code>sm_confsymon(1M)</code> , <code>sm_control(1M)</code> , <code>sm_egd(1M)</code> , <code>sm_krd(1M)</code> , <code>sm_logscand(1M)</code> , <code>sm_symond(1M)</code> , <code>auth_checker.tcl(4)</code> , <code>auth_list.tcl(4)</code> , <code>logscan.tcl(4)</code> , <code>rules.tcl(4)</code> , <code>sm_symond.conf(4)</code>

NAME	logscan.tcl – Defines file that the Solstice SyMON program's Log Viewer will search
SYNOPSIS	<code>/opt/SUNWsymon/etc/logscan.tcl</code>
DESCRIPTION	<p>This Tcl file contains a definition of the <code>/var/adm/messages</code> file that will be searched by the Log Viewer of the Solstice SyMON program.</p> <p>For more information, see the <i>Solstice SyMON User's Guide</i></p>
SEE ALSO	<code>symon(1)</code> , <code>sm_configd(1M)</code> , <code>sm_confsymon(1M)</code> , <code>sm_control(1M)</code> , <code>sm_egd(1M)</code> , <code>sm_krd(1M)</code> , <code>sm_logscand(1M)</code> , <code>sm_symond(1M)</code> , <code>auth_checker.tcl(4)</code> , <code>auth_list.tcl(4)</code> , <code>event_gen.tcl(4)</code> , <code>rules.tcl(4)</code> , <code>sm_symond.conf(4)</code>

NAME	rules.tcl – The master set of event rules used by Tcl software in the Solstice SyMON program
SYNOPSIS	<code>/opt/SUNWsymon/etc/rules.tcl</code>
DESCRIPTION	<p>This Tcl file contains a master list of event rules.</p> <p>When you create a new rules file, add a psource command for the new rules file to the rules.tcl file so that the new rules file can be read.</p> <p>For more information, see the <i>Solstice SyMON User's Guide</i></p>
SEE ALSO	<code>symon(1)</code> , <code>sm_configd(1M)</code> , <code>sm_confsymon(1M)</code> , <code>sm_control(1M)</code> , <code>sm_egd(1M)</code> , <code>sm_krd(1M)</code> , <code>sm_logscand(1M)</code> , <code>sm_symond(1M)</code> , <code>auth_checker.tcl(4)</code> , <code>auth_list.tcl(4)</code> , <code>event_gen.tcl(4)</code> , <code>logscan.tcl(4)</code> , <code>sm_symond.conf(4)</code>

NAME	sm_symond.conf – list of agents for sm_symond to spawn and retrieve from other hosts
DESCRIPTION	<p>The file <code>/etc/opt/SUNWsymon/sm_symond.conf</code> controls process spawning by sm_symond(1M). The processes most typically dispatched by sm_symond are symon agents.</p> <p>The sm_symond.conf file is composed of entries that either list an agent and its arguments, or specify agents to run on remote machines.</p> <p>Local agents are listed, one per line, with the normal command line arguments, and are invoked by sm_symond. Remote agent entries have the following format:</p> <p style="padding-left: 40px;"><i>host:agent-type</i></p> <p>Each entry is delimited by a newline. Comments may be inserted in the sm_symond.conf file by starting the line with a #.</p> <p>The remote agent fields are:</p> <p><i>host</i> The name of the remote host where the agent is to be run.</p> <p><i>agent-type</i> The specific type of symon agent being run. Currently, the only agent type supported on remote machines is EventGenerator.</p>
SEE ALSO	<p>symon(1), sm_configd(1M), sm_confsymon(1M), sm_control(1M), sm_egd(1M), sm_krd(1M), sm_logscand(1M), sm_symond(1M), auth_checker.tcl(4), auth_list.tcl(4), event_gen.tcl(4), logscan.tcl(4), rules.tcl(4)</p>

NAME afb – Elite3D graphics accelerator driver

DESCRIPTION **afb** is the device driver for the Sun Elite3D graphics accelerators. The **afbdaemon** process loads the afb microcode at system startup time and during the resume sequence of a suspend-resume cycle.

FILES **/dev/fbs/afb*n*** device special file
/usr/lib/afb.ucode afb microcode
/usr/sbin/afbdaemon the afb microcode loader

SEE ALSO **afbconfig(1M)**,

NAME	cvc – virtual console driver
DESCRIPTION	<p>cvc is a STREAMS-based pseudodriver that supports the network console, which is called cvc on the host side and netcon on the SSP. cvc interfaces with console(7).</p> <p>Logically, the cvc driver sits below the console(7) driver. It intercepts console output, redirecting it to the cvcredir(7) driver.</p> <p>cvc receives console input from cvcredir(7) and passes it to the process associated with /dev/console.</p>
NOTES	The cvc facility supercedes the SunOS wscons(7) facility, which should not be used in conjunction with cvc . wscons(7) is useful for systems with directly attached consoles (frame buffers and keyboards), but is not useful with the Enterprise 10000 system, which has no local keyboard or frame buffer.
SEE ALSO	cvcd(1M) , cvc(7) , cvcredir(7) in this reference manual netcon(1M) , netcon_server(1M) in <i>UNKNOWN TITLE ABBREVIATION: UE10000REFEMANIM</i> console(7) in <i>man Pages(7): Device and Network Interfaces</i>

NAME	cvcredir – virtual console redirection driver
DESCRIPTION	<p>cvcredir, the virtual console redirection driver, is a STREAMS-based pseudodriver that works in conjunction with the cvc driver, cvc(7), and the cvc daemon, cvcd(1M).</p> <p>The cvcredir device is opened at start-of-day by the cvc daemon, cvcd(1M). cvcredir receives console output from cvc(7) and passes it to cvcd(1M). It receives console input from cvcd(1M) and passes it to cvc(7).</p>
SEE ALSO	<p>cvcd(1M), cvc(7) in this reference manual</p> <p>netcon(1M), netcon_server(1M) in <i>man Pages(1M): Ultra Enterprise 10000 SSP Administration Commands</i></p> <p>console(7) in <i>man Pages(7): Device and Network Interfaces</i></p>

NAME	dr – dynamic reconfiguration driver, /dev/dr
SYNOPSIS	dr
DESCRIPTION	<p>The DR driver provides a pseudo-driver interface to the kernel Dynamic Reconfiguration (DR) Attach and DR Detach features.</p> <p>For DR Detach, the command dr_daemon(1M) executes SunOS ioctl(2) calls to:</p> <ul style="list-style-type: none"> • Detach selected devices from kernel usage • Remove detached device nodes from the kernel's device tree • Direct OBP to delete all detached nodes from its device tree <p>For DR Attach, dr_daemon(1M) executes ioctl(2) calls to:</p> <ul style="list-style-type: none"> • Direct OBP to probe the board and add nodes to its device tree • Get the nodes from OBP and add proto nodes to the kernel's device tree • Convert the proto nodes to CF1 nodes <p>The pathname of the device node is /devices/pseudo/dr@0:0.</p>
SEE ALSO	<p><i>Dynamic Reconfiguration User's Guide</i> <i>Ultra Enterprise 10000 SSP User's Guide</i> dr_daemon(1M) in this reference manual hostview(1M), hpost(1M) in <i>man Pages(1M): Ultra Enterprise 10000 SSP Administration Commands</i> dr(1M) in <i>man Pages(1M): DR Administration Commands</i> add_drv(1M), drvconfig(1M), devlinks(1M), disks(1M), ports(1M), tapes(1M) in <i>man Pages(1M): System Administration Commands</i></p>

NAME	idn – Inter-Domain Network device driver
DESCRIPTION	<p>idn is a multi-thread, loadable, clonable, STREAMS-based pseudo driver that supports the connectionless Data Link Provider Interface, dlpi(7P), over the Enterprise 10000 Gigplane-XB Interconnect. This connection is permitted only between domains within the same Enterprise 10000 server.</p> <p>The driver provides one to 32 logical network interfaces. One or more of these interfaces may be connected to one or more dynamic system domains that have been previously linked to the local domain via the domain_link(1M) command. (See domain_link(1M) in the <i>Ultra Enterprise 10000 SSP 3.1 Reference</i>.) The driver works in conjunction with the SSP to perform domain linking and unlinking, along with automated linking upon host bootup.</p> <p>The cloning character-special device /dev/idn is used to access all IDN services provided by the system.</p>
idn and DLPI	<p>The idn driver is a "style 2" Data Link Service provider. All M_PROTO and M_PCPROTO type messages are interpreted as DLPI primitives. An explicit DL_ATTACH_REQ message by the user is required for idn to associate the opened stream with a particular device (<i>ppa</i>). The <i>ppa</i> ID is interpreted as an unsigned long and indicates the corresponding device instance (unit) number. The error DL_ERROR_ACK is returned by the driver if the <i>ppa</i> field value does not correspond to a valid device instance number for the system. The device is initialized on first attach and de-initialized (stopped) on last detach.</p> <p>The values returned by the driver in the DL_INFO_ACK primitive in response to the DL_INFO_REQ from the user are as follows:</p> <ul style="list-style-type: none"> • The maximum SDU is configurable via ndd(1M) and has the range of 512 bytes to 512K bytes. The default value is 16384 bytes. • The minimum SDU is 0. • The dlsap address length is 8. • The MAC type is DL_ETHER. • The sap length value is -2, meaning the physical address component is followed immediately by a 2-byte sap component within the DLSAP address. • The service mode is DL_CLDLS. • No optional quality of service (QOS) support is included at present so the QOS fields are 0. • The provider style is DL_STYLE2. • The version is DL_VERSION_2. • The broadcast address value is Ethernet/IEEE broadcast address (0xFFFFF). Note that IDN supports broadcast by issuing messages to each target individually. IDN is inherently a point-to-point network between domains. Once in the DL_ATTACHED state, the user must send a DL_BIND_REQ to associate a particular

SAP (Service Access Pointer) with the stream. The **idn** driver interprets the **sap** field within the **DL_BIND_REQ** as an Ethernet “type” therefore valid values for the **sap** field are in the **[0-0xFFFF]** range. Only one Ethernet type can be bound to the stream at any time.

If the user selects a **sap** with a value of **0**, the receiver will be in 802.3 mode. All frames received from the media having a “type” field in the range **[0-1500]** are assumed to be 802.3 frames and are routed up all open Streams which are bound to **sap** value **0**. If more than one Stream is in “802.3 mode” then the frame will be duplicated and routed up multiple Streams as **DL_UNITDATA_IND** messages.

In transmission, the driver checks the **sap** field of the **DL_BIND_REQ** if the **sap** value is **0**, and if the destination type field is in the range **[0-1500]**. If either is true, the driver computes the length of the message, not including initial **M_PROTO** mblk (message block), of all subsequent **DL_UNITDATA_REQ** messages and transmits 802.3 frames that have this value in the MAC frame header length field.

The driver also supports raw **M_DATA** mode. When the user sends a **DLIOCRAW ioctl**, the particular Stream is put in raw mode. A complete frame along with a proper ether header is expected as part of the data.

The **idn** driver **DLSAP** address format consists of the 6 byte physical (Ethernet) address component followed immediately by the 2 byte **sap** (type) component producing an 8-byte **DLSAP** address. Applications should *not* hardcode to this particular implementation-specific **DLSAP** address format but use information returned in the **DL_INFO_ACK** primitive to compose and decompose **DLSAP** addresses. The **sap** length, full **DLSAP** length, and **sap**/physical ordering are included within the **DL_INFO_ACK**. The physical address length can be computed by subtracting the **sap** length from the full **DLSAP** address length or by issuing the **DL_PHYS_ADDR_REQ** to obtain the current physical address associated with the stream.

Once in the **DL_BOUNDED** state, the user may transmit frames on the IDN by sending **DL_UNITDATA_REQ** messages to the **idn** driver. The **idn** driver will route received IDN frames up all those open and bound streams having a **sap** which matches the Ethernet type as **DL_UNITDATA_IND** messages. Received IDN frames are duplicated and routed up multiple open streams if necessary. The **DLSAP** address contained within the **DL_UNITDATA_REQ** and **DL_UNITDATA_IND** messages consists of both the **sap** (type) and physical (Ethernet) components.

idn Primitives

In addition to the mandatory connectionless **DLPI** message set the driver additionally supports the following primitives.

The **DL_ENABMULTI_REQ** and **DL_DISABMULTI_REQ** primitives enable/disable reception of individual multicast group addresses. A set of multicast addresses may be iteratively created and modified on a per-stream basis using these primitives. These primitives are accepted by the driver in any state following **DL_ATTACHED**.

The **DL_PROMISCON_REQ** and **DL_PROMISCOFF_REQ** primitives with the **DL_PROMISC_PHYS** flag set in the **dl_level** field enables/disables reception of all (“promiscuous mode”) frames on the media including frames generated by the local

domain. When used with the **DL_PROMISC_SAP** flag set this enables/disables reception of all **sap** (Ethernet type) values. When used with the **DL_PROMISC_MULTI** flag set this enables/disables reception of all multicast group addresses. The effect of each is always on a per-stream basis and independent of the other **sap** and physical level configurations on this stream or other streams.

The **DL_PHYS_ADDR_REQ** primitive return the 6 octet Ethernet address currently associated (attached) to the stream in the **DL_PHYS_ADDR_ACK** primitive. This primitive is valid only in states following a successful **DL_ATTACH_REQ**.

The **DL_SET_PHYS_ADDR_REQ** primitive is not allowed by the **idn** driver as the driver maintains point-to-point domain address information in the address in order to direct packets to the correct destination.

NOTES The driver supports a set of tuneable parameters. The list can be retrieved via **ndd(1M)**.

FILES **/dev/idn** idn special character device.

SEE ALSO *Inter-Domain Network User's Guide*

domain_link(1M), **domain_unlink(1M)** in the *Ultra Enterprise 10000 SSP Reference Manual*

ndd(1M) in *man Pages(1M): System Administration Commands* of the *SunOS Reference Manual*.

dlpi(7P), **qe(7P)** in *man Pages(7): Device and Network Interfaces* of the *SunOS Reference Manual*.

Index

A

afb (7D), 7-81
afbconfig (1M), 1M-10
auth_checker.tcl (4), 4-756
auth_list.tcl (4), 4-76

C

cfgadm (1M), 1M-18
config_admin (3X), 3-68
cvc (7), 7-82
cvcd (1M), 1M-27
cvcredir (7), 7-83

D

devices and network interfaces, 7-81 to 7-87
dr (7), 7-84
dr_daemon (1M), 1M-28

E

event_gen.tcl (4), 4-77

F

file formats, 4-75 to 4-80

I

idn (7), 7-85

L

library functions, miscellaneous, 3-68 to 3-74
logscan.tcl (4), 4-78
luxadm (1M), 1M-29

M

maintenance commands, 1M-10 to 1M-67

R

rules.tcl (4), 4-79

S

sm_configd (1M), 1M-40
sm_confsymon (1M), 1M-41
sm_control (1M), 1M-43
sm_egd (1M), 1M-43
sm_krd (1M), 1M-46
sm_logscand (1M), 1M-47
sm_symond (1M), 1M-48
sm_symond.conf (4), 4-41
smc_copy (1), 1-1
smc_ftpd (1M), 1M-50
smc_gettacl (1M), 1M-54

smc_ls (1), 1-3
smc_rm (1), 1-4
smc_settacl (1M), 1M-55
smc_tar (1), 1-5
ssp-config (1M), 1M-57
ssp-unconfig (1M), 1M-58
sunvts (1M), 1M-59
symon (1), 1-7

U

user commands, 1-1 to 1-9

V

vtsk (1M), 1M-60
vtsprobe (1M), 1M-61
vtstty (1M), 1M-64
vtsui (1M), 1M-66
vtsui.ol (1M), 1M-67