



Sun StorEdge™ A3500/A3500FC Task Map

1

Read Release Notes

Review the release notes before beginning the installation for late breaking news and updates, such as patch information, hardware changes, and product functionality.

2

Plan Configuration

Refer to the *Sun StorEdge A3500/A3500FC Hardware Configuration Guide*.

3

Prepare Host System

For SCSI connections, install the UDWIS host adapter cards in the host system(s). For FC-AL connections, install the Sun StorEdge SBus or PCI FC-100 host adapter in the host system(s). Refer to the documentation that came with your host adapter and A3500/A3500FC system for instructions.

4

Install Hardware

Install the Sun StorEdge A3500/A3500FC system, connecting it to the host.

To:

- Install a controller module in the cabinet
- Operate a controller module already installed in the cabinet
- Upgrade an existing SCSI controller module for FC-AL host connections

Do this:

Start with Chapter 2 of the *Sun StorEdge A3500/A3500FC Controller Module Guide*.

Start with Chapter 3 of the *Sun StorEdge A3500/A3500FC Controller Module Guide*.

Refer to the *Sun StorEdge A3500FC Controller Upgrade Guide*.

Make sure you record the installation date on the battery label.

5

Install Software

Install the RAID Manager software from the CD. Refer to the *Sun StorEdge RAID Manager Installation and Support Guide* for instructions.

Troubleshooting

For hardware troubleshooting, refer to the *Sun StorEdge A3500/A3500FC Controller Module Guide*.

For software troubleshooting, refer to the *Sun StorEdge RAID Installation and Support Guide*.

System Administration

Refer to the *Sun StorEdge RAID Manager User's Guide* for system administration tasks.

Related Documentation

The following hardware guides were shipped with your system:

Sun StorEdge A3500/A3500FC Controller Module Guide, p/n 805-4980

Sun StorEdge A3500/A3500FC Hardware Configuration Guide, p/n 805-4981

Sun StorEdge A3500/A3500FC Task Map, p/n 805-4982 (this document)

The following software guides were shipped with your system:

Sun StorEdge RAID Manager 6.22 Release Notes, p/n 805-7758

Sun StorEdge RAID Manager 6.22 Installation and Support Guide, p/n 805-7756

Sun StorEdge RAID Manager 6.22 User's Guide, p/n 806-0478

Other documents you may need:

Sun StorEdge RAID Manager Controller Replacement Guide, p/n 805-7854

Sun StorEdge A3500FC Controller Upgrade Guide, p/n 806-0479

Sun StorEdge Expansion Cabinet Installation and Service Manual, p/n 805-3067

Sun Documentation on the Web

The `docs.sun.comsm` Web site enables you to access Sun technical documentation on the Web. You can browse the `docs.sun.com` archive or search for a specific book title or subject at:

`http://docs.sun.com/`

Reader Comments

Your comments and suggestions are important to us. You can email your comments to us at:

`docfeedback@sun.com`

Please include the part number of your document in the subject line of your email.

Copyright 1999 Sun Microsystems, Inc. All rights reserved. Protected by copyright and licenses restricting use, copying, distribution, and decompilation. Sun, Sun Microsystems, the Sun Logo, StorEdge, and Solaris are trademarks or registered trademarks of Sun Microsystems, Inc. in the United States and in other countries.

Copyright 1999 Sun Microsystems, Inc. Tous droits réservés. Protégé par un copyright et distribué par des licences qui en restreignent l'utilisation, la copie, la distribution, et la décompilation. Sun, Sun Microsystems, le logo Sun, StorEdge, et Solaris sont des marques déposées ou enregistrées de Sun Microsystems, Inc. aux Etats-Unit et dans d'autres pays.



Sun Microsystems Computer Company • 901 San Antonio Road • Palo Alto, CA 94303 USA •
650 960-1300 • Fax 650 969-9131

