

---

## HP Integrity Superdome Servers

# READ ME FIRST

The HP Integrity Superdome servers may require a firmware update to support Intel® Itanium® 2 Processor/Cell Add-On products shipping after June 15th, 2005.

Affected Intel® Itanium® 2 processor products for the HP Integrity Superdome are:

- AD003A – Intel® Itanium® 2 1.6-GHz 9MB CPU (2-Pack)
- AD004A – Instant Capacity Right To Access Intel® Itanium® 2 1.6-GHz 9MB CPU

### ACTION

Check the server firmware prior to installing any of these processor products. The firmware versions can be checked using the MP “sysrev” command. The HP Integrity Superdome requires “Firmware Version rel\_5.1” or later. The individual firmware revisions that make up version rel\_5.1 and the firmware upgrade instructions are in the Release Notice that is included in the firmware download bundle. If you are not able to check the firmware or if the firmware is not at version rel\_5.1 or later, contact HP support.

---

**NOTE** Once the firmware is at the supported revision level, proceed with attaching the Processor/Cell Add-On Products to the server using the Service Guide. The Service Guide is available at <http://docs.hp.com>.

---