

VERITAS NetBackup™ 3.4

Media Manager Device Configuration Guide

UNIX

June, 2000
100-001517


VERITAS

Disclaimer

The information contained in this publication is subject to change without notice. VERITAS Software Corporation makes no warranty of any kind with regard to this manual, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. VERITAS Software Corporation shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this manual.

Copyright

Copyright © 1995-2000 VERITAS Software Corporation. All rights reserved. VERITAS is a registered trademark of VERITAS Software Corporation in the US and other countries. The VERITAS logo, VERITAS NetBackup, and VERITAS NetBackup BusinessServer are trademarks of VERITAS Software Corporation. All other trademarks or registered trademarks are the property of their respective owners.

Portions of this software are derived from the RSA Data Security, Inc. MD5 Message-Digest Algorithm. Copyright 1991-92, RSA Data Security, Inc. Created 1991. All rights reserved.

Printed in the USA, June, 2000.

VERITAS Software Corporation
1600 Plymouth St.
Mountain View, CA 94043
Phone 650-335-8000
Fax 650-335-8050
www.veritas.com



Contents

About This Guide	xi
Introduction	xi
Audience	xi
Scope	xi
Organization	xi
Using This Guide	xii
Related Documents	xii
Conventions	xiv
Type Style	xiv
Notes and Cautions	xiv
Key Combinations	xiv
Command Usage	xiv
Getting Help	xv
Chapter 1. How To Use This Guide	17
Before You Start Configuring Devices	17
Read the Release Notes	17
Considerations When Using This Guide	17
A Configuration Caution	18
Chapter 2. Auspex	19
Before You Start	19
Configuring Robotic Controls	20
Configuring SCSI Robotic Controls	20



The SCSI Generic driver	20
Loading the SCSI Generic driver	20
Examples of SCSI Robotic Control Device Files	22
Changing SCSI ID Mapping in Kernel Configuration	24
Finding the SunOS Kernel Configuration File	24
Checking the SCSI Device Unit Assignment Table	25
Changing the SCSI Device Unit Assignment Table	25
Logical Unit Numbers	25
Configuring Tape Drives	27
Creating No Rewind Device Files	27
Examples of No Rewind Device Files	28
Adding Nonstandard Tape Drives	28
Note on Case and Spaces in <code>st_conf.c</code> Entries	28
Adding Exabyte Compression Drives	29
Adding HP 4-mm Drives and HP C1560B DAT Autoloaders	30
Adding STK Drives	32
Adding Quantum DLT Drives or Stackers	33
Configuring HP Optical Disk Drives	35
Creating Device Files	35
Setting the Optical Drive Type in Nonvolatile Memory	36
Rebuilding a SunOS Kernel	38
Command Summary	40
Chapter 3. Sun4/SPARC Running Solaris 2.6/7/8	43
Before You Start	43
If You Are Using NetBackup BusinessServer	44
Topics Applicable to NetBackup BusinessServer	44
Topics Not Applicable to NetBackup BusinessServer	44
Preventing Possible System Problems	44
Installing SCSI Pass-Through Drivers	45



Configuring the SG Driver	46
Configuring Robotic Controls	49
Configuring SCSI Robotic Controls	49
Examples of SCSI Robotic Control Device Files	50
Configuring Tape Drives	53
Using Berkeley-Style Close	53
Fast-Tape Positioning (locate-block)	53
Enabling locate-block	53
Disabling locate-block	53
No Rewind Device Files	53
Examples of No Rewind Device Files	54
Configuring Nonstandard Tape Drives	55
Note on Case and Spaces in <code>st.conf</code> Entries	55
Additions to the <code>st.conf</code> File	56
Adding Logical Unit Number Entries	57
Multiple Logical Unit Numbers per SCSI Target	58
Adding HP 4-mm Drives and HP DAT Autoloaders	62
Adding Sony AIT or AIT-2 Drives	63
Configuring HP Optical Disk Drives	66
Creating Device Files	66
Examples of Optical Disk Device Files	67
Setting the HP Optical Drive Type in Nonvolatile Memory	67
Command Summary	69
Chapter 4. IBM RS6000 Running AIX 4.2.1/4.3/4.3.1/4.3.2/4.3.3	71
Before You Start	71
RS6000 AIX Adapter Number Conventions	72
Installing the SCSI Pass-Through Driver	73
Configuring Robotic Controls	74
Configuring SCSI Robotic Controls	74



Examples of SCSI Robotic Control Device Files	76
Configuring IBM 3590 Stacker Robotic Controls	78
Configuring Tape Drives	80
Configuring Non-QIC Tape Drives	80
Using Extended-File Marks for Drives	80
Fast-Tape Positioning (locate-block)	80
Creating No Rewind Device Files	81
No Rewind Device File Example	82
Using Multiple Tape Densities	83
Adding HP 4-mm Drives and HP C1560B DAT Autoloaders	84
Adding Sony AIT Drives	84
No Rewind Device Files	84
Dip Switch Settings	85
Configuring Optical Disk Drives	87
Creating Device Files	87
Examples of Optical Disk Device Files	88
Setting an HP Optical Drive Type in Nonvolatile Memory	89
Command Summary	93
Chapter 5. HP9000-700 Running HP-UX 10.20/11.0	95
Before You Start	95
If You Are Using NetBackup BusinessServer	95
Configuring Robotic Controls	96
Configuring SCSI Robotic Controls	96
Examples of SCSI Robotic Control Device Files	97
Configuring Tape Drives	98
Using Berkeley Style Close	98
No Rewind Device Files	98
Examples of No Rewind Device Files	99
Switch Settings for HP C1533A 4-mm DAT Drives	100



Configuring Optical Disk Drives	102
Examples of Optical Disk Device Files	102
Command Summary	104
Chapter 6. HP9000-800 Running HP-UX 10.20/11.0	105
Before You Start	105
If You Are Using NetBackup BusinessServer	105
Configuring Robotic Controls	106
Configuring SCSI Robotic Controls	106
Determining Which Pass-Through Driver to Configure	106
Configuring Device Files for <code>spt</code> Pass-Through Driver	107
Configure Device Files for <code>sctl</code> Pass-Through Driver	109
Configuring Tape Drives	113
Using Berkeley Style Close	113
Fast-Tape Positioning (<code>locate-block</code>)	113
No Rewind Device Files	114
No Rewind Device File Example	114
Switch Settings for HP C1533A 4-mm DAT Drives	115
Configuring Optical Disk Drives	116
Example of an Optical Disk Device File	116
Command Summary	117
Chapter 7. IRIX 6.5/6.5.1/6.5.2/6.5.3/6.5.4/6.5.5	119
Before You Start	119
Using SCIP Controllers	120
Using the <code>mediad</code> Command	121
Configuring Robotic Controls	122
Configuring SCSI Robotic Controls	122
Examples of SCSI Robot Control Device Files	122
Configuring Tape Drives	124
Fast-Tape Positioning (<code>locate-block</code>)	124



No Rewind Device Files	124
Examples of No Rewind Device Files	124
Adding HP 4-mm Drives and HP C1560B DAT Autoloaders	125
Checking Switch Settings	125
Changing the /var/sysgen/master.d/scsi File	126
Adding Sony DTF Drives	128
Adding Quantum DLT Drives or Stackers	129
Configuring Optical Disk Drives	131
Examples of Optical Disk Device Files	131
Command Summary	132
Chapter 8. Compaq Alpha Running TRU64 UNIX 4.0F/5.0	133
Configuring Robotic Controls	134
Configuring SCSI Robotic Controls	134
Creating SCSI Robotic Control Device Files	134
Examples of SCSI Robotic Control Device Files	135
Configuring Tape Drives	136
Fast-Tape Positioning (locate-block)	136
Adding Standard Tape Drives	136
Creating No Rewind Device Files	136
Configuring Fibre Channel Tape Drives	137
Examples of No Rewind Device Files	138
Adding Nonstandard Tape Drives	139
Switch Settings for HP C1533A 4mm DAT Drives	139
Command Summary	141
Chapter 9. NCR Running SVR4MP-RAS 3.02	143
NCR Device Files	144
Configuring Robotic Controls	145
Configuring Tape Drives	145



Chapter 10. Sequent Running DYNIX/ptx 4.4.2/4.4.4/4.5	147
Configuring Robotic Controls	148
Configuring SCSI Robotic Controls	148
Configuring Tape Drives	150
Kernel Configuration	152
Turning Off Messages	152
Exabyte Drive Type	152
DLT Drive Type	153
Tape Drive Support	153
DLT Drive Type	153
IBM Magstar (3590) Drive Type	153
Command Summary	154
Chapter 11. Pyramid Running Reliant UNIX 5.43 C20/5.43 C30/5.44/5.45	155
Configuring Robotic Controls	156
Configuring Tape Drives	156
Using Berkeley-style Close	156
Checking For Berkeley-style Close	156
Setting Berkeley-style Close	157
Glossary	159
Index	183





About This Guide

Introduction

This guide contains configuration information that VERITAS has found useful when adding storage peripherals to device hosts controlled by Media Manager.

Media Manager is the component of NetBackup DataCenter, NetBackup BusinessServer, and Storage Migrator that manages devices and media.

This guide is intended for use with the NetBackup DataCenter and the NetBackup BusinessServer products. In this guide, the term *NetBackup* refers to NetBackup DataCenter and NetBackup BusinessServer.

Storage Migrator is not supported with NetBackup BusinessServer.

Audience

The intended audience for this guide is the system administrator responsible for adding the storage peripherals, and assumes a thorough knowledge of UNIX system and device configuration.

Scope

This guide is intended to be used with the NetBackup DataCenter and NetBackup BusinessServer products.

The information in this guide supplements the manuals provided by hardware and operating system vendors.

Organization

This guide contains a chapter for each of the UNIX server platforms that are supported on NetBackup DataCenter. Chapter 3 (Sun4), Chapter 5 (HP9000-700), and Chapter 6 (HP9000-800) are also applicable for NetBackup BusinessServer.

- ◆ Chapter 1 provides instructions for using this guide.
- ◆ Chapter 2 provides configuration information for Auspex device hosts.



- ◆ Chapter 3 provides configuration information for Sun4/SPARC device hosts.
- ◆ Chapter 4 provides configuration information for IBM RS6000 device hosts.
- ◆ Chapter 5 provides configuration information for HP9000-700 device hosts.
- ◆ Chapter 6 provides configuration information for HP9000-800 device hosts.
- ◆ Chapter 7 provides configuration information for SGI device hosts.
- ◆ Chapter 8 provides configuration information for Compaq Alpha device hosts.
- ◆ Chapter 9 provides configuration information for NCR device hosts.
- ◆ Chapter 10 provides configuration information for Sequent device hosts.
- ◆ Chapter 11 provides configuration information for Pyramid RM1000 device hosts.

In addition to these chapters, there is a glossary of terms that you may encounter, and an index.

Using This Guide

Each UNIX platform that is supported by NetBackup DataCenter and NetBackup BusinessServer as a media or client server is described in a separate chapter in this guide. You should have to use only the chapters for the platforms on which you are configuring devices for Media Manager.

Portions of this guide include topics and examples that may *not* be applicable to your system hardware configuration.

It is important to refer to the NetBackup release notes to determine which Media Manager robot types, robots, and drives are supported for your NetBackup product, before using this guide.

Related Documents

NetBackup documents that may be useful are listed below. For a complete list of related documents, see the NetBackup release notes. Depending on your configuration, other documents may also be required.

- ◆ *NetBackup BusinessServer Getting Started Guide - UNIX*
Gives you the information you need to quickly get NetBackup BusinessServer server software installed and running. This is the first document that you should read after opening the NetBackup BusinessServer package.
- ◆ *NetBackup BusinessServer Media Manager System Administrator's Guide - UNIX*



Explains how to configure and manage the storage devices and media on UNIX servers running NetBackup BusinessServer. Media Manager is part of the NetBackup BusinessServer product.

◆ *NetBackup DataCenter Installation Guide - UNIX*

Provides information on installing NetBackup DataCenter software on a UNIX server.

◆ *NetBackup DataCenter Media Manager System Administrator's Guide - UNIX*

Explains how to configure and manage the storage devices and media on UNIX servers running NetBackup DataCenter. Media Manager is part of the NetBackup DataCenter product.

◆ *NetBackup Release Notes*

Contains information, such as, list of new features, platforms and operating systems that are supported, and operating notes that may not be in the manuals or the online help.

◆ *NetBackup Troubleshooting Guide - UNIX*

Provides troubleshooting information for the NetBackup products.

Storage Migrator is not supported with the NetBackup BusinessServer product.

◆ *Storage Migrator Release Notes - UNIX*

Provides information such as the platforms and operating systems that are supported and operating notes that may not be in the Storage Migrator manuals.

◆ *Storage Migrator System Administrator's Guide - UNIX*

Explains how to configure and manage Storage Migrator on a UNIX system.



Conventions

The following explains typographical and other conventions used in this guide.

Type Style

Table 1. Typographic Conventions

Typeface	Usage
Bold fixed width	Input. For example, type <code>cd</code> to change directories.
Fixed width	Paths, commands, filenames, or output. For example: The default installation directory is <code>/opt/VRTSxx</code> .
<i>Italics</i>	Book titles, new terms, or used for emphasis. For example: <i>Do not</i> ignore cautions.
<i>Sans serif (italics)</i>	Placeholder text or variables. For example: Replace <i>filename</i> with the name of your file.
Sans serif (no italics)	Graphical user interface (GUI) objects, such as fields, menu choices, etc. For example: Enter your password in the Password field.

Notes and Cautions

Note This is a Note and is used to call attention to information that makes it easier to use the product or helps you to avoid problems.

Caution This is a Caution and is used to warn you about situations that can cause data loss.

Key Combinations

Some keyboard command sequences use two or more keys at the same time. For example, you may have to hold down the Ctrl key before you press another key. When this type of command is referenced, the keys are connected by plus signs. For example:

Press `Ctrl+t`

Command Usage

The following conventions are frequently used in the synopsis of command usage.

brackets []

The enclosed command line component is optional.

Vertical bar or pipe (|)



Separates optional arguments from which the user can choose. For example, when a command has the following format:

```
command arg1 | arg2
```

the user can use either the *arg1* or *arg2* variable.

Getting Help

For updated information about this product, including system requirements, supported platforms, supported peripherals, and a list of current patches available from Technical Support, visit our web site:

```
http://www.veritas.com/
```

For product assistance, contact VERITAS Customer Support.

US and Canadian Customers: 1-800-342-0652

International Customers: +1 (650) 335-8555

VERITAS Customer Support can also be reached through electronic mail at:

```
support@veritas.com
```





Before You Start Configuring Devices

Observe the following important points before using this guide to perform device configurations.

Read the Release Notes

Refer to the NetBackup Release Notes to determine

- ◆ The UNIX platforms that are supported on NetBackup BusinessServer. This dictates the chapters of this guide that are applicable for the NetBackup BusinessServer product and which chapters are only applicable for the NetBackup DataCenter product.

Each UNIX platform that is supported by NetBackup as a media or client server is described in a separate chapter in this guide. You should have to use only the chapters for the platforms on which you are configuring devices for Media Manager.

- ◆ Which Media Manager robot types, robots, and drives are supported on
 - ◆ Your UNIX platform.
 - ◆ Your NetBackup product (DataCenter or BusinessServer).

Portions of this guide include topics and examples that may *not* be applicable to your system hardware configuration.

Considerations When Using This Guide

- ◆ This guide is intended for use with the NetBackup DataCenter and NetBackup BusinessServer products. In this guide, the term *NetBackup* refers to NetBackup DataCenter and NetBackup BusinessServer.
- ◆ It is important to read the Before You Start section in each chapter of this guide that you use. The Before You Start section provides any important platform-specific instructions. This section may also contain specific instructions pertaining to NetBackup BusinessServer.



- ◆ To help avoid configuration errors, you can copy configuration examples from the text-only version of this manual, that is in the following file:
`/usr/opensv/volmgr/MediaMgr_DeviceConfig_Guide.txt`. This file is installed along with the NetBackup Media Manager software.

A Configuration Caution

- ◆ VERITAS does not recommend or support the use of single-ended to differential SCSI converters on Media Manager controlled devices. You may encounter problems if you use these converters.

This chapter provides information for configuring devices on an Auspex server running SunOS 4.1.4. Configure drives and robots using one of the available Media Manager administrative interfaces.

This main topics in this chapter are as follows:

- ◆ Before You Start
- ◆ Configuring Robotic Controls
- ◆ Changing SCSI ID Mapping in Kernel Configuration
- ◆ Configuring Tape Drives
- ◆ Configuring HP Optical Disk Drives
- ◆ Rebuilding a SunOS Kernel
- ◆ Command Summary

Before You Start

Typical device path names you enter when configuring drives and robots are described in this chapter. Instructions for changing and rebuilding the kernel are also given. Depending on the type and number of devices you are adding, you may have to enter information into kernel source files and then reconfigure the kernel.



Configuring Robotic Controls

Robots can be controlled through a SCSI or a network connection. Configuration for network controlled robotic libraries is discussed in the appendices of the Media Manager system administrator's guide. SCSI control is covered in the following section.

Configuring SCSI Robotic Controls

Read this topic if you plan to use a robotic storage device that is controlled through a SCSI robotic connection.

Supported SCSI robots include the following. See the NetBackup release notes for a list of the vendor models associated with these robot types.

- ◆ ODL - Optical Disk Library
- ◆ TL4 - Tape Library 4MM
- ◆ TL8 - Tape Library 8MM
- ◆ TLD - Tape Library DLT
- ◆ TS8 - Tape Stacker 8MM
- ◆ TSD - Tape Stacker DLT

SCSI robotics are supported on Auspex systems with `sun4c` or `sun4m` kernel architecture. SCSI robotics are not supported on systems with `sun4` kernel architecture. To determine the kernel architecture, use the `/usr/bin/arch -k` command.

The SCSA Generic driver

The SCSA Generic (SG) driver is a loadable driver used in combination with Media Manager robotic software to control SCSI robotic peripherals. When installing SCSI-controlled robotic software on a server running SunOS, you need to install this driver to use the peripheral's robotic control.

If the only robotics you have are on an Auspex Storage Processor (SP), you do not need to load the SG driver. The passthru driver for robotics on a SP is built into the system.

Since the SG driver is loadable, the kernel does not have to be reconfigured and the system does not have to be rebooted to install this driver. However, the driver must be installed and reloaded each time the system is booted and VERITAS recommends that you automate this procedure (for example, by putting it in `/etc/rc.local`).

Loading the SCSA Generic driver

The following instructions explain how to load the SG driver. You must perform these steps as the root user.



1. Determine what loadable kernel modules are currently loaded by executing the `modstat` command:

```
/usr/etc/modstat
Id Type Loadaddr Size B-major C-major Sysnum Mod Name
1 Drv ff08f000 5000 59. SCSCA Generic Driver
<no output is produced if no loadable drivers are present>
```

- ◆ If an SG driver is already installed (as in the above example), you must unload it before trying to install the new SG driver. Refer to step 2.
 - ◆ If the `modstat` output shows any other loadable drivers, ensure that they are not used for communicating with the same SCSI robotic devices that Media Manager will access through the SG driver. If there are any such drivers, remove them as explained in step 2. A case where a conflicting driver could exist is where it is from another backup product.
 - ◆ If there is no SG or other conflicting driver installed, proceed to step 3.
2. Unload an existing SG or other loadable driver using the `modunload` command.

The following is an example of how to unload the SG driver. The `-id` value that you use with `modunload` is the Id number of the driver as shown by `modstat`.

```
/usr/etc/modstat
Id Type Loadaddr Size B-major C-major Sysnum Mod Name
1 Drv ff08f000 5000 59. SCSCA Generic Driver
/usr/etc/modunload -id 1
/usr/etc/modstat
<no output is produced if no loadable drivers are present>
```

3. Run the SG driver installation script provided with Media Manager by entering the following:

```
/usr/opensv/volmgr/bin/driver/sg.install
```

This script loads the appropriate SG driver based on the system's kernel architecture and creates the `/dev/sg` device files.

4. Verify that the driver was loaded, using the `modstat` command.

```
/usr/etc/modstat
```

The output should be similar to the following:

```
Id Type Loadaddr Size B-major C-major Sysnum Mod Name
1 Drv ff08f000 5000 59. SCSCA Generic Driver
```

5. The driver must be installed each time the system is booted. To install the SG driver at boot time on systems running SunOS, the following code can be placed in the `/etc/rc.local` start up script.



```
# Install the SG driver
if [ -f /usr/opensv/volmgr/bin/driver/sg.install ]
then
    (cd /usr/opensv/volmgr/bin/driver; ./sg.install)
else
    echo "sg driver not installed." > /dev/console
fi
```

Note To display SCSI inquiry strings for devices available through the SG driver, execute `/usr/opensv/volmgr/bin/sgscan`.
On Auspex, to display SCSI inquiry strings for `/dev/asc*` devices, execute `/usr/opensv/volmgr/bin/spscan`.

Examples of SCSI Robotic Control Device Files

Example 1:

On SunOS systems, SCSI controlled robotics use device files located in the `/dev/sg` directory. The format of the device file paths follows:

`/dev/sg/c $Controller$ t $Target$ d $Luns$ 0`

Where:

Controller is the SCSI bus (adapter) number

Target is the SCSI ID

Lun is the logical unit number and is always 0 (except for some peripherals, such as DLT2700, DLT4700, and HP C1560B).

If the robotics control is not for a DLT2700, DLT4700, HP C1560B, or other LUN 1 peripheral and is on SCSI bus (adapter) 0 at SCSI ID 5, the device file you specify is:

`/dev/sg/c0t5d0s0`

If the robotics control is not for a DLT2700, DLT4700, HP C1560B, or other LUN 1 peripheral and is on SCSI bus (adapter) 1 at SCSI ID 3, the device file you specify is:

`/dev/sg/c1t3d0s0`

If a DLT2700, DLT4700, HP C1560B, or other LUN 1 peripheral robotics control is on SCSI bus (adapter) 0 at SCSI ID 4 with logical unit number 1, the device file you specify is:

`/dev/sg/c0t4d1s0`

Example 2:

If the robotic device is connected to an Auspex SP, the format of the device file path follows:

```
/dev/ascXX
```

Where *xx* is the slot number within the SP. Slot numbers can be determined by running the `/usr/opensv/volmgr/bin/spscan` script.

For example.

An Odetics ATL 4/52 with the robotics connected to slot 38 would have a the following robotic path:

```
/dev/asc38
```

Example 3:

If a Quantum DLT4700 is being used on an Auspex SP, a special case file must be created indicating to the TSD software that LUN 1 must be used when communicating with the robotics. If the slot number of the DLT4700 is 40, the device file for robotics is `/dev/asc40`. The following command must also be used:

```
touch /dev/asc40.1
```



Changing SCSI ID Mapping in Kernel Configuration

Read this topic if you have not yet verified that the kernel configuration file for SunOS on this system supports the number of tape and optical drives you have connected and the SCSI IDs for those devices.

When installing Media Manager and robotic software, you may need to reconfigure the SunOS kernel to support the number of tape or optical drives being added or to support a different SCSI ID. The data path to SCSI tape drives goes through the `st(4s)` SCSI tape driver, while the optical drives are used through the `sd(4s)` SCSI disk driver.

Finding the SunOS Kernel Configuration File

The kernel configuration file contains a table of SCSI device unit assignments. This file is located in:

```
/usr/sys/arch/conf/file
```

Where:

arch is the kernel architecture for the system and can be determined using the `arch -k` command.

file is the configuration file for the running system.

The configuration file for the running SunOS can normally be determined by examining the `/etc/motd` file. For example, the following `/etc/motd` file shows that the kernel name is `GENERIC`.

```
cat /etc/motd
Auspex 1.9.2M1z4/SunOS 4.1.4 (GENERIC) #1:Mon Dec 13 09:58:55 CST 1999
```

An alternate method for determining the kernel name is as follows:

```
strings /vmunix | grep SunOS
Auspex 1.9.2M1z4/SunOS 4.1.4 (GENERIC) #1:Mon Dec 13 09:58:55 CST 1999
```

Using the above example, the kernel configuration file could be:

```
/usr/sys/sun4m/conf/GENERIC
```


Checking the SCSI Device Unit Assignment Table

Within the SunOS kernel configuration file is a table of SCSI device unit assignments that maps the SCSI bus, target, and logical unit number of a device to a tape or disk number for the corresponding device driver (st or sd). This table is located near the end of the kernel configuration file.

The following is a portion of a sample SCSI device unit assignment table:

```
scsibus0 at esp # declare first SCSI bus
scsibus1 at esp # declare second SCSI bus
disk sd3 at scsibus0 target 0 lun 0 # first SCSI disk
disk sd1 at scsibus0 target 1 lun 0 # second SCSI disk
tape st0 at scsibus0 target 4 lun 0 # first SCSI tape
tape st1 at scsibus0 target 5 lun 0 # second SCSI tape
tape st2 at scsibus1 target 4 lun 0 # third SCSI tape
tape st3 at scsibus1 target 5 lun 0 # fourth SCSI tape
```

Changing the SCSI Device Unit Assignment Table

In the above example, the first SCSI tape device, st0, is declared to be attached to the first SCSI bus, at SCSI ID (target) 4, and logical unit number (lun) 0. The disk device sd3 is declared to be attached to the first SCSI bus, at SCSI ID (target) 0, and logical unit number (lun) 0.

You may have to change this table, depending on the SCSI bus and SCSI ID of the tape or optical drive. If you change this table, the kernel has to be reconfigured and rebuilt to recognize the changes. See “Rebuilding a SunOS Kernel” on page 38 for an example of how to reconfigure and rebuild a SunOS kernel. Before rebuilding the kernel, you should read the other topics to see if additional changes are necessary because of the type of the tape or optical drive.

Logical Unit Numbers

Tape devices (such as HP C1560B DAT Autoloaders or STK half-inch cartridge drives) that use the logical unit number characteristic require special attention. When devices use a logical unit number, multiple drives all share the same SCSI ID (target) and are differentiated only by their logical unit number at that specific SCSI target.

The following is a portion of a sample SCSI device unit assignment table that employs logical unit numbers:

```
scsibus0 at esp # declare first SCSI bus
scsibus1 at esp # declare second SCSI bus
disk sd3 at scsibus0 target 0 lun 0 # first SCSI disk
disk sd1 at scsibus0 target 1 lun 0 # second SCSI disk
tape st1 at scsibus1 target 3 lun 0 # first SCSI tape
```



```
tape st2 at scsibus1 target 3 lun 1 # second SCSI tape
tape st3 at scsibus1 target 3 lun 2 # third SCSI tape
tape st4 at scsibus1 target 3 lun 3 # fourth SCSI tape
```

In this example:

- ◆ The first SCSI tape device, `st1`, is declared to be attached to the SCSI bus 1, at SCSI ID (target) 3, and logical unit number 0.
- ◆ The second (`st2`), third (`st3`), and fourth (`st4`) tape drives are also attached to SCSI bus 1 at SCSI ID (target) 3.

The distinguishing characteristic of these four drives is their logical unit number.

Note The HP C1560B DAT Autoloader always uses a logical unit number of 1.

Configuring Tape Drives

When adding tape drives to a Media Manager configuration, you must specify a no rewind on close device path. In a typical SunOS configuration, most of the tape device files already exist in the `/dev` directory. These device files have the following format:

```
/dev/nrstST_Number+Density
```

Where:

ST_Number is the tape device number configured to the desired SCSI bus and SCSI ID in the kernel configuration file.

Density is 0, 8, or 16, depending on the drive's density capabilities. *Density* is added to *ST_Number*.

For Exabyte drives, a density of

- ◆ 0 is added to the device number for 8200 drives
- ◆ 8 is added to the device number for 8500 drives
- ◆ 16 is added to the device number for 8500C and 8505 drives

Other drive types normally use 0 for the density, unless multiple densities are specified in the `st_conf.c` file. (Refer to the `st(4S)` man page.)

Creating No Rewind Device Files

If the required device files do not exist, you can use the `MAKEDEV` command to create device files for a particular SCSI tape number as follows:

```
cd /dev
MAKEDEV stST_Number
```

Where *ST_Number* is the tape device number assigned to the desired SCSI bus and SCSI ID in the SCSI device unit assignment table (see "Checking the SCSI Device Unit Assignment Table" on page 25).

For example, if the desired tape drive is on SCSI bus 1 at SCSI ID 3 and the SCSI device unit assignment table contains the following line, the tape device number is 7.

```
tape st7 at scsibus1 target 3 lun 0 # tape drive
```

The following commands create the device file:

```
cd /dev
MAKEDEV st7
```

If the tape drive is connected to an Auspex SP, the no rewind on close device file for the drive is as follows (*slot_number* is the slot number):

```
/dev/nrastslot_number
```



Examples of No Rewind Device Files

Example 1:

If the desired Exabyte tape drive is on SCSI bus 1 at SCSI ID 3 and the SCSI device unit assignment table contains the following line:

```
tape st7 at scsibus1 target 3 lun 0      # tape drive
```

then the *ST_Number* is 7 and the path would be one of following (depending on the type of Exabyte drive):

```
/dev/nrst7   (Exabyte 8200)  
/dev/nrst15  (Exabyte 8500)  
/dev/nrst23  (Exabyte 8500C or 8505)
```

Example 2:

If the desired 4-mm (DAT) tape drive is on SCSI bus 0 at SCSI ID 3, and the kernel configuration file contains the following line:

```
tape st1 at scsibus0 target 5 lun 0 # tape drive
```

then the *ST_Number* is 1, and the device path is

```
/dev/nrst1
```

Example 3:

On an Auspex SP, a DLT tape drive is connected to slot 39, as determined using `/usr/opencv/volmgr/bin/spscan`. For example, if this command returns the following output:

```
/dev/asc39: removable dev type 1h Quantum DLT4000 CC1E
```

then the device path is as follows:

```
/dev/nrast39
```

Adding Nonstandard Tape Drives

Adding any of the drives mentioned in this section may require you to modify and rebuild the SunOS kernel. The following topics explain how to determine if kernel changes are necessary and how to make those changes.

Note on Case and Spaces in `st_conf.c` Entries

Upper and lower case are significant. For example, using QUANTUM instead of Quantum would not work for DLT4000 drives.



Spaces are significant within quoted strings in this file. For example, the first part of the entry for an HP C1533A drive is as follows (string length of 14, including spaces):

```
14, "HP      C1533A"
```

If you omit some of the spaces, as in the following (string length of nine, including spaces), the drive would not be recognized correctly:

```
14 "HP C1533A"
```

The best way to ensure that your entries are accurate is to copy them from the on-line version of this manual whenever possible.

Adding Exabyte Compression Drives

Read this topic if you plan to use one or more standalone or robotic Exabyte compression drives (8500C, 8505, 8505XL, 8900). This topic is also important if you want to take advantage of faster file-skip performance on non-compression Exabyte tape drives (see the text on ST_KNOWS_EOD in step 1 below).

You may have to modify and rebuild the SunOS kernel for the system to recognize the Exabyte compression drives. The following procedure explains the steps you should perform.

1. Check if the following code exists in the struct `st_drivetype` `st_drivetypes[]` array in the `/sys/scsi/targets/st_conf.c` file.

```
/* Exabyte 8mm half-height compression cartridge 8505 or 8505XL */
{
    "Exabyte EXB-8505 8mm Helical Scan", 16, "EXABYTE EXB-8505",
    ST_TYPE_EXB8505, 1024,
    (ST_VARIABLE | ST_BSF | ST_BSR | ST_LONG_ERASE |
    ST_KNOWS_EOD ),
    5000, 5000,
    { 0x14, 0x15, 0x00, 0x8C },
    { 0, 0, 0, 0 }
},
/* Exabyte 8mm compression cartridge */
{
    "Exabyte EXB-8500C 8mm Helical Scan", 16, "EXABYTE EXB8500C",
    ST_TYPE_EXB8500C, 1024,
    (ST_VARIABLE | ST_BSF | ST_BSR | ST_LONG_ERASE |
    ST_KNOWS_EOD ),
    5000, 5000,
    { 0x14, 0x15, 0x00, 0x8C },
    { 0, 0, 0, 0 }
},
/* Exabyte 8mm compression cartridge */
{
```



```

"Exabyte EXB-8900 Mammoth", 16, "EXABYTE EXB-8900",
ST_TYPE_EXB8505, 1024,
(ST_VARIABLE | ST_BSF | ST_BSR | ST_LONG_ERASE |
ST_KNOWS_EOD ),
5000, 5000,
{ 0x27, 0x27, 0x27, 0x00 },
{ 0, 0, 0, 0 }
},

```

Drives may have different vendor/product strings than the strings shown here. In the example above for an Exabyte 8505, "EXABYTE EXB-8505" is the vendor/product string. The 16 preceding this string is the string length and must compare.

To view the vendor/product strings for your drives, you can use the `dmesg(8)` command shortly after boot. The vendor and product strings for a drive are also logged with the `syslogd(8)` utility when the system is booted. This utility typically logs to `/var/adm/messages`.

Caution Always save a copy of a kernel file before changing it.

If this code is not in the `/sys/scsi/targets/st_conf.c` file, add it. The best way to do this is to copy it from the `MediaMgr_DeviceConfig_Guide.txt` file.

For better file-skip performance on Exabyte drives, you may also want to add the `ST_KNOWS_EOD` attribute (as specified in the example code above) to the `st_conf.c` file for all Exabyte drive types. The `st_conf.c` file included in the standard SunOS does not contain this attribute for any Exabyte drive types.

2. Check for the following lines in `/sys/scsi/targets/stdef.h`:

```

define ST_TYPE_EXB8505 0x31 /*Exabyte 8505,8905XL,or 8900*/
define ST_TYPE_EXB8500C 0x32 /*Exabyte 8500C */

```

If these lines are not in `stdef.h`, add them.

3. If you changed the `st_conf.c` or `stdef.h` files, you will have to rebuild the kernel and then reboot the system for any of these changes to become effective. Do this after completing all other necessary changes to the kernel. See "Rebuilding a SunOS Kernel" on page 38 for instructions.

Adding HP 4-mm Drives and HP C1560B DAT Autoloaders

Read this topic if you plan to use standalone or robotic Hewlett-Packard (HP) 4-mm DAT tape drives or HP C1560B DAT Autoloaders. It explains drive switch settings and SunOS kernel changes you may have to make in order for the system to recognize these drives.

First, ensure that the hardware switch settings on the drives are as follows. Other switch combinations may work, but these are the settings that were functional during testing with an HP 35480A drive and an HP C1560B Autoloader.

On=1, Off=0

Switch	Setting
1	1
2	1
3	1
4	1
5	1
6	1
7	0
8	0

You may also have to make changes to the SunOS kernel and then rebuild it. The following explains how to determine if changes are necessary and how to make them.

Caution Always save a copy of a kernel file before changing it.

1. Check if the following code is in the struct `st_drivetype st_drivetypes[]` array in the `/sys/scsi/targets/st_conf.c` file.

```
/* HP 4mm Helical Scan Tape */
{
    "HP 4mm DAT", 13, "HP      HP354", ST_TYPE_HP1, 10240,
    (ST_VARIABLE | ST_BSF | ST_BSR | ST_LONG_ERASE |
    ST_KNOWS_EOD),
    6000, 6000,
    { 0x00, 0x00, 0x00, 0x00},
    { 0, 0, 0, 0 }
},

/* HP C1560B DAT Autoloader */
{
    "HP DAT Autoloader", 13, "HP      C1533", ST_TYPE_HP1, 10240,
    (ST_VARIABLE | ST_BSF | ST_BSR | ST_LONG_ERASE |
    ST_KNOWS_EOD),
    6000, 6000,
    { 0x00, 0x00, 0x00, 0x00},
```



```
    { 0, 0, 0, 0 }  
},
```

Drives may have different vendor/product strings than the strings shown here. In the example above for an HP 4-mm, "HP HP354" is the vendor/product string. The 13 preceding this string is the string length and must compare.

To view the vendor/product strings for your drives, you can use the `dmesg(8)` command shortly after boot. The vendor and product strings for a drive are also logged with the `syslogd(8)` utility when the system is booted. This utility typically logs to `/var/adm/messages`.

If this code is not in the `st_conf.c` file, add it. The best way to make this addition is to copy it from `MediaMgr_DeviceConfig_Guide.txt`.

2. Check for the following line in `/sys/scsi/targets/stddef.h`. If this line is not in the file add it.

```
define ST_TYPE_HP1 0x33 /* HP DAT */
```

3. After completing all other necessary changes to the kernel, rebuild it and reboot the system as explained in "Rebuilding a SunOS Kernel" on page 38. This is necessary for any of these changes to become effective.

Adding STK Drives

Read this topic if you plan to use standalone or robotic StorageTek (STK) half-inch cartridge tape drives. It explains SunOS kernel changes you may have to make in order for the system to recognize these drives.

If the drives are contained in an STK silo, you may need to use multiple logical unit numbers (lun) for a given SCSI ID (target). See "Logical Unit Numbers" on page 25 for a discussion on how to use logical unit numbers.

Caution Always save a copy of a kernel file before changing it.

1. Check if the following code is in the `struct st_drivetype st_drivetypes[]` array found in the `/sys/scsi/targets/st_conf.c` file.

If the code is not in this file, add it. The best way to make this addition is to copy it from `MediaMgr_DeviceConfig_Guide.txt`.

```
/* STK 38000 1/2 in cartridge */  
{  
    "STK", 3, "STK", ST_TYPE_STK, 1024,  
    (ST_VARIABLE | ST_BSF | ST_BSR | ST_LONG_ERASE |  
    ST_AUTODEN_OVERRIDE | ST_KNOWS_EOD),
```



```

        5000, 5000,
        { 0x00, 0x00, 0x00, 0x00 },
        { 0, 0, 0, 0 }
    },

```

2. Check for the following line in `/sys/scsi/targets/stddef.h`. If this line is not in this file, add it.

```
define ST_TYPE_STK 0x34 /* STK 1/2 in.Cartridge */
```

3. After completing all other necessary changes to the kernel, rebuild it and reboot the system as explained in “Rebuilding a SunOS Kernel” on page 38. This is necessary for these changes to become effective.

Adding Quantum DLT Drives or Stackers

Read this topic if you plan to use standalone or robotic Quantum DLT2000 or DLT4000 drives or a Quantum DLT2700 or DLT4700 stacker. It explains SunOS kernel changes you may have to make in order for the system to recognize these drives.

Caution Always save a copy of a kernel file before changing it.

1. Check that the following code is in the `struct st_drivetype st_drivetypes[]` array found in the `/sys/scsi/targets/st_conf.c` file.

```

/* QUANTUM DLT */
{
    "QUANTUM DLT Tape Drive", 15, "Quantum DLT2000",
    ST_TYPE_DLT, 1024,
    (ST_VARIABLE | ST_BSF | ST_BSR | ST_LONG_ERASE |
    ST_AUTODEN_OVERRIDE | ST_KNOWS_EOD),
    5000, 5000,
    { 0x00, 0x00, 0x00, 0x00 },
    { 0, 0, 0, 0 }
},

```

Note For a DLT4000 drive, create the entry as shown above, except substitute DLT4000 for DLT2000.

For a QUANTUM DLT2700 stacker, add the following to the `struct st_drivetype st_drivetypes[]` array:

```

/* QUANTUM DLT2700 Stacker */
{
    "QUANTUM DLT Tape Drive", 15, "Quantum DLT2700",
    ST_TYPE_DLT, 1024,

```



```
(ST_VARIABLE | ST_BSF | ST_BSR | ST_LONG_ERASE |  
ST_AUTODEN_OVERRIDE | ST_KNOWS_EOD),  
5000, 5000,  
{ 0x00, 0x00, 0x00, 0x00 },  
{ 0, 0, 0, 0 }  
},
```

Note For a DLT4700 stacker, create the entry as shown above, except substitute DLT4700 for DLT2700.

Devices may have different vendor/product strings than those shown here. In the Quantum DLT2700 drive example, Quantum DLT2700 is the vendor/product string. The 15 preceding the string is the string length. It must compare.

To view the vendor/product strings for your drives, use the `dmesg(8)` command shortly after boot. The vendor and product strings for a drive are also logged with the `syslogd(8)` utility when the system is booted. This utility typically logs to `/var/adm/messages`.

Note Some older DLT2000 drives may have DEC instead of Quantum for a vendor ID.

If this code is not in the `st_conf.c` file, add it. The best way to make additions is to copy it from `MediaMgr_DeviceConfig_Guide.txt`.

2. Check for the following line in `/sys/scsi/targets/stdef.h`. If this line is not in this file, add it.

```
define          ST_TYPE_DLT 0x35 /* Quantum DLT*/
```

3. After completing all other necessary changes to the kernel, rebuild it and reboot the system as explained in “Rebuilding a SunOS Kernel” on page 38. This is necessary for these changes to become effective.

Configuring HP Optical Disk Drives

Note HP optical disk drives are accessed through the SCSI disk driver (`sd`). Read the “Setting the Optical Drive Type in Nonvolatile Memory” on page 36 for instructions on configuring the system so this access can occur.

When adding optical disk drives to a Media Manager configuration, you must specify the following device paths:

- ◆ Character device path (partition `g`)
- ◆ Volume header device path (partition `a`)

In a typical SunOS configuration, most of the desired disk device files already exist in the `/dev` directory.

Character disk device files have the following format:

```
/dev/rsdsd_numberg
```

Volume header device files have the following format:

```
/dev/rsdsd_numbera
```

Where:

`sd_number` is the disk device number configured to the desired SCSI bus and SCSI ID in the kernel configuration file.

`g` is the desired disk partition.

`a` is the desired disk partition.

See the `sd(4S)` man page for further details.

Creating Device Files

If the required device files does not exist, you can use the `MAKEDEV` command to create device files for a particular SCSI optical disk number as follows:

```
cd /dev
MAKEDEV sdsd_number
```

Where `sd_number` is the disk device number assigned to the desired SCSI bus and SCSI ID in the SCSI device unit assignment table (see “Checking the SCSI Device Unit Assignment Table” on page 25).

For example, if the desired optical disk drive is on SCSI bus 1 at SCSI ID 3 and the SCSI device unit assignment table contains the following line:

```
disk sd7 at scsibus1 target 3 lun 0 # HP optical disk drive
```



the SCSI disk number is 7 and the following commands create the device files:

```
cd /dev
MAKEDEV sd7
```

Examples of Device Files

If the desired optical disk drive is on SCSI bus 1 at SCSI ID 3, and the kernel configuration file contains the following line:

```
disk sd7 at scsibus1 target 3 lun 0 # HP optical disk drive
```

then the *sd_number* is 7 and the device file paths you enter are as follows:

Volume header:

```
/dev/rsd7a
```

Character device:

```
/dev/rsd7g
```

Setting the Optical Drive Type in Nonvolatile Memory

Note If you have not already done so, verify that your kernel SCSI ID mapping table has the appropriate *sd* (SCSI disk) entries for the optical disk drives. See “Changing SCSI ID Mapping in Kernel Configuration” on page 24 for details.

To use HP optical disk drives, the system must recognize the optical drives as disk drives (using the *sd* driver) at system boot time. If you are adding Hewlett-Packard 1.2 gigabyte or equivalent model magneto-optical disk drives, the system may not recognize these as disk drives, and thus cannot write to or read from them.

The following steps explain how to correct this condition:

1. Install the SG loadable driver if it is not already installed. See “Configuring SCSI Robotic Controls” on page 20 for information on how to install the SG loadable driver.

Note Usually Media Manager uses the SG driver to access robotic controls. In the following step, the */dev* path must allow Media Manager to access the optical disk drive through the SG driver. Be sure to specify the SCSI ID for the optical disk drive, *not* the SCSI ID for the robotic control.

2. Use `/usr/opensv/volmgr/bin/scsi_command` to change the optical drive's device type (stored in the drive's nonvolatile memory) from optical memory to disk. The format of this command is as follows:

```
scsi_command -d /dev/sg/ccontroller:tid10 -disk
```



Where:

controller is the number of the SCSI controller

id is the SCSI ID of the disk drive

For example, if the Hewlett-Packard 1.2 gigabyte magneto-optical disk drive is on controller 1 at SCSI ID 3, enter the following command:

```
scsi_command -d /dev/sg/c1t3l0 -disk
```

- 3.** Reboot the system to allow the drive to be recognized as a disk drive during system initialization by the kernel's SCSI disk (sd) driver. If you have done kernel reconfiguration, ensure the kernel is in place prior to reboot.



Rebuilding a SunOS Kernel

Read this topic if you have modified the SCSI ID mapping in the kernel configuration table or have added a new drive type to the kernel source by altering the `st_conf.c` or `stdef.h` files.

After you have completed modifications to the SunOS kernel configuration for the type or number of drives, as described in previous topics, you are ready to reconfigure and rebuild the kernel. This procedure is explained in the following steps:

1. Determine the name of your kernel by using one of the following commands.

```
cat /etc/motd
Auspex 1.9.2M1z4/SunOS 4.1.4 (MY_KERN)#19:Tue Feb 15 09:55:41 2000

strings /vmunix | grep SunOS
Auspex 1.9.2M1z4/SunOS 4.1.4 (MY_KERN)#19:Tue Feb 15 09:55:41 2000
```

In these examples, the name of the running kernel is most likely `MY_KERN`.

2. Use the `arch` command to determine the kernel architecture.

```
/usr/bin/arch -k
sun4m
```

3. Use the `config` utility on the kernel configuration file as follows:

- a. Change your working directory as appropriate:

```
cd /sys/arch/conf
```

Where *arch* is the kernel architecture value obtained in step 2. For example:

```
cd /sys/sun4m/conf
```

- b. Run the utility on the configuration file:

```
/etc/config kernel_name
```

Where *kernel_name* is the value obtained in step 1 or a new name for your kernel.
For example:

```
/etc/config MY_KERN
```

4. Build the new kernel using `make` in the appropriate directory:

```
cd ../kernel_name
make
```

Where *kernel_name* is the value used in step 3. This results in a new file named `vmunix` created in your current working directory.



5. Before booting with the new kernel created in the previous step, do the following:
 - a. Ensure there is enough disk space in the / partition, then make a copy of the old kernel:

```
cp /vmunix /vmunix.old
```
 - b. Replace the old kernel with the new one.

```
cp vmunix /vmunix
```
6. Reboot the system.

For more detailed information, see the `st(4s)`, `sd(4s)`, and `config(8)` man pages.



Command Summary

The following is a summary of commands that may be useful when configuring devices. See the procedures in this chapter for examples of their usage.

```
/usr/etc/modstat
```

Shows the loadable drivers that are currently loaded.

```
/usr/opensv/volmgr/bin/driver/sg.install
```

Loads the SG driver.

```
/usr/etc/modunload -id n
```

Unloads the loadable driver that has an Id of *n*, as shown by `modstat`.

```
cat /etc/motd
```

Displays the name of the kernel configuration file.

```
arch -k
```

Displays the kernel architecture.

```
MAKEDEV stst_number
```

Creates SCSI tape device files, where *st_number* is the tape device number configured to the desired SCSI bus and SCSI ID in the kernel configuration file.

```
dmesg
```

Shows the vendor and product strings for the drives on your system, when it is executed shortly after a boot.

```
/etc/config kernel_name
```

Builds system configuration files prior to rebuilding the kernel. *kernel_name* is the name of the kernel configuration file as returned by `cat /etc/motd` (for example, `GENERIC`).

```
make
```

Creates a new kernel file named `vmunix` in your current working directory. This working directory should be `/etc/config/kernel_name`, where *kernel_name* is the name of the kernel configuration file as returned by `cat /etc/motd` (for example, `GENERIC`).

```
/usr/opensv/volmgr/bin/sgscan
```

Allows you to determine the SCSI devices connected to a Auspex SunOS server by executing a SCSI inquiry on all device files in `/dev/sg`.

```
/usr/opensv/volmgr/bin/spscan
```



Allows you to determine the SCSI devices connected to an Auspex Storage Processor by executing a SCSI inquiry on all `/dev/asc*` device files.

```
/usr/opensv/volmgr/bin/vmconf
```

Provided with Media Manager, this script does device setup in less complex configurations.





This chapter explains how to configure devices for use with Media Manager on a Sun4/SPARC platform. Configure drives and robots using one of the available Media Manager administrative interfaces.

The major topics included are as follows:

- ◆ Before You Start
- ◆ Preventing Possible System Problems
- ◆ Installing SCSI Pass-Through Drivers
- ◆ Configuring the SG Driver
- ◆ Configuring Robotic Controls
- ◆ Configuring Tape Drives
- ◆ Configuring HP Optical Disk Drives
- ◆ Command Summary

Before You Start

Observe the following points when performing the configurations described in this chapter:

- ◆ When configuring devices, you should attach all peripherals and reboot the system with the reconfigure option (`boot -r` or `reboot -- -r`).
- ◆ Always install the `sg` driver (see “Installing SCSI Pass-Through Drivers” on page 45). This driver is used by `avrd` (automatic volume recognition daemon) to scan drives, and is required for communicating with SCSI devices and for locate-block tape positioning.
- ◆ When removing or replacing adapter cards, remove all device files previously associated with the adapter card.
- ◆ If you use the Automated Cartridge System (ACS) robotic software, you must ensure that the SunOS/BSD Source Compatibility Package is installed, so that the ACS software can make use of shared libraries in `/usr/ucblib`.



If You Are Using NetBackup BusinessServer

Portions of this chapter include configuration topics and examples for peripherals that are not supported in NetBackup BusinessServer. It is important to refer to the NetBackup release notes to determine which Media Manager robot types, robots, and drives are supported for NetBackup BusinessServer, before using this chapter.

Topics Applicable to NetBackup BusinessServer

“Preventing Possible System Problems” on page 44 applies to NetBackup BusinessServer.

Topics Not Applicable to NetBackup BusinessServer

“Installing SCSI Pass-Through Drivers” on page 45 does not apply to NetBackup BusinessServer. The NetBackup BusinessServer installation script installs the sg driver.

“Configuring HP Optical Disk Drives” on page 66 does not apply to NetBackup BusinessServer.

Preventing Possible System Problems

When system memory gets low, Solaris unloads unused drivers from memory and reloads drivers as needed. Tape drivers are a frequent candidate for unloading, since they tend to be less heavily used than disk drivers. Depending on the timing of these unload and load events for the st (Sun), sg (VERITAS), and fibre channel drivers, various problems may result. These problems can range from devices "disappearing" from a SCSI bus to system panics.

VERITAS recommends adding the following `forceload` statements to the `/etc/system` file. These statements prevent the st and sg drivers from being unloaded from memory.

```
forceload: drv/st
forceload: drv/sg
```

Other statements may be necessary for various fibre channel drivers, such as the following example for JNI:

```
forceload: drv/fcaw
```

Installing SCSI Pass-Through Drivers

NetBackup Media Manager software provides its own driver for communicating with SCSI-controlled robotic peripherals. This driver is called the SCSA (Generic SCSI pass-through driver), also referred to as the `sg` driver.

Note Since NetBackup uses its own pass-through driver, the Solaris 8.0 `sgen scsi` pass-through driver is not supported.

The `sg` driver is also used for the following:

- ◆ By `avrd` for scanning drives.
- ◆ By NetBackup for locate-block positioning.
- ◆ To set the optical drive type (as explained in “Setting the HP Optical Drive Type in Nonvolatile Memory” on page 67).

Use the following procedure to load the `sg` driver. Perform these steps as the root user.

1. Determine if an `sg` driver is loaded by using the following command:

```
/usr/sbin/modinfo | grep sg
141 fc580000 2d8c 116 1 sg (SCSA Generic Revision: 3.2)
153 fc7fa000 1684 49 1 msgsys (System V message facility)
```

In this example, there already is an `sg` driver loaded, so you must remove it before proceeding.

2. Remove the existing driver by executing:

```
/usr/sbin/rem_drv sg
```

3. Install the new `sg` driver, with the following command:

```
/usr/opensv/volmgr/bin/driver/sg.install
```

Once the driver has been installed, it is not necessary to reboot the system, or run the `sg.install` command during or after each system boot.

To uninstall the driver, at a later time, use the following command:

```
/usr/sbin/rem_drv sg
```



Configuring the SG Driver

This procedure contains instructions for configuring the sg driver for SCSI targets 8 thru 15 for Fast/Wide Adapter Cards. In this procedure, you execute `sg.build` three times to add these targets to `st.conf`, `sg.links`, and `sg.conf`.

1. Execute the `sg.build` script to create a file that you then use to replace the following seven entries that are in the `/kernel/drv/st.conf` file:

```
name="st" class="scsi"
  target=0 lun=0;
name="st" class="scsi"
  target=1 lun=0;
name="st" class="scsi"
  target=2 lun=0;
name="st" class="scsi"
  target=3 lun=0;
name="st" class="scsi"
  target=4 lun=0;
name="st" class="scsi"
  target=5 lun=0;
name="st" class="scsi"
  target=6 lun=0;
```

- a. Create a temporary `st.conf` file. An example of using `sg.build` to create this file follows. This command will create targets 0 thru 15 (omitting target 7).

```
cd /usr/opensv/volmgr/bin/driver
/usr/opensv/volmgr/bin/sg.build st.conf -mt 15 -ml 1 -st ./st.conf
```

- b. Edit the `/kernel/drv/st.conf` file. The temporary file `./st.conf` contains the entries that you need to insert into `/kernel/drv/st.conf`.
- c. Reboot the system with the reconfigure option (`boot -r` or `reboot -- -r`).

2. Execute the `sg.build` script to add targets 8 thru 15 to the `/usr/opensv/volmgr/bin/driver/sg.links` file.

Caution The field separator is a tab between the `addr=#,#;` and the `sg/c\N0t#l#` field.

An example of using the script and the file that is generated follow:

```
cd /usr/opensv/volmgr/bin/driver
/usr/opensv/volmgr/bin/sg.build sg.links -mt 15 -ml 1 -sl ./sg.links
```



```

type=ddi_pseudo;name=sg;addr=0,0;      sg/c\N0t010
type=ddi_pseudo;name=sg;addr=1,0;      sg/c\N0t110
type=ddi_pseudo;name=sg;addr=2,0;      sg/c\N0t210
type=ddi_pseudo;name=sg;addr=3,0;      sg/c\N0t310
type=ddi_pseudo;name=sg;addr=4,0;      sg/c\N0t410
type=ddi_pseudo;name=sg;addr=5,0;      sg/c\N0t510
type=ddi_pseudo;name=sg;addr=6,0;      sg/c\N0t610
type=ddi_pseudo;name=sg;addr=8,0;      sg/c\N0t810
type=ddi_pseudo;name=sg;addr=9,0;      sg/c\N0t910
type=ddi_pseudo;name=sg;addr=a,0;      sg/c\N0t1010
type=ddi_pseudo;name=sg;addr=b,0;      sg/c\N0t1110
type=ddi_pseudo;name=sg;addr=c,0;      sg/c\N0t1210
type=ddi_pseudo;name=sg;addr=d,0;      sg/c\N0t1310
type=ddi_pseudo;name=sg;addr=e,0;      sg/c\N0t1410
type=ddi_pseudo;name=sg;addr=f,0;      sg/c\N0t1510
type=ddi_pseudo;name=sg;addr=0,1;      sg/c\N0t011
type=ddi_pseudo;name=sg;addr=1,1;      sg/c\N0t111
type=ddi_pseudo;name=sg;addr=2,1;      sg/c\N0t211
type=ddi_pseudo;name=sg;addr=3,1;      sg/c\N0t311
type=ddi_pseudo;name=sg;addr=4,1;      sg/c\N0t411
type=ddi_pseudo;name=sg;addr=5,1;      sg/c\N0t511
type=ddi_pseudo;name=sg;addr=6,1;      sg/c\N0t611
type=ddi_pseudo;name=sg;addr=8,1;      sg/c\N0t811
type=ddi_pseudo;name=sg;addr=9,1;      sg/c\N0t911
type=ddi_pseudo;name=sg;addr=a,1;      sg/c\N0t1011
type=ddi_pseudo;name=sg;addr=b,1;      sg/c\N0t1111
type=ddi_pseudo;name=sg;addr=c,1;      sg/c\N0t1211
type=ddi_pseudo;name=sg;addr=d,1;      sg/c\N0t1311
type=ddi_pseudo;name=sg;addr=e,1;      sg/c\N0t1411
type=ddi_pseudo;name=sg;addr=f,1;      sg/c\N0t1511

```

3. Execute the `sg.build` script to add targets 8 thru 15 to the `/usr/opensv/volmgr/bin/driver/sg.conf` file.

An example of using the script and the file that is generated follow:

```

cd /usr/opensv/volmgr/bin/driver
/usr/opensv/volmgr/bin/sg.build sg.conf -mt 15 -ml 1 -sc ./sg.conf

```

```

name="sg" class="scsi" target=0 lun=0;
name="sg" class="scsi" target=0 lun=1;
name="sg" class="scsi" target=1 lun=0;
name="sg" class="scsi" target=1 lun=1;
name="sg" class="scsi" target=2 lun=0;
name="sg" class="scsi" target=2 lun=1;
name="sg" class="scsi" target=3 lun=0;

```



```
name="sg" class="scsi" target=3 lun=1;
name="sg" class="scsi" target=4 lun=0;
name="sg" class="scsi" target=4 lun=1;
name="sg" class="scsi" target=5 lun=0;
name="sg" class="scsi" target=5 lun=1;
name="sg" class="scsi" target=6 lun=0;
name="sg" class="scsi" target=6 lun=1;
name="sg" class="scsi" target=8 lun=0;
name="sg" class="scsi" target=8 lun=1;
name="sg" class="scsi" target=9 lun=0;
name="sg" class="scsi" target=9 lun=1;
name="sg" class="scsi" target=10 lun=0;
name="sg" class="scsi" target=10 lun=1;
name="sg" class="scsi" target=11 lun=0;
name="sg" class="scsi" target=11 lun=1;
name="sg" class="scsi" target=12 lun=0;
name="sg" class="scsi" target=12 lun=1;
name="sg" class="scsi" target=13 lun=0;
name="sg" class="scsi" target=13 lun=1;
name="sg" class="scsi" target=14 lun=0;
name="sg" class="scsi" target=14 lun=1;
name="sg" class="scsi" target=15 lun=0;
name="sg" class="scsi" target=15 lun=1;
```

4. Edit the file `/etc/devlink.tab` and remove the devices for the sg driver.

5. Uninstall the sg driver.

```
/usr/sbin/rem_drv sg.
```

6. Install the new sg driver.

```
/usr/openv/volmgr/bin/driver/sg.install.
```


Configuring Robotic Controls

Robots are controlled through a SCSI or a network connection.

Configuration of network controlled robotic libraries (for example, ACS robots) is discussed in the appendices of the UNIX Media Manager system administrator's guide.

SCSI control is covered in the following sections.

Configuring SCSI Robotic Controls

Read this topic if you plan to use a robotic storage device that is controlled through a SCSI robotic connection. Supported SCSI robots include the following. See the NetBackup release notes for a list of the vendor models associated with each robot type.

- ◆ ODL - Optical Disk Library
- ◆ TL4 - Tape Library 4MM
- ◆ TL8 - Tape Library 8MM
- ◆ TLD - Tape Library DLT
- ◆ TS8 - Tape Stacker 8MM
- ◆ TSD - Tape Stacker DLT
- ◆ TSH - Tape Stacker Half-inch

When communicating with SCSI-controlled robotic peripherals, Media Manager software utilizes the SCSI Generic (*sg*) driver. This driver is provided with the NetBackup software.

Note You must install the *sg* driver before continuing with the instructions in this topic (see "Installing SCSI Pass-Through Drivers" on page 45 for details).

To display the device files that are available to be used through the *sg* driver, use the *sgscan* command with the *all* parameter and note the lines that indicate the Changer devices, as in the following example:

```
# /usr/opensv/volmgr/bin/sgscan all
/dev/sg/c0t5l0: Tape (/dev/rmt/0): "HP          C1537A"
/dev/sg/c0t6l0: Cdrom: "TOSHIBA XM-5401TASUN4XCD"
/dev/sg/c1t2l0: Tape (/dev/rmt/7): "EXABYTE  EXB-85058HE-0000"
/dev/sg/c1t4l0: Tape (/dev/rmt/9): "EXABYTE  EXB-8900MH000202"
/dev/sg/c1t5l0: Changer: "EXABYTE  EXB-210"
/dev/sg/c2t2l0: Tape (/dev/rmt/10): "Quantum  DLT4000"
/dev/sg/c2t5l0: Tape (/dev/rmt/11): "QUANTUM  DLT7000"
/dev/sg/c3t0l0: Disk (/dev/rdisk/c1t0d0): "FUJITSU  M2952ESP  SUN2.1G"
/dev/sg/c3t3l0: Disk (/dev/rdisk/c1t3d0): "FUJITSU  M2952ESP  SUN2.1G"
```



```
/dev/sg/c4t410: Tape (/dev/rmt/4): "Quantum DLT4000"  
/dev/sg/c4t510: Tape (/dev/rmt/5): "Quantum DLT4000"  
/dev/sg/c5t010: Disk (/dev/rdisk/c5t0d0): "SONY      SMO-F541"  
/dev/sg/c5t110: Disk (/dev/rdisk/c5t1d0): "SONY      SMO-F541"  
/dev/sg/c5t210: Disk (/dev/rdisk/c5t2d0): "SEAGATE  ST11200N SUN1.05"  
/dev/sg/c5t610: Disk (/dev/rdisk/c5t6d0): "SEAGATE  ST11200N SUN1.05"  
/dev/sg/c6t310: Changer: "SONY      DMS-B35"  
/dev/sg/c6t510: Tape (/dev/rmt/6): "SONY      GY-2120"  
/dev/sg/c7t010: Disk (/dev/rdisk/c7t0d0): "SEAGATE  ST32550W SUN2.1G"  
/dev/sg/c7t310: Disk (/dev/rdisk/c7t3d0): "MICROP   4221-09  1128RA"  
/dev/sg/c7t410: Disk (/dev/rdisk/c7t4d0): "MICROP   4221-09MZ  Q4D"  
/dev/sg/c8t210: Tape (/dev/rmt/14): "Quantum DLT4000"  
/dev/sg/c8t310: Changer: "STK      9740"  
/dev/sg/c8t410: Tape (/dev/rmt/13): "STK      SD-3"  
/dev/sg/c8t610: Changer: "STK      9710"  
/dev/sg/c9t010: Changer: "EXABYTE  Exabyte 18D"  
/dev/sg/c9t110: Tape (/dev/rmt/15): "Quantum DLT4000"
```

Note Specific device types can be filtered from the output using other forms of `sgscan`.

Usage: `sgscan [all|basic|changer|disk|tape] [conf] [-v]`

Examples of SCSI Robotic Control Device Files

Example 1

Using the above `sgscan` output, if the SCSI robotic control for an Exabyte 210 is connected to SCSI ID 5 of adapter 1, you use the following path:

```
/dev/sg/c1t510
```

Example 2

Using the above `sgscan` output, if the SCSI robotic control for a Sony library is connected to SCSI ID 3 of adapter 6, you use the following path:

```
/dev/sg/c6t310
```

Example 3

Using the above `sgscan` output, if the SCSI robotic control for an STK 9710 is connected to SCSI ID 6 of adapter 8 and you want to use TLD robotics, you use the following path:

```
/dev/sg/c8t610
```

Example 4

If the SCSI robotic control for a DLT2700, DLT4700, or HP C1560B was connected to SCSI ID 5 of adapter 0, you use the following path:

```
/dev/sg/c0t5l1
```

Note that logical unit number 1 is used for those devices. The sg driver configuration can be modified so `sgscan` lists LUN 1 devices. In the `sgscan` output shown above, the configuration was not modified.

Example 5

Using the above `sgscan` output, even if the SCSI robotic control for an STK 9740 is connected to SCSI ID 3 of adapter 8, you would not enter any path to configure ACS robotic control.

Instead, assuming ACS control over the network, enter the appropriate ACSLS Host name. (If you want to use TLD robotics to control the 9740, specify the path

```
/dev/sg/c8t3l0).
```

Example 6 (IBM 3570 B-series Stackers)

If there is one drive in the stacker, the robotic control is LUN 1 of the drive's SCSI ID. If there are two drives in the stacker, the robotic control is LUN 1 of the Drive 1 SCSI ID. The SCSI ID's are viewed and configured by using the front panel on the stacker.

The robotic control for the IBM 3570 B01/B02 is TLD, so if there are two drives, they may be connected to different host systems. If this is the case, the host system which is connected to drive 1 must also have the robotic control. Also, the library should be in RANDOM mode and BASE configuration. See the operator's guide supplied with the unit for information on setting library mode and configuration.

Assume a configuration as follows:

```
# /usr/openv/volmgr/bin/sgscan
/dev/sg/c0t0l0: Disk (/dev/rdisk/c0t0d0): "IBM   DCAS32160SUN2.1G"
/dev/sg/c0t6l0: Cdrom: "TOSHIBA XM5701TASUN12XCD"
/dev/sg/c1t5l0: Tape (/dev/rmt/1): "IBM     03570B02"
/dev/sg/c1t6l0: Tape (/dev/rmt/2): "IBM     03570B02"
```

If drive 1 is SCSI ID 5, the robotic control for the stacker is `/dev/sg/c1t5l1`.

Example 7 (Fujitsu M8100 Stackers)

The robotic control for the Fujitsu M8100 stacker is TSH. The unit must be set up to run in SYSTEM Mode and 2LUN Mode. See the M8100 Cartridge Tape Drive product guide supplied with the unit for information on setting the library modes.



The robotic control is LUN 1 of the drive's SCSI ID. The SCSI ID's are viewed and configured by using the front panel on the stacker.

Assume a configuration as follows:

```
# /usr/opensv/volmgr/bin/sgscan  
/dev/sg/clt010: Tape (/dev/rmt/0): "FUJITSU M8100AA2"  
/dev/sg/clt011: Changer: "FUJITSU M8100AA2"
```

If the drive is SCSI ID 0, the robotic control for the stacker is `/dev/sg/clt011`.

Configuring Tape Drives

Using Berkeley-Style Close

The examples in this section use Berkeley-style close for tape drives as indicated by the letter `b` after the density specification. You must specify Berkeley-style close for tape devices that you configure under Media Manager.

The terms *Berkeley-style close* and *AT&T style close* refer to where a tape is left logically positioned after a close operation (in relation to a tape mark). One style leaves an application logically positioned before a tape mark and the other leaves it after. Applications must assume where the tape is left after a close in order to establish the correct orientation the next time they do a tape-position or read operation. Some operating systems allow tape devices to be configured with either type of close. NetBackup assumes it is using Berkeley-style close.

Fast-Tape Positioning (`locate-block`)

For AIT, DLT, Exabyte, DTF, and half-inch tape drives, Media Manager supports the SCSI `locate-block` command for positioning to a specific block on a tape. This approach improves tape-positioning times over the alternative, which is the `forward-space-file/record` method.

Enabling `locate-block`

NetBackup and Storage Migrator use the `locate-block` command by default if you did not uninstall the `sg passthru` driver as explained in “Installing SCSI Pass-Through Drivers” on page 45. The driver is automatically installed with Media Manager.

Disabling `locate-block`

To disable `locate-block` positioning, execute the following:

```
touch /usr/opensv/volmgr/database/NO_LOCATEBLOCK
```

With `locate-block` positioning disabled, NetBackup uses the `forward-space-file/record` method and Storage Migrator skips file marks.

No Rewind Device Files

When adding tape drives to a Media Manager configuration, you need only specify a no rewind on close device path. To display the tape device files that are configured on your system, use the `sgscan` command with the `tape` parameter.

```
# /usr/opensv/volmgr/bin/sgscan tape
```



```
/dev/sg/c0t5l0: (/dev/rmt/0): "HP      C1537A"  
/dev/sg/c1t2l0: (/dev/rmt/7): "EXABYTE EXB-85058HE-0000"  
/dev/sg/c1t4l0: (/dev/rmt/9): "EXABYTE EXB-8900MH000202"  
/dev/sg/c2t2l0: (/dev/rmt/10): "Quantum DLT4000"  
/dev/sg/c2t5l0: (/dev/rmt/11): "QUANTUM DLT7000"  
/dev/sg/c4t4l0: (/dev/rmt/4): "Quantum DLT4000"  
/dev/sg/c4t5l0: (/dev/rmt/5): "Quantum DLT4000"  
/dev/sg/c6t5l0: (/dev/rmt/6): "SONY    GY-2120"  
/dev/sg/c8t2l0: (/dev/rmt/14): "Quantum DLT4000"  
/dev/sg/c8t4l0: (/dev/rmt/13): "STK     SD-3"  
/dev/sg/c9t1l0: (/dev/rmt/15): "Quantum DLT4000"
```

Note All device types can be displayed in the output using the `all` parameter with `sgscan`. This command can be helpful for associating tape devices with other SCSI devices that may be configured on the same adapter.

Usage: `sgscan [all|basic|changer|disk|tape] [conf] [-v]`

No rewind on close device files are in the `/dev/rmt` directory, and have the following format:

```
/dev/rmt/Logical_drivecbn
```

Where:

Logical_drive is the logical drive id, as shown by the `sgscan` command.

The `c` indicates compression.

The `b` indicates Berkeley-style close.

The `n` indicates no rewind on close.

Examples of No Rewind Device Files

Example 1

Using the `sgscan` output, if an Exabyte 8505C drive is connected to SCSI ID 2 of adapter 1, the device path you use follows:

```
/dev/rmt/7cbn
```

Example 2

Using the `sgscan` output, if a DLT7000 drive is connected to SCSI ID 5 of adapter 2, the device path you use follows:

```
/dev/rmt/11cbn
```

Configuring Nonstandard Tape Drives

This topic applies to the following drive types.

Note These are nonstandard drive types that require changes to the kernel before you can use them on some of the supported versions of Solaris.

- ◆ Exabyte (models 8500, 8505, 8505XL, 8500C, 8900, or Mammoth2)
- ◆ Fujitsu M2488 and M8100
- ◆ HP 4-mm DAT
- ◆ IBM 3570 and 3590
- ◆ Quantum DLT2000, DLT4000, DLT7000, or DLT8000
- ◆ Sony AIT, AIT-2, and DTF
- ◆ STK half-inch cartridge
- ◆ Tandberg QIC and QIC 150

Caution As shown by the `st.conf` examples in this section, you must configure non-QIC tape drives as variable-mode devices if they are to be used by Media Manager on Solaris platforms. Otherwise, NetBackup is able to write data, but not read it. During a read, you see a “not in tar format” error. The terms *variable mode* or *fixed mode* refers to the behavior of reads and writes and the way the kernel packs physical tape records into logical tape records for an application. Variable-mode devices allow more flexibility in reading previously written tapes. Many tape devices can be accessed in either mode. NetBackup assumes variable mode for non-QIC drives.

Note on Case and Spaces in `st.conf` Entries

Upper and lower case are significant. For example, using Hp instead of HP would not work.

Spaces are significant within quoted strings in the `/kernel/drv/st.conf` file. The area that users most frequently have trouble with is the vendor field, which must always be eight characters in length.

For example, the vendor/product string for an HP C1533A drive is as follows (HP and 6 spaces is the vendor field):

```
"HP      C1533A"
```

If you were to omit some of the spaces (HP and 2 spaces is now the vendor field) in the vendor field as in the following example, the drive would not be recognized correctly.

```
"HP  C1533A"
```



The best way to ensure that your entries are accurate is to copy them from the `MediaMgr_DeviceConfig_Guide.txt` file.

Additions to the `st.conf` File

An entry must be included for the drive type you are running. The changes in this section were tested and are known to work, but other settings may also work.

Caution Note the second portion of this list, where the third parameter (variable mode) must be 0. Not using 0 causes restores to fail and may result in data loss. (The entry for `ARCHIVE_VIP` is the only exception.)

```
tape-config-list =

"EXABYTE EXB8500C", "Exabyte EXB-8500C 8mm Helical Scan", "EXB-8500C",
"EXABYTE EXB-8505", "Exabyte EXB-8505 8mm Helical Scan", "EXB-8505",
"EXABYTE EXB-8500", "Exabyte EXB-8500 8mm Helical Scan", "EXB-8500",
"EXABYTE EXB-8900", "Exabyte EXB-8900 Mammoth", "EXB-8900",
"EXABYTE Mammoth2", "Mammoth2 8MM Helical Scan Drive", "EXB-MAMMOTH2",
"FUJITSU M2488", "Fujitsu M2488", "FJ-D3",
"FUJITSU M8100", "Fujitsu M8100 1/2 Inch Cartridge", "FJ-M8100",
"HP HP354", "HP 4mm DAT Drive", "HP-DAT",
"HP C1533A", "HP DAT Autoloader", "HP-DAT",
"HP C1557A", "HP Dat DDS3 Autoloader", "HP-DAT-DDS3",
"HP C5683A", "HP DDS-4 4mm DAT", "HP_DAT_4",
"IBM 03590", "IBM 3590 1/2 Inch Cartridge", "IBM-3590",
"IBM 03570", "IBM 3570 1/2 Inch Cartridge", "IBM-3590",
"Metrum RSP-2150", "Metrum VHS Drive", "Metrum",
"ARCHIVE VIPER 150", "Archive 150 Tape", "ARCHIVE_VIP",
"TANDBERG SLR5 4/8GB", "Tandberg 8 Gig QIC", "TAND-8G-VAR",
"TANDBERGLT4000", "Tandberg DLT4000", "DEC-DLT",
"TANDBERGLT7000", "Tandberg DLT7000", "Q-DLT7000",
"SONY GY-2120", "Sony DTF Drive", "gy20-data",
"SONY GY-8240", "DTF2", "gy2120-data",
"SONY SDX-300C", "SONY 8mm AIT", "SONY_AIT",
"SONY SDX-500C", "SONY 8mm AIT2", "SONY_AIT",
"SONY TSL-A300C", "SONY 8mm AIT", "SONY_AIT",
"SONY TSL-A500C", "SONY 8mm AIT2", "SONY_AIT",
"DEC DLT2000", "DEC DLT Tape Drive", "DEC-DLT",
"DEC DLT2700", "DEC DLT Tape Stacker", "DEC-DLT",
"Quantum DLT2000", "Quantum DLT Tape Drive", "DEC-DLT",
"Quantum DLT4000", "Quantum DLT Tape Drive", "DEC-DLT",
"Quantum DLT4500", "Quantum DLT Tape Stacker", "DEC-DLT",
"Quantum DLT4700", "Quantum DLT Tape Stacker", "DEC-DLT",
"QUANTUM DLT7000", "Quantum DLT7000 Tape Drive", "Q-DLT7000",
"QUANTUM DLT8000", "Quantum DLT8000 Tape Drive", "DLT8k-data",
"Quantum DLT2700", "Quantum DLT Tape Stacker", "DEC-DLT",
```



```
"STK      4781", "STK 1/2 Inch Cartridge (4480)", "STK-4781",
"STK      4791", "STK 1/2 Inch Cartridge (Silverton)", "STK-4791",
"STK      4890", "STK 1/2 Inch Cartridge (Twin Peaks)", "STK-4890",
"STK      9840", "STK 1/2 Inch Cartridge (9840)", "STK-9840",
"STK      SD-3", "STK 1/2 Inch Cartridge (Redwood)", "STK-SD-3";
```

```
EXB-8500C = 1,0x35,0,0x9639,4,0x14,0x15,0x8C,0x00,3;
EXB-8505 = 1,0x35,0,0x9639,4,0x14,0x15,0x8C,0x00,3;
EXB-8500 = 1,0x35,0,0x9639,4,0x14,0x00,0x00,0x15,2;
EXB-8900 = 1,0x35,0,0x9639,4,0x27,0x27,0x27,0x00,3;
EXB-MAMMOTH2 = 1,0x35,0,0x19639,4,0,0x27,0x28,0x7f,2;
FJ-D3 = 1,0x21,0,0xCA19,4,0x09,0x09,0x09,0x09,0;
FJ-M8100 = 1,0x24,0,0x1d63d,4,0x0,0x0,0x0,0x0,3;
HP-DAT = 1,0x34,0,0x9639,4,0x0,0x0,0x0,0x0,3;
HP-DAT-DDS3 = 1,0x34,0,0,0x9639,4,0x0,0x8c,0x8c,0x8c,3;
HP_DAT_4 = 1,0x34,0,0x9639,4,0x00,0x8c,0x8c,0x8c,1;
IBM-3590 = 1,0x24,0,0x1c63d,4,0x0,0x0,0x0,0x0,3;
Metrum = 1,0x36,0,0x9639,4,0xf0,0xf0,0xf0,0xf0,3;
ARCHIVE_VIP = 1,0x32,512,0x163a,4,0x0,0x0,0x0,0x0,3;
TAND-8G-VAR = 1,0x37,0,0x963b,4,0xa0,0xd0,0xd0,0xd0,3;
gy20-data = 1,0x36,0,0xd659,1,0x00,0;
gy2120-data = 1,0x36,0,0x39659,1,0x00,0;
DEC-DLT = 1,0x36,0,0x9639,4,0x0,0x0,0x0,0x0,3;
Q-DLT7000 = 1,0x38,0,0x19639,4,0x82,0x83,0x84,0x85,3;
DLT8k-data = 1,0x38,0,0x19639,4,0x1a,0x1b,0x41,0x41,3;
SONY_AIT = 1,0x34,0,0x9639,4,0x13,0x0,0x8C,0x8C,3;
STK-4781 = 1,0x24,0,0x1d43d,1,0x00,0;
STK-4791 = 1,0x24,0,0x1d67d,1,0x00,0;
STK-4890 = 1,0x24,0,0x1d67d,1,0x00,0;
STK-9840 = 1,0x36,0,0x1d639,1,0x00,0;
STK-SD-3 = 1,0x24,0,0x1d67d,1,0x00,0;
```

Caution Reboot the system when you are done changing the kernel, using the reconfigure option (`boot -r` or `reboot -- -r`) to allow the kernel's SCSI tape (st) driver to recognize the drives as the correct type during system initialization.

Adding Logical Unit Number Entries

If the devices you are adding utilize the logical unit number (LUN) concept, (such as a half-inch cartridge drives that attach to an STK Automated Cartridge System) you must also add entries of the following form to the `st.conf` file:

```
name="st" class="scsi"
      target=SCSI_ID lun=LUN
```



Where:

SCSI_ID is the SCSI ID to which the drives are attached.

LUN is the logical unit number for the drive.

For example, if a drive is configured at logical unit number 4 of SCSI ID 3, you add the following entry to `st.conf`:

```
name="st" class="scsi"
    target=3 lun=4
```

You can use the `sg.build` script to generate entries for the `st.conf` file.

Multiple Logical Unit Numbers per SCSI Target

This procedure describes how to install a device with multiple Logical Unit Numbers (LUN) per SCSI target. In this procedure, you execute `sg.build` three times to add targets 0 thru 15 (omitting target 7) and LUNs 0 thru 4 to `st.conf`, `sg.conf`, and `sg.links`.

Note This procedure is necessary in a fibre channel environment.

1. Execute the `sg.build` script to create a file that you use to replace the following entries that are in the `/kernel/drv/st.conf` file:

```
name="st" class="scsi"
    target=0 lun=0;
name="st" class="scsi"
    target=1 lun=0;
name="st" class="scsi"
    target=2 lun=0;
name="st" class="scsi"
    target=3 lun=0;
name="st" class="scsi"
    target=4 lun=0;
name="st" class="scsi"
    target=5 lun=0;
name="st" class="scsi"
    target=6 lun=0;
```

- a. Create a temporary `st.conf` file. An example of using `sg.build` to create this file follows:

```
cd /usr/opensv/volmgr/bin/driver
/usr/opensv/volmgr/bin/sg.build st.conf -mt 15 -ml 4 -st ./st.conf
```

- b. Edit the `/kernel/drv/st.conf` file. The temporary file `./st.conf` contains the entries that you need to insert into `/kernel/drv/st.conf`.
 - c. Reboot the system with the reconfigure option (`boot -r` or `reboot -- -r`).
2. Execute the `sg.build` script to create an `sg.conf` file with targets 0 thru 15 (omitting target 7). Each target will have LUNs 0 thru 4.

An example of using the script and the file that is generated follow:

```
cd /usr/opensv/volmgr/bin/driver
/usr/opensv/volmgr/bin/sg.build sg.conf -mt 15 -ml 4 -sc ./sg.conf
```

```
name="sg" class="scsi" target=0 lun=0;
name="sg" class="scsi" target=0 lun=1;
name="sg" class="scsi" target=0 lun=2;
name="sg" class="scsi" target=0 lun=3;
name="sg" class="scsi" target=0 lun=4;
name="sg" class="scsi" target=1 lun=0;
name="sg" class="scsi" target=1 lun=1;
name="sg" class="scsi" target=1 lun=2;
name="sg" class="scsi" target=1 lun=3;
name="sg" class="scsi" target=1 lun=4;
name="sg" class="scsi" target=2 lun=0;
name="sg" class="scsi" target=2 lun=1;
name="sg" class="scsi" target=2 lun=2;
name="sg" class="scsi" target=2 lun=3;
name="sg" class="scsi" target=2 lun=4;
name="sg" class="scsi" target=3 lun=0;
name="sg" class="scsi" target=3 lun=1;
name="sg" class="scsi" target=3 lun=2;
name="sg" class="scsi" target=3 lun=3;
name="sg" class="scsi" target=3 lun=4;
name="sg" class="scsi" target=4 lun=0;
name="sg" class="scsi" target=4 lun=1;
name="sg" class="scsi" target=4 lun=2;
name="sg" class="scsi" target=4 lun=3;
name="sg" class="scsi" target=4 lun=4;
name="sg" class="scsi" target=5 lun=0;
name="sg" class="scsi" target=5 lun=1;
name="sg" class="scsi" target=5 lun=2;
name="sg" class="scsi" target=5 lun=3;
name="sg" class="scsi" target=5 lun=4;
name="sg" class="scsi" target=6 lun=0;
name="sg" class="scsi" target=6 lun=1;
name="sg" class="scsi" target=6 lun=2;
name="sg" class="scsi" target=6 lun=3;
```



```
name="sg" class="scsi" target=6 lun=4;
name="sg" class="scsi" target=8 lun=0;
name="sg" class="scsi" target=8 lun=1;
name="sg" class="scsi" target=8 lun=2;
name="sg" class="scsi" target=8 lun=3;
name="sg" class="scsi" target=8 lun=4;
name="sg" class="scsi" target=9 lun=0;
name="sg" class="scsi" target=9 lun=1;
name="sg" class="scsi" target=9 lun=2;
name="sg" class="scsi" target=9 lun=3;
name="sg" class="scsi" target=9 lun=4;
name="sg" class="scsi" target=10 lun=0;
name="sg" class="scsi" target=10 lun=1;
name="sg" class="scsi" target=10 lun=2;
name="sg" class="scsi" target=10 lun=3;
name="sg" class="scsi" target=10 lun=4;
name="sg" class="scsi" target=11 lun=0;
name="sg" class="scsi" target=11 lun=1;
name="sg" class="scsi" target=11 lun=2;
name="sg" class="scsi" target=11 lun=3;
name="sg" class="scsi" target=11 lun=4;
name="sg" class="scsi" target=12 lun=0;
name="sg" class="scsi" target=12 lun=1;
name="sg" class="scsi" target=12 lun=2;
name="sg" class="scsi" target=12 lun=3;
name="sg" class="scsi" target=12 lun=4;
name="sg" class="scsi" target=13 lun=0;
name="sg" class="scsi" target=13 lun=1;
name="sg" class="scsi" target=13 lun=2;
name="sg" class="scsi" target=13 lun=3;
name="sg" class="scsi" target=13 lun=4;
name="sg" class="scsi" target=14 lun=0;
name="sg" class="scsi" target=14 lun=1;
name="sg" class="scsi" target=14 lun=2;
name="sg" class="scsi" target=14 lun=3;
name="sg" class="scsi" target=14 lun=4;
name="sg" class="scsi" target=15 lun=0;
name="sg" class="scsi" target=15 lun=1;
name="sg" class="scsi" target=15 lun=2;
name="sg" class="scsi" target=15 lun=3;
name="sg" class="scsi" target=15 lun=4;
```

3. Execute the `sg.build` script to create an `sg.links` file with targets 0 thru 15 (omitting target 7). Each target will have LUNs 0 thru 4.



Caution The field separator is a tab between the `addr=#,#;` and the `sg/c\N0t#l#` field.

An example of using the script and the file that is generated follow:

```
cd /usr/opensv/volmgr/bin/driver
/usr/opensv/volmgr/bin/sg.build sg.links -mt 15 -ml 4 -sl ./sg.links

type=ddi_pseudo;name=sg;addr=0,0;      sg/c\N0t010
type=ddi_pseudo;name=sg;addr=0,1;      sg/c\N0t011
type=ddi_pseudo;name=sg;addr=0,2;      sg/c\N0t012
type=ddi_pseudo;name=sg;addr=0,3;      sg/c\N0t013
type=ddi_pseudo;name=sg;addr=0,4;      sg/c\N0t014
type=ddi_pseudo;name=sg;addr=1,0;      sg/c\N0t110
type=ddi_pseudo;name=sg;addr=1,1;      sg/c\N0t111
type=ddi_pseudo;name=sg;addr=1,2;      sg/c\N0t112
type=ddi_pseudo;name=sg;addr=1,3;      sg/c\N0t113
type=ddi_pseudo;name=sg;addr=1,4;      sg/c\N0t114
type=ddi_pseudo;name=sg;addr=2,0;      sg/c\N0t210
type=ddi_pseudo;name=sg;addr=2,1;      sg/c\N0t211
type=ddi_pseudo;name=sg;addr=2,2;      sg/c\N0t212
type=ddi_pseudo;name=sg;addr=2,3;      sg/c\N0t213
type=ddi_pseudo;name=sg;addr=2,4;      sg/c\N0t214
.
.
.
```

4. Edit `/usr/opensv/volmgr/bin/sgscan` to remove the zero preceding the last * in the for statement, to allow all LUNs to print.

Change the following line:

```
for i in /dev/sg/c*t*[dl]0*; do
```

To the following line:

```
for i in /dev/sg/c*t*[dl]*; do
```

5. Install or re-install the sg driver `./install.sg`.
Refer to “Installing SCSI Pass-Through Drivers” on page 45 for more details.
6. Run the `sgscan` command to display the `/dev/sg/` *device numbers* and SCSI inquiry strings.
7. If you are installing an optical library, run `scsi_command -d /dev/sg/sg_id -inquiry` to verify each optical target.



Then run `scsi_command -d /dev/sg/sg_id -disk` to change the eeprom for the optical drive from optical to disk, so the Solaris `sd` driver can communicate with the drive.

8. Edit the `/kernel/drv/sd.conf` file. Copy the target entry lines that you need and substitute the new lun # as needed.

```
#
# Copyright (c) 1992, by Sun Microsystems, Inc.
#
#ident  "@(#)sd.conf      1.8      93/05/03 SMI"
name="sd" class="scsi"
        target=0 lun=0;
name="sd" class="scsi"
        target=1 lun=0;
name="sd" class="scsi"
        target=2 lun=0;
name="sd" class="scsi"
        target=3 lun=0;
name="sd" class="scsi"
        target=4 lun=0;
name="sd" class="scsi"
        target=4 lun=1;
name="sd" class="scsi"
        target=4 lun=2;
name="sd" class="scsi"
        target=4 lun=3;
.
.
.
```

9. Reboot the system using the `-r` option to reconfigure the devices and you should see the `sd` driver address the drives during the boot process. (The `sgscan all` command displays them.)

Adding HP 4-mm Drives and HP DAT Autoloaders

Read this section if you plan to use Hewlett-Packard (HP) 4-mm DAT tape drives or HP C1560B DAT Autoloaders.

Note Other switch settings may work, but these settings were functional during testing with an HP35480 drive and HP C1560B Autoloader.

Use the following hardware (tape drive) switch settings on HP35480 4-mm (DAT) drives:



On=1, Off=0

Switch	Setting
1	1
2	1
3	1
4	1
5	1
6	1
7	1
8	1

Use the following settings on HP C1533A drives in an HP C1560B DAT Autoloader:

Switch	Setting
1	1
2	1
3	1
4	1
5	1
6	1
7	0
8	0

Adding Sony AIT or AIT-2 Drives

Read this section if you plan to use Sony AIT or AIT-2 tape drives in your configuration.

No Rewind Device Files

When adding tape drives to a Media Manager configuration, you need only specify a no rewind on close device path. To display the no rewind device files that are configured on your system, use the `sgscan` command with the `tape` parameter.

```
# /usr/opensv/volmgr/bin/sgscan tape
/dev/sg/c2t5l0: Tape (/dev/rmt/6): "SONY SDX-300C"
```



Using the `sgscan` output, if the drive is connected to SCSI ID 5 of adapter 2, the device path you use follows:

```
/dev/rmt/6cbn
```

Dip Switch Settings

Sony drives have 8 dip switches located on the bottom of the drive. It is important to set these switches correctly, even if it means taking the drives out of robots and checking them.

Some robots (for example, SpectraLogic) provide a way to set the drive switches from the robot itself. For SpectraLogic robots, it doesn't matter what the drive switches are. The Treefrog (215) robot has a dial in the back to set the appropriate OS. The Bullfrog (10000) robot has a means of setting the OS through the touch screen.

Depending on the version of the AIT drive, drives are shipped from Sony with one of the following two settings:

Note Robot vendors and hardware resellers may change the default drive switch settings.

On=1 and Off=0.

Switch	Setting
1	0
2	0
3	0
4	0
5	0
6	0
7	1
8	1

Switch	Setting
1	0
2	0
3	0
4	0

Switch	Setting
5	1
6	0
7	1
8	0

Switches 1 thru 4 are critical for setting the OS type. Usually, switches 5 - 8 can be left set at the default. For Solaris, use the following switch settings:

Switch	Setting
1	0
2	1
3	0
4	1

You can use the following command to determine the current dip switch settings without removing the drives and checking them:

```
/usr/opensv/volmgr/bin/scsi_command -d /dev/sg/c2t5l0 -ait
```

The output is as follows:

```
Physical AIT drive switch setting = 0x0 (Default configuration)  
Logical AIT drive switch setting = 0xa (SUN - SunOS and Solaris)
```



Configuring HP Optical Disk Drives

To use standalone Hewlett-Packard optical-disk drives, the `sg` driver must be installed (see “Installing SCSI Pass-Through Drivers” on page 45). The system must also be configured to recognize the optical drives as disk drives at system boot time.

If you are adding Hewlett-Packard 1.2 gigabyte or equivalent model magneto-optical disk drives, the system may not recognize these as disk drives and thus cannot use them. See “Setting the HP Optical Drive Type in Nonvolatile Memory” on page 67 for more information.

Creating Device Files

When adding optical disk drives to a Media Manager configuration, you must specify the following device paths:

- ◆ Volume header disk device path (partition 0).
- ◆ Character device path (partition 6).

To display the disk device files that are configured on your system, use the `sgscan` command with the `disk` parameter:

```
# /usr/opensv/volmgr/bin/sgscan disk
/dev/sg/c0t0l0: (/dev/rdisk/c0t0d0): "IBM      DCAS32160SUN2.1G"
/dev/sg/c0t1l0: (/dev/rdisk/c0t1d0): "HP      C1113F"
/dev/sg/c0t2l0: (/dev/rdisk/c0t2d0): "HP      C1113F"
/dev/sg/c0t5l0: (/dev/rdisk/c0t5d0): "HP      C1160F"
/dev/sg/clt0l0: (/dev/rdisk/clt0d0): "SONY    SMO-F541"
/dev/sg/clt1l0: (/dev/rdisk/clt1d0): "SONY    SMO-F541"
/dev/sg/clt2l0: (/dev/rdisk/clt2d0): "SEAGATE ST11200N SUN1.05"
```

Note All device types can be displayed using the `all` parameter when executing `sgscan`. This command can be helpful for associating disk devices with other SCSI devices that may be configured on the same adapter.

Usage: `sgscan [all|basic|changer|disk|tape] [conf] [-v]`

Optical disk device files are located in the `/dev` directory and have the following formats:

`/dev/rdisk/cAdapterTargetd0s0` (volume header device)

`/dev/rdisk/cAdapterTargetd0s6` (character device)

Where:

Adapter is the logical adapter number as shown in the `sgscan` output.

Target is the SCSI ID.

Examples of Optical Disk Device Files

Example 1

Using the above sample `sgscan` output, if the desired optical disk drive connects to SCSI ID 5 of adapter card 0, you would use the following device paths:

```
/dev/rdisk/c0t5d0s0 (volume header device)
```

```
/dev/rdisk/c0t5d0s6 (character device)
```

Example 2

Using the above sample `sgscan` output, if the desired optical disk drive connects to SCSI ID 0 of S bus 1 adapter card 1, you would use the following device paths:

```
/dev/rdisk/c1t0d0s0 (volume header device)
```

```
/dev/rdisk/c1t0d0s6 (character device)
```

Setting the HP Optical Drive Type in Nonvolatile Memory

To use HP optical disk drives, the system must recognize the optical drives as disk drives at system boot time. If you are adding Hewlett-Packard 1.2 gigabyte or equivalent model magneto-optical disk drives, the system may not recognize these as disk drives. The following steps explain how to correct this condition:

1. Install the `sg` loadable driver if it is not already installed. See “Installing SCSI Pass-Through Drivers” on page 45 for information on how to install this driver.
2. Use the `scsi_command` command to change the device type (stored in the drive’s nonvolatile memory) from optical memory to disk. The format of the command follows.

```
/user/opensv/volmgr/bin/scsi_command -d /dev/sg/sg_id -disk
```

Where *sg_id* is the logical identifier assigned to the optical disk drive for use by the `sg` driver. See “Configuring SCSI Robotic Controls” on page 49 for information on determining the logical identifier.

Note The `/dev` path allows Media Manager to access the optical disk drive through the `sg` driver. This is an exception to the usual case where Media Manager uses the `sg` driver to access robotic controls. Therefore, be sure to specify the SCSI ID for the optical disk drive, *not* the SCSI ID for the robotic control.



3. Reboot the system with the reconfigure option (`boot -r` or `reboot -- -r`) to allow the drive to be recognized as a disk drive by the kernel's SCSI disk (`sd`) driver during system initialization.

Command Summary

The following is a summary of commands that may be useful when configuring devices. See the procedures in this chapter for examples of their usage.

```
/usr/sbin/modinfo | grep sg
```

Displays whether or not the `sg` driver is installed.

```
/usr/opensv/volmgr/bin/driver/sg.install
```

Installs the `sg` driver for the first time.

```
/usr/sbin/rem_drv sg
```

Uninstalls `sg` driver.

```
/usr/opensv/volmgr/bin/sg.build all
```

```
-mt max_target
```

```
-ml max_lun
```

```
-st st.conf_file
```

```
-sc sc.conf_file
```

```
-sl sg.links_file
```

Updates `st.conf`, `sg.conf`, and `sg.links`, and generates wide SCSI IDs with multiple LUNs.

```
/usr/opensv/volmgr/bin/sg.build st.conf
```

```
-mt max_target
```

```
-ml max_lun
```

```
-st st.conf_file
```

Updates `st.conf` and generates wide SCSI IDs with multiple LUNs.

```
/usr/opensv/volmgr/bin/sg.build sg.conf
```

```
-mt max_target
```

```
-ml max_lun
```

```
-sc sg.conf_file
```

Updates `sg.conf` and generates wide SCSI IDs with multiple LUNs.

```
/usr/opensv/volmgr/bin/sg.build sg.links
```

```
-mt max_target
```

```
-ml max_lun
```



`-s1 sg.links_file`

Updates `sg.links` and generates wide SCSI IDs with multiple LUNs.

`/usr/opensv/volmgr/bin/sgscan all`

Scans all connected devices with a SCSI inquiry and provides correlation between physical and logical devices using all device files in `/dev/sg`.

`/usr/opensv/volmgr/bin/scsi_command -d /dev/sg/sg_id -disk`

Changes the device type (stored in the drive's nonvolatile memory) from optical memory to disk.

Where *sg_id* is the logical identifier assigned to the optical disk drive for use by the `sg` driver. See "Configuring SCSI Robotic Controls" on page 49 for information on determining the logical identifier.

`boot -r` or `reboot -- -r`

Reboot the system with the reconfigure option (`-r`) to allow a drive to be recognized as a disk drive during system initialization by the kernel's SCSI disk (`sd`) driver.

`/usr/opensv/volmgr/bin/vmconf`

Provided with Media Manager, this script does device setup in less complex configurations.



IBM RS6000 Running AIX

4.2.1/4.3/4.3.1/4.3.2/4.3.3

4

This chapter describes how to configure devices for use with Media Manager on an IBM RS6000 system. Configure drives and robots using one of the available Media Manager administrative interfaces.

The topics covered are as follows:

- ◆ Before You Start
- ◆ RS6000 AIX Adapter Number Conventions
- ◆ Installing the SCSI Pass-Through Driver
- ◆ Configuring Robotic Controls
- ◆ Configuring Tape Drives
- ◆ Configuring Optical Disk Drives
- ◆ Command Summary

Before You Start

Observe the following points when performing the configurations described in this chapter:

- ◆ Attach all peripherals and reboot the system before configuring devices. Many of these steps may be accomplished using `smit` (the System Management Interface Tool). See `smit(1)` for more information.
- ◆ To obtain error and debugging information about devices and robotic software daemons, the `syslogd` daemon must be configured to be in effect. See `syslogd(1)` for more information.



RS6000 AIX Adapter Number Conventions

The location code for an adapter consists of two pairs of digits with the format *AA-BB*; where *AA* identifies the location code of the drawer containing the adapter card and *BB* identifies both the I/O bus and slot containing the card.

A value of 00 for *AA* means that the adapter card is located in the CPU drawer or system unit, depending on the type of system. Any other value for *AA* indicates that the card is located in an I/O expansion drawer; in which case the value identifies the I/O bus and slot number in the CPU drawer that contains the asynchronous expansion adapter. The first digit identifies the I/O bus with 0 corresponding to the standard I/O bus and 1 corresponding to the optional I/O bus. The second digit identifies the slot on the indicated I/O bus.

The first digit of *BB* identifies the I/O bus containing the adapter card. If the card is in the CPU drawer or system unit, this digit will be 0 for the standard I/O bus or 1 for the optional I/O bus. If the card is in an I/O expansion drawer, this digit is 0. The second digit identifies the slot number on the indicated I/O bus (or slot number in the I/O expansion drawer) that contains the card.

A location code of 00-00 is used to identify the Standard I/O Planar.

Examples

00-05 identifies an adapter card that is in slot 5 of the standard I/O bus in either the CPU drawer or system unit, depending on the type of system.

00-12 identifies an adapter card that is in slot 2 of the optional I/O bus in the CPU drawer.

18-05 identifies an adapter card located in slot 5 of an I/O expansion drawer. The drawer is the one connected to the asynchronous expansion adapter located in slot 8 of the optional I/O bus in the CPU drawer.

Installing the SCSI Pass-Through Driver

Read this topic if you plan to use SCSI-controlled robotic peripherals or Hewlett-Packard 1.2 gigabyte or equivalent model magneto-optical disk drives.

When communicating with SCSI-controlled robotic peripherals on an IBM RS6000 system, Media Manager software utilizes a SCSI pass-through driver called `ovpass`. This driver is also used to set the optical drive type, as documented in “Setting an HP Optical Drive Type in Nonvolatile Memory” on page 89. This driver is not required if the only peripheral is the IBM 3590 B11 tape stacker.

To install the `ovpass` driver for the first time, enter the following command:

```
/usr/opensv/volmgr/bin/driver/install_ovpass
```

To ensure the driver device files are accessible after each system boot, the following command should be placed in the system startup script:

```
/usr/opensv/volmgr/bin/driver/mkdev_ovpass
```

Note The `mkdev_ovpass` command is called by the `rc.veritas.aix` script. This script is found in the `/usr/opensv/netbackup/bin/goodies` directory. You can call this script at system boot time, by following the instructions in the Modify Scripts section of the NetBackup DataCenter Installation Guide for UNIX.

To uninstall the `ovpass` driver at a later time, enter the following command:

```
/usr/opensv/volmgr/bin/driver/remove_ovpass
```

Note You cannot use `smit` to configure `ovpass` device files.



Configuring Robotic Controls

Robots are controlled through a SCSI or a network connection.

Configuration for network controlled robotic libraries is discussed in the appendices of the Media Manager system administrator's guide for UNIX.

SCSI control is covered in the following section.

Configuring SCSI Robotic Controls

Read this topic if you plan to use a robotic storage device that is controlled through a SCSI robotic connection. Supported SCSI robots include the following. See the NetBackup release notes for a list of the vendor models associated with the following robot types.

- ◆ ODL - Optical Disk Library
- ◆ TL4 - Tape Library 4MM
- ◆ TL8 - Tape Library 8MM
- ◆ TLD - Tape Library DLT
- ◆ TS8 - Tape Stacker 8MM
- ◆ TSD - Tape Stacker DLT
- ◆ TSH - Tape Stacker Half-inch

Perform the following steps to check for and create the necessary device files.

1. Install the SCSI pass-through driver as explained in “Installing the SCSI Pass-Through Driver” on page 73.
2. Display which SCSI controllers are physically available on your machine by using the following command:

```
/usr/sbin/lsdev -C -c adapter | grep SCSI
```

In the following sample output, SCSI controller 1 (01) has been assigned the logical identifier scsi0:

```
scsi0 Available 00-01 SCSI I/O Controller
```

3. Display the SCSI device files that have already been created by using the following command:

```
/usr/sbin/lsdev -C -s scsi
```

The example output follows:

```
hdisk0 Available 00-01-00-0,0 400 MB SCSI Disk Drive
hdisk1 Available 00-01-00-1,0 400 MB SCSI Disk Drive
```

```
rmt0    Available 00-01-00-3,0 Other SCSI Tape Drive
```

This output shows that two disk drives and one tape drive are configured as follows:

- ◆ `hdisk0` is a disk drive at controller 1 (01) and SCSI id 0 (0,0)
- ◆ `hdisk1` is a disk drive at controller 1 (01) and SCSI id 1 (1,0)
- ◆ `rmt0` is a tape drive at controller 1 (01) and SCSI id 3 (3,0)

If the device files for the SCSI robotic control already exist, they appear in the `lsdev` output as `ovpass0`, `ovpass1`, etc. The output for this example does not show any `ovpass` files so you would have to create them as explained in the next step.

4. If the device files for the desired robotic control SCSI id do not exist, create them with the following command:

```
mkdev -c media_changer -s scsi -t ovpass -p ctrl -w id,lun
```

Where:

ctrl is the logical identifier of the drive's SCSI adaptor, such as `scsi0`, `scsi1` or `vscsi1`.

id is the SCSI id of the robotic connection.

lun is the logical unit number of the robotic connection.

5. You can display the newly created logical identifier for the device by using the following command:

```
/usr/sbin/lsdev -C -s scsi
```

In this example output, `ovpass0` is a SCSI robotic control device file.

```
hdisk0  Available 00-01-00-0,0 400 MB SCSI Disk Drive
hdisk1  Available 00-01-00-1,0 400 MB SCSI Disk Drive
rmt0    Available 00-01-00-3,0 Other SCSI Tape Drive
ovpass0 Available 00-01-5,0   VERITAS Media Changer
```

The path name for these types of device files has the following form:

```
/dev/ovpass_id
```

Where *ovpass_id* is the logical identifier assigned to the device.

In this example, you use the following device file path:

```
/dev/ovpass0
```



Examples of SCSI Robotic Control Device Files

Example 1

Assume this robot is not a TSD or an HP C1560B. The `ovpass` driver has been installed and the desired SCSI robotic controller is controller 1 at SCSI ID 5, but the device files do not exist.

1. Determine the logical identifier for the SCSI controller as follows:

```
/usr/sbin/lsdev -C -c adapter | grep SCSI
```

The output shows that `scsi0` is the logical name for SCSI controller 1.

```
scsi0 Available 00-01 SCSI I/O Controller
```

2. Check if the device files exist for `ovpass` at SCSI ID 5.

```
/usr/sbin/lsdev -C -s scsi
```

The output shows that the device files exist for tape and disk, but not for the SCSI robotic control at controller 1 (`scsi0`) and SCSI ID 5 (5,0).

```
hdisk0 Available 00-01-00-0,0 400 MB SCSI Disk Drive
rmt0 Available 00-01-00-3,0 Other SCSI Tape Drive
```

3. Create the device files by using the following command:

```
mkdev -c media_changer -t ovpass -s scsi -p scsi0 -w 5,0
```

4. Display the device files by issuing the `lsdev` command:

```
/usr/sbin/lsdev -C -s scsi
hdisk0 Available 00-01-00-0,0 400 MB SCSI Disk Drive
hdisk1 Available 00-01-00-1,0 400 MB SCSI Disk Drive
rmt0 Available 00-01-00-3,0 Other SCSI Tape Drive
ovpass0 Available 00-01-5,0 VERITAS Media Changer
```

For this example, use the following device file path to configure the SCSI robot control connected to controller 1 and SCSI ID 5:

```
/dev/ovpass0
```

Example 2

Assume the robot is a DLT2700/DLT4700 (TSD) or an HP C1560B (TL4). The `ovpass` driver has been installed, but the device files for SCSI robotic control at controller 1 with SCSI ID 3 and logical unit number 1 do not exist.

1. Determine the logical identifier for the SCSI controller:

```
/usr/sbin/lsdev -C -c adapter | grep -i SCSI
```

The following output shows that `scsi0` is the logical name for SCSI controller 1:

```
scsi0 Available 00-01 SCSI I/O Controller
```

2. Check if the device files exist for `ovpass` at SCSI ID 5.

```
/usr/sbin/lsdev -C -s scsi
```

The following output shows that the device files exist for tape and disk, but not for the SCSI robotic control at controller 1 (`scsi0`), SCSI ID 3, and logical unit number 1 (3,1):

```
hdisk0 Available 00-01-00-0,0 400 MB SCSI Disk Drive
rmt0 Available 00-01-00-3,0 Other SCSI Tape Drive
```

3. The device files can now be created using the following command:

```
mkdev -c media_changer -t ovpass -s scsi -p scsi0 -w 3,1
```

4. Display the device files by issuing the `lsdev` command:

```
/usr/sbin/lsdev -C -s scsi
hdisk0 Available 00-01-00-0,0 400 MB SCSI Disk Drive
hdisk1 Available 00-01-00-1,0 400 MB SCSI Disk Drive
rmt0 Available 00-01-00-3,0 Other SCSI Tape Drive
ovpass0 Available 00-01-3,1 VERITAS Media Changer
```

For this example, the device file to use for the TSD SCSI robotic control connected at controller 1 with SCSI ID 3 and logical unit number 1 would be:

```
/dev/ovpass0
```

Example 3

Assume the robot is an STK 9710 connected to a F/W Differential SCSI board and the pass-through driver has been installed. Assume the drives are at SCSI ID's 4 and 5, and the robotics is at SCSI ID 6.

1. Determine the correct `scsi` controller.

```
lsdev -C | grep scsi
scsi0 Available 00-02 SCSI I/O Controller
ascsi0 Available 00-04 Wide SCSI I/O Controller Adapter
vscsi0 Available 00-04-0,0 SCSI I/O Controller Protocol Device
vscsi1 Available 00-04-0,1 SCSI I/O Controller Protocol Device
```

```
lsdev -C -c tape
```



```
.
rmt2 Available 00-04-01-4,0 Other SCSI Tape Drive
rmt3 Available 00-04-01-5,0 Other SCSI Tape Drive
.
.
```

2. The drives are on Adapter 00-04-01. Therefore, `vscsil` is the correct adapter for making the `ovpass` device file as follows:

```
mkdev -c media_changer -t ovpass -s scsi -p vscsil -w 6,0
```

Note Never use the `ascsi` adapter name.

Example 4 (IBM 3570 B-series Stackers)

If there is one drive in the stacker, the robotic control is LUN 1 of the drive's SCSI ID. If there are two drives in the stacker, the robotic control is LUN 1 of the Drive 1 SCSI ID. The SCSI IDs can be set or viewed using the front panel on the stacker. The robotic control for the IBM 3570 B01/B02 is TLD, so if there are two drives they may be connected to different host systems.

If this is the case, the host system which is connected to Drive 1 must also have the robotic control. Also, the library should be in RANDOM mode and BASE configuration. See the operator's guide supplied with the unit for information on setting library mode and configuration.

Assume a configuration as follows:

```
lsdev -C -c tape
rmt0 Available 00-02-01-5,0 Other SCSI Tape Drive
rmt0 Available 00-02-01-6,0 Other SCSI Tape Drive
```

If drive 1 is SCSI ID 5, the robotic control for the stacker will be LUN 1 of this SCSI ID. Assuming `vscsil` is the correct adapter, make the `passthru` device (`ovpass`) as follows:

```
mkdev -c media_changer -t ovpass -s scsi -p vscsil -w 5,1
```

Configuring IBM 3590 Stacker Robotic Controls

Read this topic if you plan to use a Tape Stacker Half-inch (TSH) robotic storage device. See the NetBackup release notes for the vendor model associated with the TSH robot type.

Perform the following steps to check for and create the necessary device files:

1. Display the SCSI tape devices configured in the system using the following command:

```
/usr/sbin/lsdev -C -c tape
rmt0 Defined 00-02-00-4,0 Other SCSI Tape Drive
```

rmt1 Available 00-08-00-6,0 2.3 GB 8mm Tape Drive

.

rmt12 Available 00-04-01-6,0 IBM 3590 Tape Drive and Medium Changer

- 2.** The SCSI robotic path for the IBM 3590 is the same as the no rewind on close tape path. When configuring the TSH SCSI robotic path, the robotic control path for the above 3590 would be `/dev/rmt12.1`. The tape drive path would also be `/dev/rmt12.1`.



Configuring Tape Drives

Read the topics in this section if you plan to use tape drives in your configuration.

Configuring Non-QIC Tape Drives

Caution If you do not configure non-QIC tape drives as variable-length-block devices, NetBackup is able to write data, but may not be able to read it.

As shown by the examples in this section, you must configure non-QIC tape drives as variable-length-block devices if they will be used by Media Manager. Otherwise, NetBackup is able to write data but may not be able to read it correctly. During a read, you may see a “not in tar format” error.

The terms *variable length block* or *fixed length block* refers to the behavior of reads and writes and the way the kernel packs physical tape records into logical tape records for an application. Variable-mode devices allow more flexibility in reading previously written tapes. Many tape devices can be accessed in either mode. NetBackup assumes variable length for non-QIC drives. For more information, see `chdev(1)`, `smit(1)` and the system management guide. The `smit` application is the most convenient way to change from fixed to variable-length-block devices.

Ensure that the device being used is configured for variable mode by using the `chdev` command as follows:

```
/usr/sbin/chdev -l dev -a block_size=0
```

Where *dev* is the logical identifier for the drive (for example: `rmt0` or `rmt1`).

Using Extended-File Marks for Drives

You must configure tape drives to use extended file marks, if those tape drives are capable of supporting them (for example, 8-mm drives). See `chdev(1)` and `smit(1)` for additional information. Otherwise, NetBackup may not be able to use those drives.

Ensure that the device being used is configured for extended file marks as required by Media Manager by using the `chdev` command as follows:

```
/usr/sbin/chdev -l dev -a extfm=yes
```

Where *dev* is the logical identifier for the drive (for example: `rmt0` or `rmt1`).

Fast-Tape Positioning (`locate-block`)

For DLT, Exabyte, and half-inch cartridge tape drives, Media Manager supports the SCSI `locate-block` command for positioning tape to a specific block. This improves tape-positioning greatly over what can be obtained with the alternative.

Media Manager uses the `locate-block` command by default unless you disable it by executing:

```
touch /usr/opensv/volmgr/database/NO_LOCATEBLOCK
```

With `locate-block` positioning disabled, NetBackup uses the `forward-space-file/record` method.

Creating No Rewind Device Files

When adding tape drives to a Media Manager configuration, you need only specify a no rewind on close device path. These SCSI device files are in the `/dev` directory and have the following format:

```
/dev/rmtid.1
```

Where *id* is the logical identifier assigned to the device by the system.

Perform the following steps to check for and create the necessary device files:

1. Display which SCSI controllers are physically available by using the `lsdev` command as follows:

```
/usr/sbin/lsdev -C -c adapter | grep SCSI
```

This sample output shows that SCSI controller 1 (00-01) has been assigned the logical identifier `scsi0`.

```
scsi0 Available 00-01 SCSI I/O Controller
```

2. Display the SCSI device files that have already been created by using the `lsdev` command.

```
/usr/sbin/lsdev -C -s scsi
hdisk0 Available 00-01-00-0,0 400 MB SCSI Disk Drive
hdisk1 Available 00-01-00-1,0 400 MB SCSI Disk Drive
rmt0 Available 00-01-00-3,0 Other SCSI Tape Drive
```

This example output shows that two disk drives and one tape drive exist as follows:

- ◆ `hdisk0` is a disk drive at controller 1 (00-01) and SCSI id 0 (0, 0)
- ◆ `hdisk1` is a disk drive at controller 1 (00-01) and SCSI id 1 (1, 0)
- ◆ `rmt0` is a tape drive at controller 1 (00-01) and SCSI id 3 (3, 0)

If the device files for the SCSI tape drives exist, they appear in the output as `rmt0`, `rmt1`, and so on. The above example output shows `rmt0`.

For `rmt0` and `rmt1`, you would use the following no rewind on close device files:

```
/dev/rmt0.1
/dev/rmt1.1
```



3. If the device files for the desired tape drive's SCSI ID do not exist, create them using the following `mkdev` command:

```
/usr/sbin/mkdev -c tape -s scsi -t ost -p contr -w id,lun
```

Where:

contr is the logical identifier of the SCSI adapter for the device, such as `scsi0` or `scsi1`.

id is the SCSI ID of the drive connection.

lun is the logical unit number of the drive connection.

An example for an 8-mm drive connected to controller 0 and SCSI ID 5 follows:

```
mkdev -c tape -s scsi -t ost -p scsi0 -w 5,0
```

You can display the newly created logical identifier for the device by using the `lsdev` command.

```
/usr/sbin/lsdev -C -s scsi
hdisk0 Available 00-01-00-0,0 400 MB SCSI Disk Drive
hdisk1 Available 00-01-00-1,0 400 MB SCSI Disk Drive
rmt0 Available 00-01-00-3,0 Other SCSI Tape Drive
rmt1 Available 00-01-00-5,0 Other SCSI Tape Drive
ovpass0 Available 00-01-6,0 VERITAS Media Changer
```

The `rmt1` device file has been created.

4. Ensure that the device being used is configured for variable-mode and extended file marks as required by Media Manager by using the `chdev` command as follows:

```
/usr/sbin/chdev -l dev -a block_size=0
/usr/sbin/chdev -l dev -a extfm=yes
```

Where *dev* is the logical identifier for the drive (for example: `rmt0` or `rmt1`).

No Rewind Device File Example

Assume the device files for the desired SCSI 8-mm tape drive (controller 1, SCSI ID 5) do not exist.

1. Determine the logical identifier for the SCSI controller as follows:

```
/usr/sbin/lsdev -C -c adapter | grep SCSI
```

The following output shows that `scsi0` is the logical name for SCSI controller 1:

```
scsi0 Available 00-01 SCSI I/O Controller
```

2. Check if the device files exist for any device at SCSI ID 5.

```
/usr/sbin/lsdev -C -s scsi
```

The following output shows that some device files exist for tape and disk, but not for the 8-mm tape drive at controller 1 (scsi0) and SCSI ID 5 (5,0):

```
hdisk0 Available 00-01-00-0,0 400 MB SCSI Disk Drive
hdisk1 Available 00-01-00-1,0 400 MB SCSI Disk Drive
rmt0 Available 00-01-00-3,0 Other SCSI Tape Drive
```

3. Create the desired device files by using the following command:

```
mkdev -c tape -t ost -s scsi -p scsi0 -w 5,0
```

4. Display the device files by issuing the following `lsdev` command:

```
/usr/sbin/lsdev -C -s scsi
hdisk0 Available 00-01-00-0,0 400 MB SCSI Disk Drive
hdisk1 Available 00-01-00-1,0 400 MB SCSI Disk Drive
rmt0 Available 00-01-00-3,0 Other SCSI Tape Drive
rmt1 Available 00-01-00-5,0 Other SCSI Tape Drive
```

5. To ensure that the tape device is configured for variable-mode and extended file marks, use the following commands:

```
chdev -l rmt1 -a block_size=0
chdev -l rmt1 -a extfm=yes
```

Enter the following device file path to configure the 8-mm drive connected to controller 1 and SCSI ID 5:

```
/dev/rmt1.1
```

Using Multiple Tape Densities

After creating the necessary device files for your tape drives you may want to use nondefault densities on drives that support them (for example, Exabyte 8500C tape drives).

There are two configurable densities available for all tape drives, although not all tape drives support multiple densities. The default density for both density setting 1 and density setting 2 is 0, which means maximum density.

To modify either of the density settings, you can use `smit(1)` or commands similar to the following:

```
chdev -l tapedev -a density_set_1=density
chdev -l tapedev -a density_set_2=density
```

Where:



tapedev is the logical identifier for the drive, such as `rmt0` or `rmt1`.

density is the decimal number representing the desired density.

To use density setting 1, use the following no rewind on close device file:

```
/dev/rmt*.1
```

To use density setting 2, use the following no rewind on close device file:

```
/dev/rmt*.5
```

Adding HP 4-mm Drives and HP C1560B DAT Autoloaders

To support HP (Hewlett-Packard) 4-mm DAT tape drives and HP C1560B DAT Autoloaders use the following hardware (tape drive) switch settings. Other combinations may work, but these are the settings that were functional during testing with an HP 35480 tape drive and HP C1560B DAT Autoloader.

On=1, Off=0

Switch	Setting
1	1
2	1
3	1
4	1
5	1
6	1
7	0
8	0

Adding Sony AIT Drives

Read this section if you plan to use Sony AIT tape drives in your configuration.

No Rewind Device Files

When adding tape drives to a Media Manager configuration, you need only specify a no rewind on close device path. To display the no rewind device files that are configured on your system, use the `lsdev` command as follows:

```
/usr/sbin/lsdev -C -s scsi  
rmt6 Available 00-03-01-6,0 Other SCSI Tape Drive
```

Using the `lsdev` output, if the drive is connected to SCSI ID 6 of adapter 3, the device path you use follows:

```
/dev/rmt0.1
```

Dip Switch Settings

Sony AIT drives have 8 dip switches located on the bottom of the drive. It is important to set these switches correctly, even if it means taking the drives out of robots and checking them.

Some robots (for example, SpectraLogic) provide a way to set the drive switches from the robot itself. For SpectraLogic robots, it doesn't matter what the drive switches are. The Treefrog (215) robot has a dial in the back to set the appropriate OS. The Bullfrog (10000) robot has a means of setting the OS through the touchscreen.

Depending on the version of the AIT drive, drives are shipped from Sony with one of two switch settings, as shown in the following tables:

Note Robot vendors and hardware resellers may change the default drive switch settings.

On=1 and Off=0.

Switch	Setting
1	0
2	0
3	0
4	0
5	0
6	0
7	1
8	1

Switch	Setting
1	0
2	0
3	0
4	0



Switch	Setting
5	1
6	0
7	1
8	0

Switches 1 thru 4 are critical for setting the OS type. Usually, switches 5 thru 8 can be left set at the default. For AIX, use the following switch settings:

Switch	Setting
1	1
2	0
3	0
4	0

You can use the following command to determine the correct dip switch settings without removing the drives and checking them:

```
/usr/opensv/volmgr/bin/scsi_command -d /dev/rmt0.1 -ait
```

The output is as follows:

```
Physical AIT drive switch setting = 0x1 (IBM RS6000 - AIX - disconnect enabled)
```

```
Logical AIT drive switch setting = 0xff (Not set, physical setting in effect)
```

The above example was an AIT drive in a ADIC Grau library. The drive was removed and set to the AIX switch settings.

Configuring Optical Disk Drives

When adding optical disk drives to a Media Manager configuration, you specify only a character device path. Optical disk character device files are located in the `/dev` directory and have the following format:

```
/dev/rhdiskid
```

Where *id* is the logical identifier assigned to the device by the system.

Note To use Hewlett-Packard optical disk drives, the system must recognize the optical drives as disk drives at system boot time. If you are adding Hewlett-Packard 1.2 gigabyte or equivalent model magneto-optical disk drives to an AIX system, the system may not recognize them as disk drives, and thus cannot use them. See “Setting an HP Optical Drive Type in Nonvolatile Memory” on page 89 for information on correcting this condition.

Creating Device Files

Perform the following steps to check for and create the necessary device files.

1. Display which SCSI controllers are physically available on your machine by using the following `lsdev` command:

```
/usr/sbin/lsdev -C -c adapter | grep SCSI
```

This sample output shows that SCSI controller 1 (00-01) has been assigned the logical identifier `scsi0`.

```
scsi0 Available 00-01 SCSI I/O Controller
```

2. Display the SCSI device files that have already been created by using the following `lsdev` command:

```
/usr/sbin/lsdev -C -s scsi
```

The following example output shows that two disk drives and one tape drive exist:

- ◆ `hdisk0` is a disk drive at controller 1 (00-01) and SCSI id 0 (0,0)
- ◆ `hdisk1` is a disk drive at controller 1 (00-01) and SCSI id 1 (1,0)
- ◆ `rmt0` is a tape drive at controller 1 (00-01) and SCSI id 3 (3,0)

If the device files for the SCSI optical disk drives exist, they show up in the output as `hdisk0`, `hdisk1`, and so on.

```
hdisk0 Available 00-01-00-0,0 400 MB SCSI Disk Drive
hdisk1 Available 00-01-00-1,0 400 MB SCSI Disk Drive
rmt0 Available 00-01-00-3,0 Other SCSI Tape Drive
```



For `hdisk0`, you would use the following device path:

```
/dev/rhdisk0
```

3. If the device files for the desired optical drive's SCSI ID do not exist, you can create them with the following command:

```
mkdev -c disk -s scsi -t osdisk -p controller -w id,lun
```

Where:

controller is the logical identifier of the device's SCSI adapter, such as `scsi0` or `scsil`.

id is the SCSI id of the drive connection.

lun is the logical unit number of the drive connection.

An example for an optical disk drive on controller 1 and SCSI ID 5 follows:

```
mkdev -c disk -t osdisk -s scsi -p scsi0 -w 5,0
```

4. You can display the newly created logical identifier for the device by using the following command:

```
/usr/sbin/lsdev -C -s scsi
hdisk0 Available 00-01-00-0,0 400 MB SCSI Disk Drive
hdisk1 Available 00-01-00-1,0 400 MB SCSI Disk Drive
rmt0 Available 00-01-00-3,0 Other SCSI Tape Drive
hdisk2 Available 00-01-00-5,0 Other SCSI Disk Drive
ovpass0 Available 00-01-6,0 VERITAS Media Changer
```

The device files for `hdisk2` have been created and you can now use them.

Examples of Optical Disk Device Files

Assume the device files for the desired optical disk drive (controller 1, SCSI ID 5) do not yet exist.

1. Determine the logical identifier for the SCSI controller as follows:

```
/usr/sbin/lsdev -C -c adapter | grep SCSI
```

The output shows that `scsi0` is the logical name for SCSI controller 1.

```
scsi0 Available 00-01 SCSI I/O Controller
```

2. Check to see if the device files exist for `ovpass` at SCSI ID 5.

```
/usr/sbin/lsdev -C -s scsi
```


The output shows that some device files exist for tape and disk, but not for the optical disk drive at controller 1 (scsi0) and SCSI ID 5 (5,0).

```
hdisk0 Available 00-01-00-0,0 400 MB SCSI Disk Drive
hdisk1 Available 00-01-00-1,0 400 MB SCSI Disk Drive
rmt0 Available 00-01-00-3,0 Other SCSI Tape Drive
```

3. Create device files for the optical disk drive on controller 1 at SCSI ID 5 by using the following command:

```
mkdev -c disk -t osdisk -s scsi -p scsi0 -w 5,0
```

4. Display the device files by issuing the lsdev command.

```
/usr/sbin/lsdev -C -s scsi
hdisk0 Available 00-01-00-0,0 400 MB SCSI Disk Drive
hdisk1 Available 00-01-00-1,0 400 MB SCSI Disk Drive
rmt0 Available 00-01-00-3,0 Other SCSI Tape Drive
hdisk2 Available 00-01-00-5,0 Other SCSI Disk Drive
```

5. Enter the following character device file path to configure the optical disk drive connected to controller 1 and SCSI ID 5:

```
/dev/rhdisk2
```

Setting an HP Optical Drive Type in Nonvolatile Memory

To use Hewlett-Packard optical disk drives, the system must recognize the optical drives as disk drives at system boot time. If you are adding Hewlett-Packard 1.2 gigabyte or equivalent model magneto-optical disk drives to an AIX system, the system may not recognize them as disk drives and cannot use them.

To detect whether the system recognizes the optical drives, execute the following command after system boot.

```
/usr/sbin/lsdev -C -s scsi
```

If you see the appropriate controller and SCSI ID combination for the optical drive listed as *Other SCSI Disk Drive*, the system recognizes the drive as a disk drive. If not, use the procedure that follows.

```
hdisk0 Available 00-00-0S-0,0 2.2 GB SCSI Disk Drive
rmt0 Available 00-00-0S-3,0 Other SCSI Tape Drive
omd0 Defined 00-00-0S-6,0 Other SCSI Read/Write Optical Drive
ovpass0 Available 00-00-0S-2,0 VERITAS Media Changer
```



1. Install the `ovpass` driver if it is not already installed. See “Installing the SCSI Pass-Through Driver” on page 73 for information on how to install this driver.
2. Create the `ovpass` device file for the optical drive so that the driver can be used to communicate with the optical drive.

- a. Display the SCSI device files that have already been created by using the following command:

```
/usr/sbin/lsdev -C -s scsi
```

The following example output shows that a disk drive, a tape drive, an optical drive, and SCSI robotic control are configured:

- ◆ `hdisk0` is a disk drive at controller 1 (00) and SCSI id 0 (0,0)
- ◆ `rmt0` is a tape drive at controller 1 (00) and SCSI id 3 (3,0)
- ◆ `omd0` is an optical drive at controller 1 (00) and SCSI id 6 (6,0)
- ◆ `ovpass0` refers to the SCSI robotic control for controller 1 (00) and SCSI id 2 (2,0)

```
hdisk0 Available 00-00-0S-0,0 2.2 GB SCSI Disk Drive
rmt0 Available 00-00-0S-3,0 Other SCSI Tape Drive
omd0 Defined 00-00-0S-6,0 Other SCSI Read/Write Optical
Drive
ovpass0 Available 00-00-0S-2,0 VERITAS Media Changer
```

- b. Create the device files for the optical drive by using the following command:

```
mkdev -c media_changer -s scsi -t ovpass -p ctrl -w id,lun
```

Where:

ctrl is the logical identifier of the drive’s SCSI adapter, such as `scsi0` or `scsi1`.

id is the SCSI id of the optical drive (not the robotic connection).

lun is the logical unit number of the optical drive.

For example:

```
mkdev -c media_changer -s scsi -t ovpass -p scsi 0 -w 6,0
```

Use the following command to obtain the logical identifier for the optical drive you just created:

```
/usr/sbin/lsdev -C -s scsi
```

- c. Verify the temporary `ovpass` device file created in step b.

```
/usr/opensv/volmgr/bin/scsi_command -d /dev/ovpass_id -inquiry
```

Where *ovpass_id* is the logical identifier assigned to the temporary device.

For example if the temporary *ovpass* device was *ovpass2*, enter:

```
/usr/openv/volmgr/bin/scsi_command -d /dev/ovpass2 -inquiry
```

The output shows

```
removable device type c_8h_HP
```

3. Use the following command to change the device type (stored in the drive's nonvolatile memory) from optical memory to disk. The format of the command is as follows:

```
/usr/openv/volmgr/bin/scsi_command -d /dev/ovpass_id -disk
```

Where *ovpass_id* is the logical identifier assigned to the device.

For example:

```
/usr/openv/volmgr/bin/scsi_command -d /dev/ovpass1 -disk
```

4. Remove the *ovpass* device files and the optical drive that were created by using *rmdev* command as in the following:

```
rmdev -l ovpass_id -d
rmdev -l optical_drive_id -d
```

Where:

ovpass_id is the logical identifier assigned to the device.

optical_drive_id is the optical drive identifier assigned to the optical drive.

For example:

```
rmdev -l ovpass1 -d
rmdev -l omd0 -d
```

5. Reboot the system to allow the drive to be recognized as a disk drive by the kernel's SCSI disk driver during system initialization.

The optical drive should be displayed as: *hdisk logical_number*.

Where *logical_number* is the logical number assigned to the drive by the system.

For example:

```
/usr/sbin/lsdev -C -s scsi
```

The following example output shows a disk drive, tape drive, robotic control, and optical drive:

```
hdisk0 Available 00-00-0S-0,0 2.2 GB SCSI Disk Drive
rmt0 Available 00-00-0S-3,0 Other SCSI Tape Drive
```



Configuring Optical Disk Drives

```
ovpass0 Available 00-00-0S-2,0 VERITAS Media Changer  
hdisk1 Available 00-00-0S-6,0 Other SCSI Disk Drive
```



Command Summary

The following is a summary of commands that may be useful when configuring devices. See the procedures in this chapter for examples of their usage.

```
/usr/opensv/volmgr/bin/driver/install_ovpass
```

Installs the ovpass driver for the first time.

```
/usr/opensv/volmgr/bin/driver/remove_ovpass
```

Uninstalls the ovpass driver.

```
/usr/opensv/volmgr/bin/driver/mkdev_ovpass
```

Place this command in the system startup script to ensure that the ovpass driver device files are accessible after each system boot.

```
/usr/sbin/lsdev -C -c adapter | grep type
```

Displays adapters that are physically available on your machine. *type* defines the type of adapter displayed, as follows: SCSI displays SCSI adapters.

```
/usr/sbin/lsdev -C -s filetype
```

Displays the device files that have been created, where *scsi* displays SCSI files.

```
mkdev -c media_changer -s scsi -t ovpass -p controller -w id,lun
```

Creates device files for the robotic control SCSI ID.

Where *controller* is the logical identifier of the drive SCSI adaptor (such as *scsi0* or *scsi1*), *id* is the SCSI ID of the robotic connection, and *lun* is the logical unit number of the robotic connection.

```
mkdev -c disk -s scsi -t osdisk -p controller -w id,lun
```

Creates device files for optical disk drives.

Where *controller* is the logical identifier of the drive SCSI adaptor (such as *scsi0* or *scsi1*), *id* is the SCSI ID of the robotic connection, and *lun* is the logical unit number of the robotic connection.

```
mkdev -c tape -s scsi -t ost -p controller -w id,lun
```

Creates device files for tapes.

Where *controller* is the logical identifier of the drive SCSI adaptor (such as *scsi0* or *scsi1*), *id* is the SCSI ID of the robotic connection, and *lun* is the logical unit number of the robotic connection.

```
/usr/sbin/chdev -l dev -a block_size=0
```

Configures the drive with logical identifier specified by *dev* (for example: *rmt0*) to variable mode.



```
/usr/sbin/chdev -l dev -a extfm=yes
```

Configures the drive with logical identifier specified by *dev* (for example: `rmt0`) for extended file marks.

```
/usr/opensv/volmgr/bin/scsi_command -d /dev/ovpass_id -disk
```

Used for HP optical disk drives to change the device type (stored in the drive's nonvolatile memory) from optical memory to disk.

Where *ovpass_id* is the logical identifier assigned to the device.

```
/usr/opensv/volmgr/bin/vmconf
```

Provided with Media Manager, this script does device setup in less complex configurations.

```
/etc/lstat -l dev -E -H
```

Displays device information, where *dev* is the name of the device (for example, `rmt1`).

This chapter shows how to configure devices for use with Media Manager on an HP9000-700 system. Configure drives and robots using one of the available Media Manager administrative interfaces.

The topics included are as follows:

- ◆ Before You Start
- ◆ Configuring Robotic Controls
- ◆ Configuring Tape Drives
- ◆ Configuring Optical Disk Drives
- ◆ Command Summary

Before You Start

If You Are Using NetBackup BusinessServer

Portions of this chapter include configuration topics and examples for peripherals that are not supported in NetBackup BusinessServer (for example, Configuring Optical Disk Drives).

HP-UX 10.20 is not supported in NetBackup BusinessServer.

It is important to refer to the NetBackup release notes to determine which Media Manager robot types, robots, and drives are supported for NetBackup BusinessServer, before using this chapter.



Configuring Robotic Controls

Robots are controlled through a SCSI or a network connection.

Configuration of network controlled robotic libraries (for example, ACS robots) is discussed in the appendices of the UNIX Media Manager system administrator's guide.

SCSI control is covered in the following sections.

Configuring SCSI Robotic Controls

Read this topic if you plan to use a robotic storage device that is controlled through a SCSI robotic connection. Supported SCSI robots include.

- ◆ ODL - Optical Disk Library
- ◆ TL4 - Tape Library 4MM
- ◆ TL8 - Tape Library 8MM
- ◆ TLD - Tape Library DLT
- ◆ TS8 - Tape Stacker 8MM
- ◆ TSD - Tape Stacker DLT

When communicating with SCSI-controlled robotic peripherals, Media Manager robotic software utilizes the generic (user mode) SCSI pass-through driver. You do not have to reconfigure the HP-UX kernel to use this driver on HP9000-700 systems, since the generic SCSI driver is part of basic HP-UX.

If the devices do not exist, you can create device files by using the `mknod` command as follows. See the `scsi_ctl(7)` man page for more information.

```
mkdir /dev/sctl
cd /dev/sctl

/etc/mknod ccontroller target lun c 203 0xii100
```

Where:

controller is the Instance number of the controlling bus. The Instance value is displayed in `ioscan -f` output under column I of the controller entry (ext_bus in the Class column).

target is the SCSI ID of the robotic control.

lun is the SCSI logical unit number and should be 0 for all robots, except DLT2700, DLT4700, HP C1560B, and a few other robots where *lun* must be 1.

ii are two hexadecimal digits that identify the controlling bus interface card by its Instance number (same as controller).

t is one hexadecimal digit representing the SCSI ID.

/ is one hexadecimal digit representing the SCSI LUN.

Examples of SCSI Robotic Control Device Files

Example 1

If the robotic control for an Exabyte 10i (TS8) is connected to a SCSI controller with Instance number 0 at SCSI ID 5, LUN 0 and the `/dev/sctl` files exist, the device file path to use is

```
/dev/sctl/c0t5d0
```

If the `/dev/sctl` files do not exist, the commands to create the device file are

```
cd /dev/sctl
/etc/mknod c0t5d0 c 203 0x005000
```

This creates the following device file, which you specify to Media Manager:

```
/dev/sctl/c0t5d0
```

Example 2

If the robotic control for an HP Optical Disk Library (ODL) is on an EISA adapter with Instance number 2 at SCSI ID 3, LUN 0, the commands to create the device file are

```
cd /dev/sctl
/etc/mknod c2t3d0 c 203 0x023000
```

This creates the following device file, which you specify to Media Manager:

```
/dev/sctl/c2t3d0
```

Example 3

If the robotic control for a DLT2700 or DLT4700 is connected to the controller with Instance number 0 at SCSI ID 3, LUN 1, the commands to create the device file are as follows:

```
cd /dev/sctl
/etc/mknod c0t3d1 c 203 0x003100
```

This creates the following device file, which you specify to Media Manager:

```
/dev/sctl/c0t3d1
```



Configuring Tape Drives

Using Berkeley Style Close

The examples in this section show *Berkeley-style close* for tape drives as indicated by the letter `b` after the density specification. It is mandatory to specify Berkeley-style close for tape devices that you configure under Media Manager.

The terms *Berkeley-style close* and *AT&T style close* refer to where a tape is left logically positioned after a close operation (in relation to a tape mark). One style leaves an application logically positioned before a tape mark and the other leaves it after. Applications must assume where the tape is left after a close in order to establish the correct orientation the next time they do a tape-position or read operation. Some operating systems allow tape devices to be configured with either type of close. NetBackup assumes it is using Berkeley-style close on an HP9000-700.

No Rewind Device Files

When adding tape drives to a Media Manager configuration, you need specify only a no rewind on close device path. To determine if the tape device files exist on your system, check the `/dev/rmt` directory. No rewind on close device files have the following format:

```
/dev/rmt/c $\textit{Controller}$ t $\textit{Target}$ d $\textit{Unit}$ BESTnb
```

Where:

Controller is the Instance number of the controlling bus. The Instance value is displayed in `ioscan -f` output under column I of the controller entry (`ext_bus` in the Class column).

Target is the SCSI ID of the tape drive.

Unit is the SCSI logical unit number (LUN) of the drive. This is usually 0.

If the desired tape device files do not exist, you can create them using `sam`, the system administration manager, or the `mksf (1M)` command. The following is an example using `mksf`:

```
mksf -C  $\textit{tape}$  -H  $\textit{H/W Path}$  -b BEST -u -n
```

Where:

H/W Path is the hardware path of the tape drive as specified by `ioscan`.

Examples of No Rewind Device Files

Example 1

Assume that the desired Exabyte 8505 tape drive is on the built-in SCSI interface at SCSI ID 4 and the `ioscan -f` command shows the following output:

```

Class      I H/W Path   Driver      S/W State H/W Type  Description
=====
bc         0                root        CLAIMED   BUS_NEXUS
graphics  0  1          graph3      CLAIMED   INTERFACE Graphics
ba         0  2          bus_adapter CLAIMED   BUS_NEXUS Core I/O
                                                Adapter
ext_bus   0  2/0/1      c700        CLAIMED   INTERFACE Built-in SCSI
target    2  2/0/1.4    tgt         CLAIMED   DEVICE
tape      5  2/0/1.4.0  stape       CLAIMED   DEVICE      EXABYTE EXB-8505
.
.
.

```

The Instance number for the controlling bus is 0, and the H/W path for the tape drive is 2/0/1.4.0. The command to create the device file follows:

```
mksf -C tape -H 2/0/1.4.0 -b BEST -u -n
```

This creates the following device file, which you specify to Media Manager:

```
/dev/rmt/c0t4d0BESTnb
```

You can display the device files for the drive using `ioscan -f -H 2/0/1.4.0 -n`.

```

Class I  H/W Path   Driver  S/W State  H/W Type  Description
=====
tape  5  2/0/1.4.0  stape   CLAIMED    DEVICE    EXABYTE
                                                EXB-85058SQANXR1
                                                /dev/rmt/3m          /dev/rmt/c0t4d0BESTb
                                                /dev/rmt/3mb        /dev/rmt/c0t4d0BESTn
                                                /dev/rmt/3mn        /dev/rmt/c0t4d0BESTnb
                                                /dev/rmt/3mnb
                                                /dev/rmt/c0t4d0BEST

```

Example 2

Assume that the desired DAT (4mm) tape drive with compression is on an EISA adapter at SCSI 3 and `ioscan` shows the following:

```
ioscan -f
```



Class	I	H/W Path	Driver	S/W State	H/W Type	Description
bc	0		root	CLAIMED	BUS_NEXUS	
graphics	0	0	graph3	CLAIMED	INTERFACE	Graphics
ba	0	2	bus_adapter	CLAIMED	BUS_NEXUS	Core I/O Adapter
ext_bus	0	2/0/1	c700	CLAIMED	INTERFACE	Built-in SCSI
.						
.						
ba	1	4	eisa	CLAIMED	BUS_NEXUS	EISA Adapter
ext_bus	2	4/0/1	c700	CLAIMED	INTERFACE	EISA card HWPOC80
target	9	4/0/1.3	tgt	CLAIMED	DEVICE	
tape	5	4/0/1.3.0	stape	CLAIMED	DEVICE	HP C1533A

The Instance number for the controlling bus (ext_bus) is 2 and the H/W path for the tape drive is 4/0/1.3.0. The command to create the device file for this tape drive follows:

```
mksf -C tape -H 4/0/1.3.0 -b BEST -u -n
```

This creates the following device file, which you specify to Media Manager:

```
/dev/rmt/c2t3d0BESTnb
```

Switch Settings for HP C1533A 4-mm DAT Drives

If you have standalone or robotic 4-mm drives that are model HP C1533A, you may have to change the switch settings on the bottom of the drive. This drive comes in the HP C1560B (48AL) DAT Autoloader.

If the C1533A drive or HP C1560B autoloader was purchased from Hewlett Packard, the default switch settings should work. These default settings as documented by Hewlett Packard, are as follows:

On=1, Off=0

Switch	Setting
1	1
2	1
3	0
4	1
5	1
6	1



Switch	Setting
7	1
8	1

However, if the drive or autoloader was purchased from another vendor and that vendor changed the switch settings, you will have to set the switches as shown.

You may also have to make this change to HP C1533A drives in non-Hewlett Packard 4-mm robots.



Configuring Optical Disk Drives

When adding optical disk drives to a Media Manager configuration, you only need to specify a character device path. Optical disk character device files are found in the `/dev/rdisk` directory and have the following format:

```
/dev/rdisk/c $Controller$ t $Target$ d $Unit$ 
```

Where:

Controller is the Instance number of the controlling bus. The Instance value is displayed in `ioscan -f` output under the column I of the controllers entry (ext_bus in the Class column).

Target is the SCSI ID of the drive.

Unit is the SCSI logical unit number (LUN) of the drive and is usually 0.

If the desired character device files do not exist, create them with the `mksf` command. The following is an example:

```
mksf -C disk -H H/W Path -r
```

Where *H/W Path* is the hardware path of the disk drive as specified by `ioscan`.

Examples of Optical Disk Device Files

Example 1

Assume that the desired optical disk drive is on the built-in SCSI interface at SCSI ID 4 and `ioscan -f` shows the following:

```
Class      I  H/W Path  Driver  S/W State  H/W Type  Description
=====
ext_bus    0  2/0/1    c700    CLAIMED    INTERFACE  Built-in SCSI
target     4  2/0/1.4  tgt     CLAIMED    DEVICE
disk       1  2/0/1.4.0  sdisk  CLAIMED    DEVICE      HP          C1716T
.
.
.
```

The Instance number for the controlling bus is 0, and the H/W path for the optical disk drive is 2/0/1.4.0. The command to create the device file for the drive follows:

```
mksf -C disk -H 2/0/1.4.0 -r
```

This creates the following device file, which you specify to Media Manager:

```
/dev/rdisk/c0t4d0
```



Example 2

Assume that the desired optical disk drive is on an EISA interface at SCSI ID 3 and `ioscan -f` shows the following:

```

Class      I  H/W Path  Driver      S/W State  H/W Type  Description
=====
bc         0                root        CLAIMED    BUS_NEXUS
graphics  0  0          graph3      CLAIMED    INTERFACE  Graphics
ba         0  2          bus_adapter CLAIMED    BUS_NEXUS  Core I/O
                                     Adapter
ext_bus    0  2/0/1     c700        CLAIMED    INTERFACE  Built-in
                                     SCSI
.
.
ba         1  4          eisa        CLAIMED    BUS_NEXUS  EISA Adapter
ext_bus    2  4/0/1     c700        CLAIMED    INTERFACE  EISA card
                                     HWPOC80
target     9  4/0/1.3   tgt         CLAIMED    DEVICE
disk       5  4/0/1.3.0 sdisk       CLAIMED    DEVICE      HP C1716T

```

The Instance number for the controlling bus is 2, and the H/W path for the optical disk drive is 4/0/1.3.0. The command to create the device file for drive follows:

```
mksf -C disk -H 4/0/1.3.0 -r
```

This creates the following device file, which you specify to Media Manager:

```
/dev/rdisk/c2t3d0
```



Command Summary

The following is a summary of commands that may be useful when configuring devices. See the procedures in this chapter for examples of their usage.

```
ioscan -f
```

Displays information about the physical interfaces available in your system. For example, it shows the hardware path and the Instance number for the controlling bus.

```
/etc/mknod ccontroller:target:lun c 203 0xii:ll00
```

Creates device files for SCSI robotic controlled robotics.

controller is the Instance number of the controlling bus. The Instance value is displayed in `ioscan -f` output under column I of the controller entry (`ext_bus` in the Class column).

target is the SCSI ID of the robotic control.

lun is the SCSI logical unit number and should be 0 for most robots. Exceptions are Quantum DLT2700 and DLT2700, HP C1560B, and a few other robots where *lun* must be 1.

ii is two hexadecimal digits that identify the controlling bus interface card by its Instance number (same as controller).

t is one hexadecimal digit representing the SCSI ID.

l is one hexadecimal digit representing the SCSI LUN.

```
mksf -C tape -H H/W Path -b BEST -u -n
```

Creates device files for tape drives.

Where *H/W Path* is the hardware path of the disk drive as specified by `ioscan`.

```
mksf -C disk -H H/W Path -r
```

Creates device files for optical disk drives.

Where *H/W Path* is the hardware path of the disk drive as specified by `ioscan`.

This chapter shows how to configure devices for use with Media Manager on an HP9000-800 system. Configure drives and robots using one of the available Media Manager administrative interfaces.

The major topics included are as follows:

- ◆ Before You Start
- ◆ Configuring Robotic Controls
- ◆ Configuring Tape Drives
- ◆ Configuring Optical Disk Drives
- ◆ Command Summary

Before You Start

If You Are Using NetBackup BusinessServer

Portions of this chapter include configuration topics and examples for peripherals that are not supported in NetBackup BusinessServer (for example, Configuring Optical Disk Drives).

HP-UX 10.20 is not supported in NetBackup BusinessServer.

It is important to refer to the NetBackup release notes to determine which Media Manager robot types, robots, and drives are supported for the NetBackup BusinessServer product, before using this chapter.



Configuring Robotic Controls

Robots are controlled through a SCSI or a network connection.

Configuration of network controlled robotic libraries (for example, ACS robots) is discussed in the appendices of the UNIX Media Manager System Administrator's Guide.

SCSI control is covered in the following sections.

Configuring SCSI Robotic Controls

Read this topic if you plan to use a robotic storage device that is controlled through a SCSI robotic connection.

Supported SCSI robots include the following. See the NetBackup release notes for a list of the vendor models associated with the following robot types:

- ◆ ODL - Optical Disk Library
- ◆ TL4 - Tape Library 4MM
- ◆ TL8 - Tape Library 8MM
- ◆ TLD - Tape Library DLT
- ◆ TS8 - Tape Stacker 8MM
- ◆ TSD - Tape Stacker DLT

Determining Which Pass-Through Driver to Configure

When communicating with SCSI-controlled robotic peripherals, Media Manager robotic software uses the `spt` or `sctl` SCSI pass-through driver. The driver that is used depends on the type of SCSI interface on the system.

The two types of SCSI interface are

- ◆ Interfaces that use the `scsi1/scsi3` bus-adapter driver require the `spt` pass-through driver. The 28655A SCSI interface is in this category.
- ◆ Interfaces that use the `c700/c720` bus-adapter driver require the `sctl` pass-through driver. The GSC built-in SCSI interface, and some add-on cards for HP9000-800 D, K, T, and V series systems are in this category.

When attaching an autochanger device to a GCS interface and using the `sctl` driver, the `schgr` device driver must also be installed. Without this driver installed, the system will not bind the driver to the device. See the `autochanger(7)` man page.

To determine the type of interface on your system, use the `ioscan -f` command as shown in the examples below.

Example 1: 28655A SCSI Interface (spt driver)

```
ioscan -f
Class   I   H/W Path Driver S/W State   H/W Type      Description
=====
bc      0           root   CLAIMED    BUS_NEXUS
bc      1 56           bc     CLAIMED    BUS_NEXUS      Bus Converter
ext_bus 0 56/52       scsil  CLAIMED    INTERFACE      HP 28655A - SCSI
                                                Interface
target  0 56/52.2    target CLAIMED    DEVICE
tape    0 56/52.2.0  tape2  CLAIMED    DEVICE          HP HPC1533A
.
.
.
```

In this case, the `ext_bus` entry (which designates the bus adapter) specifies a `scsil` driver. You would configure the `spt` pass-through driver for the SCSI robotic controls on this system (see “Configuring Device Files for `spt` Pass-Through Driver” on page 107).

Example 2: Built-in SCSI interface (sctl driver)

```
ioscan -f
Class   I   H/W Path   Driver      S/W State H/W Type  Description
=====
ext_bus  2  10/12/5   c700        CLAIMED   INTERFACE Built-in
                                                SCSI
target  11 10/12/5.0  tgt         CLAIMED   DEVICE
tape    0  10/12/5.0.0  stape      CLAIMED   DEVICE    HP C1533A
target  12 10/12/5.2  tgt         CLAIMED   DEVICE
disk    6  10/12/5.2.0  sdisk      CLAIMED   DEVICE    TOSHIBA
                                                CD-ROM
.
.
```

In this case, the `ext_bus` entry specifies a `c700` driver. You would configure the `sctl` pass-through driver for the SCSI robotic controls on this system (see “Configure Device Files for `sctl` Pass-Through Driver” on page 109).

Configuring Device Files for `spt` Pass-Through Driver

Use this procedure on HP9000-800 systems that have a 28655A SCSI interface and use the `scsil` bus-adapter driver.

Note The HP-UX kernel has to be reconfigured to use the `spt` SCSI pass-through driver. Refer to the HP-UX `scsi_pt` (7) man page.

The device files for the `spt` driver have the following format:



`/dev/spt/c $\textit{Controller}$ t \textit{Target} l \textit{Unit}`

Where:

Controller is the Instance number of the controlling bus. The Instance value is displayed in `ioscan -f` output under the column I of the controller's entry.

Target is the SCSI ID of the robotic control.

Unit is the SCSI logical unit number (LUN) of the robot. This is usually 0.

You must create the device files for the spt driver manually, as they are not created automatically when the system boots. The following steps describe how to create these device files. These steps are also documented in the `scsi_pt(7)` man page.

1. Install and configure the driver as described in the man page.
2. Determine the character major number of the spt driver using `lsdev -d spt`.
3. Use the following commands to create the device file for the SCSI robot control:

```
mkdir /dev/spt
mknod /dev/spt/name c major 0xiil00
```

Where:

name is the device name as described above.

major is the character major number (from the `lsdev` command).

ii is two hexadecimal digits identifying the controlling bus interface card by its Instance number.

t is one hexadecimal digit representing the SCSI ID of robotic control.

l is one hexadecimal digit representing the SCSI LUN of the robotic control.

Example of a Device File

If the robotic control for an HP Optical Disk Library(ODL) is on a secondary SCSI bus at SCSI ID 3, LUN 0, use the following steps to create the device file.

1. Use the `ioscan -f` command to get information on the SCSI bus and the robotic control.

Class	I	H/W Path	Driver	S/W State	H/W Type	Description
bc	0		root	CLAIMED	BUS_NEXUS	
bc	1	56	bc	CLAIMED	BUS_NEXUS	Bus Converter
ext_bus	1	56/16	scsil	CLAIMED	INTERFACE	HP 28655A - SCSIInterface

```
target 4 56/16.3 target CLAIMED DEVICE
spt 0 56/16.3.0 spt CLAIMED DEVICE HP C1700T
.
.
.
```

The Instance number for the robot's SCSI bus is 1. It also confirms that the spt driver is attached to the optical robotic control at H/W Path 56/16.3.0.

2. Use `lsdev` to get the character major number for the spt driver.

```
lsdev -d spt
```

This shows that the character major number for the spt driver is 137.

Character	Block	Driver	Class
137	-1	spt	spt

3. Create the `/dev/spt` directory, if it has not already been created.

```
mkdir /dev/spt
```

4. Create the device file as follows:

```
mknod /dev/spt/c1t3d0 c 137 0x013000
```

This creates the `/dev/spt/c1t3d0` device file. Specify this file as the robot control path when configuring your device under Media Manager.

Configure Device Files for `sctl` Pass-Through Driver

Use this procedure on HP9000-800 D, K, T, and V series systems that have a built-in SCSI interface and also on other systems that use the `c700` bus-adapter driver.

Note You do not have to reconfigure the HP-UX kernel to use `sctl` pass-through driver on HP9000-700 systems, since the generic SCSI driver is part of basic HP-UX.

If the devices do not exist, you can create device files by using the `mknod` command as follows. See the `scsi_ctl(7)` man page.

```
mkdir /dev/sctl
cd /dev/sctl

/etc/mknod ccontroller\target1.lun c 203 0xii100
```

Where:

controller is the Instance number of the controlling bus. The Instance value is displayed in `ioscan -f` output under column I of the controller entry (`ext_bus` in the Class column).



target is the SCSI ID of the robotic control.

lun is the SCSI logical unit number and should be 0 for all robots, except DLT2700, DLT4700, HP C1560B, and a few other robots where *lun* must be 1.

ii are two hexadecimal digits that identify the controlling bus interface card by its Instance number (same as controller).

t is one hexadecimal digit representing the SCSI ID.

/i is one hexadecimal digit representing the SCSI LUN.

Notes on Using `ioscan` With `sctl` Robots

- ◆ If the robot is a LUN 1 robot (DLT4700, HP C1560B, and so on) there is no entry in the `ioscan` output for the robot.
- ◆ If the robotic control has its own SCSI ID, it has an entry similar to the following:

```
Class      I  H/W Path  Driver  S/W State H/W Type  Description
=====
unknown   -1  2/0/1.1.0  unknown UNCLAIMED UNKNOWN  LAGO SYSL3-340L
```

The Class I and Driver fields may also have invalid information. In these instances, the robotics are correct, but the `ioscan` command returns invalid information.

Examples of Device Files

Example 1

If the robotic control for a HP C1560B autoloader is on a built-in SCSI bus at SCSI ID 0 and the LUN is 1 (LUN is always 1 for HP C1560B autoloaders), use the following steps to create the device file:

1. Use the `ioscan -f` command to get information on the SCSI bus and the robotic control.

```
Class      I  H/W Path  Driver  S/W State H/W Type  Description
=====
ext_bus    2  10/12/5   c700    CLAIMED  INTERFACE Built-in SCSI
target    11 10/12/5.0  tgt     CLAIMED  DEVICE
tape       0  10/12/5.0.0 stape   CLAIMED  DEVICE    HP  C1533A
target    12 10/12/5.2  tgt     CLAIMED  DEVICE
disk       6  10/12/5.2.0 sdisk   CLAIMED  DEVICE    TOSHIBA CD-ROM
```

2. The commands to create the device file are

```
cd /dev/sctl
```



```
/etc/mknod c2t011 c 203 0x020100
```

This creates the following device file, which you specify to Media Manager:

```
/dev/sctl/c2t011
```

Example 2

Assume the robotic control for an Exabyte 10i tape stacker (TS8) is on a built-in SCSI bus at SCSI ID 3, LUN 0. Also assume that an `ioscan -f` verifies that the SCSI ID is 3 and shows that the Instance number for the robot's SCSI bus is 1.

The commands to create the device file are

```
cd /dev/sctl
```

```
/etc/mknod c1t310 c 203 0x013000
```

This creates the following device file, which you specify to Media Manager:

```
/dev/sctl/c1t310
```

Example 3

1. Use the `ioscan -f` command to get information on the SCSI bus and the robotic control.

Class	I	H/W Path	Driver	S/W State	H/W Type	Description
ext_bus	3	0/0/0.8.0.0.0	fcpmux	CLAIMED	INTERFACE	HP A3308 FCP-SCSI MUX Interface
target	0	0/0/0.8.0.0.0.0	tgt	CLAIMED	DEVICE	
tape	0	0/0/0.8.0.0.0.0.0	stape	CLAIMED	DEVICE	QUANTUM DLT7000
target	1	0/0/0.8.0.0.0.1	tgt	CLAIMED	DEVICE	
autoch	0	0/0/0.8.0.0.0.1.0	schgr	CLAIMED	DEVICE	STK9740
target	2	0/0/0.8.0.0.0.7	tgt	CLAIMED	DEVICE	
ctl	3	0/0/0.8.0.0.0.7.0	sctl	CLAIMED	DEVICE	Initiator

With fibre channel and SCSI muxes the hardware paths are a bit longer. If you use the bus H/W Path as a mask and apply it to the other hardware paths for devices on that bus, you are left with *SCSI ID.SCSI LUN* for the device.

This example has a bus with H/W Path of 0/0/0.8.0.0.0, which has an instance number (I) of 3. Applying the mask shows a DLT 7000 drive at SCSI ID 0 and a STK 9740 robot at SCSI ID 1 also on this bus. When configuring the robotic device file for the STK 9740 robot, you would use controller=3, target=1, and lun=0.

2. The commands to create the device file are

```
cd /dev/sctl
```



```
/etc/mknod c3t110 c 203 0x031000
```

These commands create the following device file, which you specify to Media Manager:

```
/dev/sctl/c3t110
```


Configuring Tape Drives

Using Berkeley Style Close

The examples in this section show *Berkeley-style close* for tape drives as indicated by the letter `b` after the compression specification. It is mandatory to specify Berkeley-style close for tape devices that you configure under Media Manager.

The terms *Berkeley-style close* and *AT&T style close* refer to where a tape is left logically positioned after a close operation (in relation to a tape mark). One style leaves an application logically positioned before a tape mark and the other leaves it after. Applications must assume where the tape is left after a close in order to establish the correct orientation the next time they do a tape-position or read operation. Some operating systems allow tape devices to be configured with either type of close. NetBackup assumes it is using Berkeley-style close on an HP9000-800.

Fast-Tape Positioning (locate-block)

Locate block is supported for most drive types in HP9000-800 for Fast/Wide GSC SCSI adapters. See the NetBackup release notes for a list of drive types that are supported.

Note Locate is not supported on HP-PB adapters such as HP 28696A - Wide SCSI or HP 28655A - SE SCSI.

To enable locate block on Fast/Wide GSC SCSI adapter, a device file in the directory `/dev/sctl` must exist for the tape drives. Create the device files as explained in “Configure Device Files for sctl Pass-Through Driver” on page 109.

Example:

Assume the configuration from `ioscan -f` is as follows:

```
Class      I   H/W Path  Driver  S/W State H/W Type  Description
=====
ext_bus    0   10/0      c720    CLAIMED  INTERFACE GSC built-in
                                     Fast/Wide SCSI Interface
tape       5   10/0.1.0  stape   CLAIMED  DEVICE     Quantum DLT4000
tape       6   10/0.2.0  stape   CLAIMED  DEVICE     Quantum DLT4000
.
.
```

The tape drives are SCSI IDs 1 and 2 on `ext_bus 0`. In the above example, the robotics for the robot is SCSI ID 0 (it does not show up with `ioscan`). In the directory `/dev/sctl`, the following device files were created:



```
# cd /dev/sctl
# ls -l
total 0
crw-r--r--  1 root    sys      203 0x000000 Jun 24 14:19 c0t0l0
crw-r--r--  1 root    sys      203 0x001000 Jun 24 14:20 c0t1l0
crw-rw-rw-  1 root    sys      203 0x002000 Mar 27 12:46 c0t2l0
```

The first one is used for the SCSI robotics. The second two are created to perform locate block on the tape drives. These device files have to exist, but are not used for any configuration in Media Manager. They must be of the form *cAdapter* *Target* *Lun*.

To disable locate block (once it is enabled), remove the */dev/sctl* device file created for the tape drive.

No Rewind Device Files

When adding tape drives to the Media Manager configuration, you need only specify a no rewind on close device file path. These device files are found in the */dev/rmt* directory and have the following format:

```
/dev/rmt/cControllertTargetdUnitBESTnb
```

Where:

Controller is the Instance number of the controlling bus. The Instance value is displayed in `ioscan -f` output under the column I of the controllers entry (ext_bus in the Class column).

Target is the SCSI ID of the tape drive.

Unit is the SCSI logical unit number (LUN) of the drive. This is usually 0.

If the desired tape device file does not exist, you can create device files through `sam`, the system administration manager, or with the following `mksf(1M)` command:

```
mksf -C tape -H H/W Path -b BEST -u -n
```

Where *H/W Path* is the hardware path of the tape drive as specified by `ioscan`.

No Rewind Device File Example

Assume that the desired 4-mm DDS2 compression tape drive is at SCSI ID 2 and `ioscan -f` shows the following:

Class	I	H/W Path	Driver	S/W State	H/W Type	Description
bc	0		root	CLAIMED	BUS_NEXUS	
bc	1	56	bc	CLAIMED	BUS_NEXUS	Bus Converter
ext_bus	0	56/52	scsil	CLAIMED	INTERFACE	HP 28655A-SCSI

```

                                Interface
target  0  56/52.2  target CLAIMED  DEVICE
tape    0  56/52.2.0 tape2 CLAIMED  DEVICE    HP    HPC1533A
.
.
.

```

The Instance number for the controlling bus is 0 and the H/W path for the tape drive is 56/52.2.0.

The command to create the device file for the drive follows:

```
mksf -C tape -H 56/52.2.0 -b BEST -u -n
```

This creates the following device file, which you specify to Media Manager:

```
/dev/rmt/c0t2d0BESTnb
```

Switch Settings for HP C1533A 4-mm DAT Drives

If you have standalone or robotic 4-mm drives, model HP C1533A, you may have to change the switch settings on the bottom of the drive. This drive comes in the HP C1560B (48AL) DAT Autoloader.

If the C1533A drive or HP C1560B autoloader was purchased from Hewlett Packard, the default switch settings should work. These default settings as documented by Hewlett Packard, are as follows:

On=1, Off=0

Switch	Setting
1	1
2	1
3	0
4	1
5	1
6	1
7	1
8	1

However, if the drive or autoloader was purchased from another vendor and that vendor changed the switch settings, you will have to set the switches as shown.

You may also have to make this change to HP C1533A drives in non-Hewlett Packard 4-mm robots.



Configuring Optical Disk Drives

When adding optical disk drives to the Media Manager configuration, you need only specify a character device path. Optical disk character device files are found in the `/dev/rdisk` directory and have the following format:

```
/dev/rdisk/cBItTargetd0
```

Where:

BI is the bus Instance number of the controlling bus. The Instance value is displayed in `ioscan` output under the column `I` of the `ext_bus` entries.

Target is the SCSI ID of the drive. This ID is in the third position of the H/W Path as displayed by `ioscan`. For example, in `56/52.5.0` the SCSI ID is 5.

You can determine the bus Instance using `ioscan -C ext_bus -f`. The output is

```
Class  I  H/W Path Driver S/W State H/W Type  Description
=====
ext_bus 0  56/52    scsi1  CLAIMED  INTERFACE  HP 28655A - SCSI
                                           Interface
ext_bus 1  56/53    lpr2   CLAIMED  INTERFACE  HP 28655A - Parallel
                                           Interface
```

You can determine the configured drives using `ioscan -C disk -f`. The output is

```
Class  I  H/W Path  Driver S/W State H/W Type  Description
=====
disk   1  56/52.1.0 disc3  CLAIMED  DEVICE  HP C1716T
disk   2  56/52.2.0 disc3  CLAIMED  DEVICE  HP C1716T
disk   3  56/52.5.0 disc3  CLAIMED  DEVICE  HP C2490AM
disk   4  56/52.6.0 disc3  CLAIMED  DEVICE  HP C2490AM
```

Example of an Optical Disk Device File

Assume you are using the two optical disk drives at SCSI IDs 1 and 2 as shown in the disk `ioscan` example above. These drives are on bus `56/52`, which as shown in the `ext_bus ioscan` above, is bus Instance 0.

The character device file paths that you specify to Media Manager follow:

For target 1:

```
/dev/rdisk/c0t1d0
```

For target 2:

```
/dev/rdisk/c0t2d0
```



Command Summary

The following is a summary of commands that may be useful when configuring devices. See the procedures in this chapter for examples of usage.

```
ioscan -C type -f
```

Shows information about the physical interfaces. *type* is the type of interface as follows:

spt specifies SCSI robotic controls.

tape specifies tape drives.

disk specifies optical disks.

ext_bus specifies SCSI controllers.

Note Numeric information is displayed in decimal.

```
mkknod /dev/spt/name c major 0xiitl00
```

Creates device files for SCSI robotic controls.

name is the device name as described in the format: *c**controller**t**target**unit*.

major is the character major number (from `lsdev`).

ii are the two hexadecimal digits identifying the controlling bus interface card by its Instance number. The Instance value is displayed in the `ioscan` output under the I column of the proper *ext_bus* entry.

t is one hexadecimal digit for the SCSI ID of the robotic control.

l is one hexadecimal digit for the SCSI LUN of the robotic control.

```
lsdev -d spt
```

Displays information about the SCSI robotic control drivers.

```
mkssf -C tape -H H/W Path -b BEST -u -n
```

Creates device files for tape drives. Where *H/W Path* is the hardware path of the tape drive, as specified by `ioscan`.





This chapter provides information for configuring devices for use with Media Manager on an SGI platform running IRIX. You configure drives and robots using one of the available Media Manager administrative interfaces.

The topics included in this chapter are as follows:

- ◆ Before You Start
- ◆ Using SCIP Controllers
- ◆ Using the `mediad` Command
- ◆ Configuring Robotic Controls
- ◆ Configuring Tape Drives
- ◆ Configuring Optical Disk Drives
- ◆ Command Summary

Before You Start

Observe the following points when performing the configurations described in this chapter:

- ◆ Typical device path names used when configuring drives and robots are described. Instructions for changing and rebuilding the kernel are also included. Depending on the type and number of devices you are adding, you may have to enter information in kernel source files and then reconfigure the kernel.
- ◆ The SGI IRIX version of Media Manager has been tested using SCSI peripherals (tape drives, optical disk drives, and robotic control) attached to the built-in SCSI controllers, sometimes referred to as on-board SCSI or Integral SCSI controllers.

When referring to these SCSI controllers, this guide uses the term *integral SCSI controller*. Communication with tape drives attached to integral SCSI controllers is done through the `tps(7M)` tape driver. Communication with disk drives (including optical disk drives) attached to integral SCSI controllers is done through the `dks(7M)` disk driver.



Using SCIP Controllers

If your IRIX system has SCIP fast-wide-differential controllers, a change to the `/var/sysgen/master.d/scip` file may be required to avoid SCSI timeouts.

You should change the following:

```
uint          scip_mintimeout = 0
```

To the following:

```
uint          scip_mintimeout = 180
```

This value was tested with a Quantum DLT4700 and corrected driver errors. In general, it is better to try a peripheral first without modifying this file. If errors occur, then change the timeout and retry. You may have to contact Silicon Graphics Corporation for further information.

After making this change, you must generate a new kernel and reboot the system as follows:

1. Run the following kernel auto-configuration script:

```
/etc/autoconfig
```

2. Reboot the system to utilize the newly built kernel.



Using the mediad Command

Do not use the IRIX `mediad` command to monitor devices configured under Media Manager. If you do, Media Manager will not be able to access the devices and you will see a message similar to the following in the system log:

```
Apr 12 10:30:55 3D:boris mediad: Could not access  
device /dev/rmt/tps0d4nr, Device busy
```

If you see this type of message and you are using `mediad`, then disable `mediad` as described in the `mediad(1M)` man page.

For example, assume you encounter this problem with a tape device whose device file is `/dev/rmt/tps0d4`. Instruct `mediad` to not monitor this tape device by editing the `/etc/config/mediad.config` file. `mediad` monitors this file so your change should be immediate.

In this example, you would add the following line to `mediad.config`:

```
ignore device /dev/rmt/tps0d4
```



Configuring Robotic Controls

Robots are controlled through a SCSI or a network connection.

Configuration for network controlled robotic libraries is explained in the appendices of the UNIX Media Manager system administrator's guide.

SCSI control is covered in the following section.

Configuring SCSI Robotic Controls

Read this topic if you plan to use a robotic device that is controlled through a SCSI robotic connection. Supported SCSI robots include the following:

- ◆ ODL - Optical Disk Library
- ◆ TL4 - Tape Library 4MM
- ◆ TL8 - Tape Library 8MM
- ◆ TLD - Tape Library DLT
- ◆ TS8 - Tape Stacker 8MM
- ◆ TSD - Tape Stacker DLT
- ◆ TSH - Tape Stacker Half-inch

See the NetBackup release notes for a list of the vendor models associated with the above robot types.

When communicating with SCSI-controlled robotic peripherals on an SGI platform, Media Manager robotic software utilizes `ds(7M)`, the generic (user mode) SCSI driver. Since this driver is part of basic IRIX, you do not have to reconfigure the kernel and reboot the system to use this driver.

Examples of SCSI Robot Control Device Files

Note Note that the second-to-last character in the following example paths is the letter l, rather than the number 1, and represents logical unit.

Example 1

If the robotics control is not for a DLT2700, DLT4700, HP C1560B, or other LUN 1 peripheral and is on SCSI bus (adapter) 0 at SCSI ID 5, the device file you specify is

```
/dev/scsi/sc0d5l0
```

Example 2

If the robotics control is not for a DLT2700, DLT4700, HP C1560B, or other LUN 1 peripheral and is on SCSI bus (adapter) 1 at SCSI ID 3, the device file you specify is

```
/dev/scsi/scld310
```

Example 3

If a DLT2700, DLT4700, HP C1560B, or other LUN 1 peripheral robotics control is on SCSI bus (adapter) 1 at SCSI ID 4 with logical unit number 1, the device file you specify is

```
/dev/scsi/scld411
```



Configuring Tape Drives

Read the following topics if you plan to use tape drives.

Fast-Tape Positioning (`locate-block`)

For most drive types, Media Manager supports the SCSI `locate-block` command for positioning a tape to a specific block. This improves tape-positioning greatly over the alternative method. See the NetBackup release notes for a list of drive types that support `locate-block`.

NetBackup and Storage Migrator use the `locate-block` command by default unless you disable the command by executing the following:

```
touch /usr/opensv/volmgr/database/NO_LOCATEBLOCK
```

With `locate-block` positioning disabled, NetBackup uses the `forward-space-file/record` method and Storage Migrator skips file marks.

No Rewind Device Files

When adding tape drives to a Media Manager configuration, you need only specify a no rewind on close device path. In a typical configuration, most of the desired tape device files exist and you just have to locate them in the `/dev` directory.

No rewind on close device files that connect to the integral SCSI controllers have the following format:

```
/dev/rmt/tps $Controller_d$ Target $nrv$ 
```

Where:

Controller is the SCSI bus (adapter) number.

Target is the SCSI ID.

The *v* specifies a variable mode device.

Some device types (like Exabyte) also have suffixes on device files that designate their particular drive type. For example

```
/dev/rmt/tps $Controller_d$ Target $nrv$ .8500c (EXB8500C)
```

Examples of No Rewind Device Files

Example 1

If the desired HP 4-mm (DAT) drive is on SCSI bus 1 at SCSI ID 4, you specify the following device path for that drive:



```
/dev/rmt/tps1d4nrv
```

Example 2

If the desired Exabyte 8500C or 8505 tape drive is on SCSI bus 0 at SCSI ID 3, you specify the following device path for that drive:

```
/dev/rmt/tps0d3nrv.8500c
```

Example 3

If the desired DLT2000 or DLT4000 tape drive is on SCSI bus 0 at SCSI ID 5, you specify the following device path for the drive:

```
/dev/rmt/tps0d5nrvc
```

Example 4

If the desired DLT7000 tape drive is on SCSI bus 0 at SCSI ID 5, you specify the following device path:

```
/dev/rmt/tps0d5nrvc.7000c
```

Example 5

If the desired Exabyte 8900 (Mammoth) is on SCSI bus 1 at SCSI ID 5, you specify the following device file path for the drive:

```
/dev/rmt/tps1d5nrvc
```

Since this drive writes in only one format, you can ignore the other device files that are created for this drive.

Adding HP 4-mm Drives and HP C1560B DAT Autoloaders

Read this topic if you plan to use standalone or robotic Hewlett-Packard (HP) 4-mm DAT tape drives or HP C1560B DAT Autoloaders. It explains drive switch settings and kernel changes you may have to make in order for the system to recognize these devices.

Checking Switch Settings

Ensure that the hardware (tape drive) switch settings on HP35480A 4-mm (DAT) drives are as follows.

Note Other combinations may work, but these are the settings that were functional during testing by VERITAS with an HP35480A drive and HP C1560B Autoloader.



On=1, Off=0

Switch	Setting
1	1
2	1
3	1
4	1
5	1
6	1
7	0
8	0

Ensure that the hardware (tape drive) switch settings on the HP C1533A 4-mm (DAT) drives are as follows:

Switch	Setting
1	1
2	1
3	0
4	1
5	1
6	1
7	0
8	0

Changing the `/var/sysgen/master.d/scsi` File

For the system to recognize the 4-mm DAT drives, the `struct tpsc_types tpsc_types[]` array must have code entries for them. You will find this array in the `/var/sysgen/master.d/scsi` file.

1. The code entries that must be in this array are as follows:

For all DAT drives except an HP C1560B DAT Autoloader:

```
/* HP DAT drives. Any product number that starts with HP354.*/
{ DATTAPE, TPDAT, 2, 5, "HP", "HP354", 0, 0, {0, 0, 0, 0},
MTCAN_BSF|MTCAN_BSR|MTCAN_APPEND|MTCAN_SETMK|MTCAN_PART
```



```

|MTCAN_PREV|
MTCAN_SYNC|MTCAN_SPEOD|MTCAN_CHKRDY|MTCAN_VAR|MTCAN_SETSZ|
MTCAN_SILI|MTCAN_SEEK|MTCAN_CHTYPEANY,
/* minimum delay on i/o is 4 minutes, because when a retry is
* performed, the drive retries a number of times, and then
* rewinds to BOT, repositions, and tries again. */
40, 4*60, 4*60, 5*60, 512, 128*512, 0, (u_char*)0, 3 * 3600,
(0), 0, 0, 0,
},

```

For an HP C1560B DAT Autoloader:

```

/* HP DAT drives. Any product number that starts with HP1533. */
{ DATTAPE, TPDAT, 2, 5, "HP", "C1533", 0, 0, {0, 0, 0, 0},
MTCAN_BSF|MTCAN_BSR|MTCAN_APPEND|MTCAN_SETMK|MTCAN_PART
|MTCAN_PREV|
MTCAN_SYNC|MTCAN_SPEOD|MTCAN_CHKRDY|MTCAN_VAR|MTCAN_SETSZ|
MTCAN_SILI|MTCAN_SEEK|MTCAN_CHTYPEANY,
/* minimum delay on i/o is 4 minutes, because when a retry is
* performed, the drive retries a number of times, and then
* rewinds to BOT, repositions, and tries again. */
40, 4*60, 4*60, 5*60, 512, 128*512, 0, (u_char*)0, 3 * 3600,
(0), 0, 0, 0,
},

```

2. If this code is in `/var/sysgen/master.d/scsi` and you have previously rebuilt the kernel as explained in step c of step 3 below, then no further changes are necessary.
3. If the code is not in `/var/sysgen/master.d/scsi`, add it as follows:
 - a. Save a copy of `/var/sysgen/master.d/scsi`.
 - b. Add the above code. The easiest way to make this addition is to copy it from the `MediaMgr_DeviceConfig_Guide.txt` file.
 - c. After completing your changes to the file, reconfigure the kernel by running the kernel auto-configuration script.

```

/etc/autoconfig

```
 - d. Reboot the system to utilize the newly built kernel.



Adding Sony DTF Drives

For the system to recognize DTF drives, the code in the struct `tpsc_types` `tpsc_types[]` array must contain entries for them. You will find this array in the `/var/sysgen/master.d/scsi` file.

1. Code entries for Sony drives that must be in this array are as follows:

```
/* SONY GY-2120 drive */
{ SONYGY, TPGY2120, 4, 7, "SONY", "GY-2120", 0, 0, {0, 0, 0, 0},
MTCAN_BSF | MTCAN_BSR | MTCANT_RET | MTCAN_CHKRDY | MTCAN_PREV |
MTCAN_SEEK | MTCAN_APPEND | MTCAN_SILI | MTCAN_VAR | MTCAN_SETSZ |
MTCAN_CHTYPEANY | MTCAN_COMPRESS,
20, 100*60, 10*60, 9*60, 9*60, 16384, 256*1024,
tpsc_default_dens_count, tpsc_default_hwg_dens_names,
tpsc_default_alias_dens_names,
{0}, 0, 0, 0,
0, (u_char *)0
},

/* SONY GY-8240 drive */
{ SONYGY, TPGY2120, 4, 7, "SONY", "GY-8240", 0, 0, {0, 0, 0, 0},
MTCAN_BSF | MTCAN_BSR | MTCANT_RET | MTCAN_CHKRDY | MTCAN_PREV |
MTCAN_SEEK | MTCAN_APPEND | MTCAN_SILI | MTCAN_VAR | MTCAN_SETSZ |
MTCAN_CHTYPEANY | MTCAN_COMPRESS,
20, 100*60, 10*60, 9*60, 9*60, 16384, 256*1024,
tpsc_default_dens_count, tpsc_default_hwg_dens_names,
tpsc_default_alias_dens_names,
{0}, 0, 0, 0, 0, (u_char *)0
},
```

2. If the above code is in `/var/sysgen/master.d/scsi` and you have previously rebuilt the kernel as explained in step c of step 3 below, then no further changes are necessary.
3. If the code is not in `/var/sysgen/master.d/scsi`, add it as follows:
 - a. Save a copy of the `/var/sysgen/master.d/scsi` file.
 - b. Add the above code. The easiest way to make this addition is to copy it from the `MediaMgr_DeviceConfig_Guide.txt` file.
 - c. After completing your changes to the file, reconfigure the kernel by running the following kernel auto-configuration script:

```
/etc/autoconfig
```



- d. Reboot the system to utilize the newly built kernel.

Adding Quantum DLT Drives or Stackers

Read this topic if you plan to use DLT8000 tape drives.

For the operating system to recognize DLT drives, the following entries must be in the `/var/sysgen/master.d/scsi` file.

1. The section used to define arrays for density counts and density names must contain the following entry:

```
#define tpsc_dlt8000_dens_count 2
char *tpsc_dlt8000_hwg_dens_names[] = { "8000", "8000_compress" };
char *tpsc_dlt8000_alias_dens_names[] = { ".8000", ".8000c" };
```

2. The struct `tpsc_types tpsc_types[]` array must contain the following entry:

```
/* DEC THZxx DLT drive */
{ DECDLT, TPDLT, 0, 7, "QUANTUM", "DLT8000", 0, 0,
  {0 /*8000*/, 0 /*8000c*/ },
  MTCAN_BSF|MTCAN_BSR|MTCAN_APPEND|MTCAN_SPEOD |
  MTCAN_CHKRDY|MTCAN_VAR| MTCAN_SETSZ|MTCAN_SILI|MTCAN_SEEK|
  MTCAN_SYNC|MTCAN_CHTYPEANY|MTCAN_COMPRESS|MTCAN_SETDEN,
  20, 8*60, 20*60, 5*60, 3*3600, 4096, 64*1024,
  tpsc_dlt8000_dens_count, tpsc_dlt8000_hwg_dens_names,
  tpsc_dlt8000_alias_dens_names,
  {0}, 0, 0, 0,
  0, (u_char *)0 },
```

3. If these entries are in `/var/sysgen/master.d/scsi` and you have previously rebuilt the kernel as explained in step c of step 4 below, then no further changes are necessary.
4. If the entries are not in `/var/sysgen/master.d/scsi`, then add them as follows:
 - a. Save a copy of `/var/sysgen/master.d/scsi`.
 - b. Add the above code. The easiest way to make this addition is to copy it from the `MediaMgr_DeviceConfig_Guide.txt` file.
 - c. After completing your changes to the file, reconfigure the kernel by running the following kernel auto-configuration script:

```
/etc/autoconfig
```



- d.** Reboot the system to utilize the newly built kernel.

Configuring Optical Disk Drives

When adding optical disk drives to a Media Manager configuration, you must specify the following device paths:

- ◆ Character device path (disk partition *s7*)
- ◆ Volume header disk device path (disk partition *vh*)

In a typical SGI IRIX configuration, most of the desired optical disk device files already exist and you just have to locate them in the `/dev` directory.

Character disk device files have the following format:

```
/dev/rdisk/dks $Controller$  $Targets$ s7
```

Volume disk device files have the following format:

```
/dev/rdisk/dks $Controller$  $Target$ vh
```

Where:

Controller is the SCSI bus (adapter) number.

Target is the SCSI ID.

s7 is the desired character device partition.

vh is the desired volume header partition.

Examples of Optical Disk Device Files

If the desired optical disk drive is on SCSI bus 1 at SCSI ID 3, you specify the following paths:

```
/dev/rdisk/dks1d3vh (volume header)  
/dev/rdisk/dks1d3s7 (character device)
```



Command Summary

The following is a summary of commands that may be useful when configuring devices. See the procedures in this chapter for examples of their usage.

`MAKEDEV type`

If the device files you need do not exist, you can execute this command from the `/dev` directory to create them.

type indicates the type of device file, as follows:

`tps` creates all the tape device file combinations for `tps` (the SCSI tape driver for Integral SCSI controllers)

`scsi` creates all the device files for the generic SCSI driver.

`dks` creates all the device files for `dks` (the SCSI disk driver for integral SCSI controllers).

`/etc/autoconfig`

Runs the kernel auto-configuration script.

`/usr/opensv/volmgr/bin/vmconf`

Provided with Media Manager, this script does device setup in less complex configurations.

`/sbin/hinv`

Shows the system configuration, including devices configured on SCSI controllers.



Compaq Alpha Running TRU64 UNIX

4.0F/5.0

8

This chapter explains how to configure devices for use with Media Manager on a Compaq Alpha platform running TRU64 UNIX. You configure drives and robots using one of the available Media Manager administrative interfaces.

The main topics included in this chapter are

- ◆ Configuring Robotic Controls
- ◆ Adding Nonstandard Tape Drives
- ◆ Command Summary



Configuring Robotic Controls

Robots are controlled through a SCSI or a network connection.

Configuration for network controlled robotic libraries is discussed in the appendices of the Media Manager system administrator's guide.

SCSI control is covered in the following section.

Configuring SCSI Robotic Controls

Read this topic if you plan to use a robotic storage device that is controlled through a SCSI robotic connection. See the NetBackup release notes for a list of the vendor models associated with the following supported SCSI robot types.

- ◆ TL4 - Tape Library 4MM
- ◆ TL8 - Tape Library 8MM
- ◆ TLD - Tape Library DLT
- ◆ TS8 - Tape Stacker 8MM
- ◆ TSD - Tape Stacker DLT

When communicating with SCSI-controlled robotic peripherals, Media Manager robotic software utilizes the generic (user mode) SCSI pass-through driver. The TRU64 UNIX kernel does not have to be reconfigured to use this driver, since this driver is part of basic TRU64 UNIX.

Creating SCSI Robotic Control Device Files

Media Manager requires that a special file be created in the `/dev` directory for SCSI controlled robotics. If the `/usr/openv/volmgr/bin/vmconf` script is used to configure devices, it creates the necessary device files.

If you do not use this script, the device files must be created using the `mknod` command as follows:

```
cd /dev  
  
/sbin/mknod robotypebustargetlun c 38 minor
```

Where:

robotype is the robot type in lower case (for example, *tsd*).

bus is the bus (adapter) number.

target is the SCSI ID.

lun is the logical unit number (*lun* is always 0, except for DLT2700, DLT4700, HP C1560B, and some other peripherals).

minor equals $(\text{bus} * 256) + (\text{target} * 16) + \text{lun}$

Examples of SCSI Robotic Control Device Files

Example 1

If the robotics control for an Exabyte 10i (TS8) is connected to bus 0 at SCSI ID 5, lun 0, the commands to create the device file are as follows:

```
cd /dev
/sbin/mknod ts8c0t5l0 c 38 80
```

This creates the following device file, which you specify to Media Manager:

```
/dev/ts8c0t5l0
```

Example 2

If the robotics control for a Quantum DLT2700 (TSD) is connected on bus 1 at SCSI ID 3, lun 1, the commands to create the device file would be

```
cd /dev
/sbin/mknod tsdc1t3l1 c 38 305
```

This creates the following device file, which you specify to Media Manager:

```
/dev/tsdc1t3l1
```

The `lsdev` command located in `/usr/opensv/volmgr/bin` can be used to determine what devices are physically connected to the system. An example for determining connected autochangers follows. This example shows that there is only one possible autochanger connected to this system.

```
/usr/opensv/volmgr/bin/lsdev changer
Bus 0 Scsi Id 5 Lun 0, Changer: EXABYTE EXB-10i 3.0
```



Configuring Tape Drives

Fast-Tape Positioning (locate-block)

For most drive types, Media Manager supports the SCSI `locate-block` command for positioning a tape to a specific block. This improves tape-positioning greatly over the alternative method. See the NetBackup release notes for a list of drive types that support `locate-block`.

NetBackup uses the `locate-block` command by default unless you disable it by executing the following:

```
touch /usr/opensv/volmgr/database/NO_LOCATEBLOCK
```

With `locate-block` positioning disabled, NetBackup uses the `forward-space-file/record` method.

Adding Standard Tape Drives

When adding tape drives to a Media Manager configuration, you need only specify a no rewind on close device path.

Note These are LUN 0 tape drives.

These device files are located in the `/dev` directory, and have the following format:

```
/dev/nrmtLtuDensity
```

Where:

Ltu is the logical tape unit. When the first MAKEDEV of a tape drive is done, *Ltu* is 0. The next time, *Ltu* is 1, and so on.

Values for *Density* can be l, m, h, or a. Typically, h (for high) is used.

Creating No Rewind Device Files

If the desired tape device file does not exist, you can create device files using the MAKEDEV command as follows:

```
cd /dev
./MAKEDEV tzn
```

Where *n* is $(bus * 8) + SCSI\ ID$

Media Manager provides the `lsdev` command that you can use to determine the devices that are physically connected to the system. This command is located in `/usr/opensv/volmgr/bin`.

An example of using `lsdev` to determine connected tape drives follows:

```
lsdev tape
Bus 0 Scsi Id 3 Lun 0, Tape (rmt2): EXABYTE EXB-8500-85Qanx005E0
Bus 0 Scsi Id 4 Lun 0, Tape (rmt0): EXABYTE EXB-850085QANXRC05E0
```

You can also use the following form of the command:

```
lsdev logical_tape_devs
rmt2 is defined on bus 0, scsi id 3
rmt0 is defined on bus 0, scsi id 4
```

If the device files do not exist for a connected tape drive, the command shows (----) instead of `rmtLtu`, for example

```
lsdev tape
```

The output shows that the device files for the tape drive on bus 0, SCSI ID 4 do not exist.

```
Bus 0 Scsi Id 3 Lun 0, Tape (rmt2): EXABYTE EXB-8500-85Qanx005E0
Bus 0 Scsi Id 4 Lun 0, Tape (----): EXABYTE EXB-850085QANXRC05E0
```

To create device files, use the `MAKEDEV` command.

```
cd /dev
./MAKEDEV tz4
```

The output is as follows:

```
MAKEDEV: special file(s) for tz4:
rmt0l
rmt0h
rmt0m
rmt0a
nrmt0l
nrmt0h
nrmt0m
nrmt0a
```

Note Only the four no rewind device files are needed for configuration.

Configuring Fibre Channel Tape Drives

When adding tape drives to a Media Manager configuration, you need only specify a no rewind on close device path. These device files are located in the `/dev` directory, and have the following format:

```
/dev/nrmtLtuDensity
```

Where:

Ltu is the logical tape unit.



Values for *Density* can be l, m, h, or a. Typically, h (for high) is used.

If the desired tape device file does not exist, you can create device files using the `mknod` command. Most fibre channel tape drives have a LUN other than 0.

The commands in the example use the following format:

```
mknod /dev/nrmtLtuDensity c 9 calc
```

Where:

$$\textit{calc} = (\textit{LUN} \times 64) + (\textit{target_ID} \times 1024) + (\textit{bus_number} \times 16384) + (\textit{den} \times 2) + \textit{rewind}$$

den = 0 for low, 1 for high, 2 for medium, or 3 for auxiliary density.

rewind = 0 for rewind and 1 for no rewind.

Note Use 1 for no rewind on close device files.

Fibre Channel Example

The following example uses the formula to add a SCSI tape device with LUN 3, target ID 4, and bus number 2.

1. Perform the following calculation for the no rewind device files, depending on the density of the device:

low density: $(3 \times 64) + (4 \times 1024) + (2 \times 16384) + (0 \times 2) + 1 = 37057$

high density: $(3 \times 64) + (4 \times 1024) + (2 \times 16384) + (1 \times 2) + 1 = 37059$

medium density: $(3 \times 64) + (4 \times 1024) + (2 \times 16384) + (2 \times 2) + 1 = 37061$

auxilliary density: $(3 \times 64) + (4 \times 1024) + (2 \times 16384) + (3 \times 2) + 1 = 37063$

2. Create the no rewind device files. *Ltu* must be a unique number.

```
# mknod /dev/nrmtLtul c 9 37057
```

```
# mknod /dev/nrmtLtuh c 9 37059
```

```
# mknod /dev/nrmtLtum c 9 37061
```

```
# mknod /dev/nrmtLtua c 9 37063
```

Examples of No Rewind Device Files

Example 1

If the desired Exabyte 8500 tape drive is on bus 0 at SCSI ID 4, the commands to create the device files follow:

```
cd /dev  
./MAKEDEV tz4
```

This creates the following device file, which you specify to Media Manager (this example assumes *Ltu* is 0):

```
/dev/nrmt0h
```

Example 2

If the desired DLT4000 tape drive is on bus 1 at SCSI ID 3, the commands to create the device files are as follows:

```
cd /dev
./MAKEDEV tzt11
```

This creates the following device file, which you specify to Media Manager (this example assumes *Ltu* is 1):

```
/dev/nrmt1h
```

Adding Nonstandard Tape Drives

VERITAS has tested several tape drives on TRU64 UNIX, including EXABYTE 8-mm drives, HP 4-mm DAT drives, and Quantum DLT drives.

Normally, using tape drives from these vendors does not require kernel reconfiguration because the default definitions are sufficient. If a drive vendor recommends kernel reconfiguration, the file that contains the tape drive definitions is

```
/usr/sys/data/cam_data.c.
```

If this file is modified

- ◆ Care should be taken to ensure tape drives are configured in variable (rather than fixed) mode.
- ◆ Refer to the `doconfig(8)` command for information on rebuilding a new kernel.

Switch Settings for HP C1533A 4mm DAT Drives

If you have standalone or robotic 4MM drives that are model HP C1533A, you may have to change the switch settings on the bottom of the drive. This drive comes in the HP C1560B (48AL) DAT Autoloader.

If the drive or autoloader was purchased from Hewlett Packard, the default switch settings should work. However, if the drive or autoloader was purchased from some other vendor, that vendor may have changed the default switch settings. The same thing may apply to other vendor's 4MM robots if they contain HP C1533A drives.

If this situation exists, set the switch settings to the following (the documented default):



On=1, Off=0

Switch	Setting
1	1
2	1
3	0
4	1
5	1
6	1
7	1
8	1



Command Summary

The following is a summary of commands that may be useful when configuring devices. See the procedures in this chapter for usage examples.

```
/sbin/mknod rotypecbustargetlun c 38 minor
```

Execute this command from the `/dev` directory to create the special device file for SCSI controlled robotics. If the `/usr/opensv/volmgr/bin/vmconf` script is used to configure devices, it automatically creates the necessary device files and this command is unnecessary.

Where:

rotype is the robot type in lower case (for example, ts8).

bus is the bus (adapter) number.

target is the SCSI ID.

lun is the logical unit number (*lun* is 0, except for DLT2700, DLT4700, HP C1560B, and some other peripherals).

$$\text{minor} = (\text{bus} * 256) + (\text{target} * 16) + \text{lun}$$

```
/sbin/mknod /dev/nrmtLtuDensity c 9 calc
```

Execute this command to can create tape device files.

Where:

Ltu is the logical tape unit and values for *Density* can be l, m, h, or a.

$$\text{calc} = (\text{LUN} * 64) + (\text{target_ID} * 1024) + (\text{bus_number} * 16384) + (\text{den} * 2) + \text{rewind}$$

den = 0 for low, 1 for high, 2 for medium, or 3 for auxiliary density.

rewind = 0 for rewind and 1 for no rewind.

```
./MAKEDEV ace0
```

Creates device files for the serial ports. Normally, these files exist after the system is installed. Execute this command from the `/dev` directory.

```
./MAKEDEV tzn
```

Where *n* is $(\text{bus} * 8) + \text{SCSI ID}$.

Creates device files for tape drives. Execute this command from the `/dev` directory.

```
/usr/opensv/volmgr/bin/lsdev tape
```

Displays tape devices that are physically connected to the system.

```
/usr/opensv/volmgr/bin/vmconf
```



Provided with Media Manager, this script does device setup in less complex configurations.

```
scu sh edt
```

Displays the CAM equipment data table (EDT).

```
scu sc edt
```

Scans for devices and places them in the CAM equipment data table (EDT).

This chapter explains how to configure devices for use with Media Manager on a NCR system. Configure drives and robots using one of the available Media Manager administrative interfaces.

The main topics covered here are as follows:

- ◆ NCR Device Files
- ◆ Configuring Robotic Controls
- ◆ Configuring Tape Drives



NCR Device Files

You do not need to install a pass-through driver or run `mkknod` commands to add new device files. (The device files are created automatically when the machine is rebooted after adding a new device.)

After you attach the hardware and boot the machine, locate your device file names in the `/etc/device.tab.rd` text file and use those device file names when configuring Media Manager.

Information about attached devices can be found in this text file, for example

```
-----snippet 1 from /etc/device.tab.rd -----
c13t2d0s0:/dev/rmt/c13t2d0s0:::\
    removable="true" \
    id="Quantum DLT4000" \
    desc="Tape Drive" \
-----
-----snippet 2 from /etc/device.tab.rd -----
c13t4d0s0:/dev/rchg/c13t4d0s0:::\
    removable="true" \
    id="STK 9714" \
    desc="Medium Changer Device" \
-----
```



Configuring Robotic Controls

Robots are controlled through a SCSI or a network connection. Configuration for network controlled robotic libraries is discussed in the appendices of the Media Manager system administrator's guide.

From the previous example, an example robotic path for SCSI control is
/dev/rchg/c13t4d0s0.

Configuring Tape Drives

To configure a no rewind on close tape device, use the device file with the nn suffix. In the following example this device file would be: /dev/rmt/c13t2d0s0nn.

The following example list was created using /usr/opensv/volmgr/bin/tpconfig -d:

Index	DriveName	DrivePath	Type	Multihost	Status
*****	*****	*****	****	*****	*****

0	DRIVE2	/dev/rmt/c13t2d0s0nn	dlt	No	UP
	TLD(0) Definition DRIVE=2				

Currently defined robotics are:

TLD(0) robotic path = /dev/rchg/c13t4d0s0, volume database host = ted

Note The list of currently supported devices is limited. The list includes: STK9710 and STK9714 robots (SCSI or Automated Cartridge System control) with DLT2000/DLT4000 drives.





Sequent Running DYNIX/ptx 4.4.2/4.4.4/4.5

10

This chapter explains how to configure devices for use with Media Manager on a Sequent system running DYNIX. You configure drives and robots using one of the available Media Manager administrative interfaces.

The main topics covered in this chapter are as follows:

- ◆ Configuring Robotic Controls
- ◆ Configuring Tape Drives



Configuring Robotic Controls

Robots can be controlled through a SCSI or a network connection.

Configuration for network controlled robotic libraries is discussed in the appendixes of the Media Manager system administrator's guide. These appendixes describe specific platform requirements and restrictions.

Configuring SCSI robotic control is covered in the following section.

Configuring SCSI Robotic Controls

The following SCSI robot types are supported. See the NetBackup release notes for a list of the vendor models associated with these robot types.

- ◆ TL4
- ◆ TL8
- ◆ TLD
- ◆ TS8

Use the following procedure to configure a pseudo device file for the robot pass-through capability:

1. The following display using `lsdev`, lists the devices in a system. This command uses the pass-through capability to do an inquiry command. If `lsdev` works it is a good indicator that the robotics will also work.

```
/usr/openv/volmgr/bin/lsdev
Bus 0, target 0, lun 0, Disk: (IBM OEM DFHSS4E          4343)
Bus 0, target 1, lun 0, Disk: (SEAGATE ST15150W         0023)
Bus 0, target 3, lun 0, Tape: (EXABYTE EXB8500C8SQANXRU07J0)
Bus 0, target 4, lun 0, Tape: (TANDBERG TDC 3800       -07:)
Bus 0, target 5, lun 0, Cdrom: (PLEXTOR CD-ROM PX-6XCS   4.05)
Bus 0, target 7, lun 0, Processor: (SEQUENT CSM SCSI Ctlr 0601)
Bus 0, target 8, lun 0, Disk: (HP          C2490A         5083)
Bus 1, target 1, lun 0, Disk: (SEAGATE ST15150W         0023)
Bus 1, target 3, lun 0, Changer: (STK          9730         1102)
Bus 1, target 4, lun 0, Tape: (Quantum DLT4000         CD3C)
Bus 1, target 5, lun 0, Tape: (Quantum DLT4000         CD3C)
```

2. Note the bus, target, and lun of the robotic library you want to control as a TLD robot. In the above example, it is the STK 9730.
3. Create a pseudo device file, as follows:



- a. Create a directory in `/dev`.

```
cd /dev
mkdir dir-name
cd dir-name
```

- b. Create a file, *file-name*, in this directory that contains the bus, target, and lun for the robotics. The directory name and file name used in the following example is `veritas/stk9730`, but they can be any names.

To configure the STK 9730 robot, create a file as follows. The `lsdev` display in step 1 shows that the bus is 1, the target is 3, and the lun is 0. These three values are entered in the new file.

```
cat > stk9730
1 3 0
^D
```

4. Use `/dev/dir-name/file-name` as the robotic path when using `tldtest` or when configuring the robot. For example

```
tldtest -r /dev/veritas/stk9730
```

Media Manger uses the file to obtain the path to the device required by the pass-through capability (bus, target, and lun).



Configuring Tape Drives

The `vmconf` configuration script does not support adding tape drives or robots to a Media Manager configuration on Sequent systems.

The following table shows the drivers that are used with various drive types:

Table 2. Drivers for Selected Drive Types

Drive Type	Sequent Driver
Exabyte 8500, 8500C, 8505, 8505XL, 8900	tx
DLT4000, DLT7000	tl
IBM Magstar (3590)	tc
4mm DAT	td
STK 4490, 4781 (4480), 4791 (Silverton), 4890 (Twin Peaks), 9490 (Timberline), SD-3 (Redwood)	tf

See the Sequent DYNIX `man` pages on the tape drivers for information on which device paths to use for a specific drive.

Table 3. Example Device Files for Media Manager

Drive Type	No Rewind Device
Exabyte 8500C	<code>/dev/rmt/tx0x85cn</code>
1/2 Cartridge (3480)	<code>/dev/rmt/tf2n</code>
DLT	<code>/dev/rmt/tl4n</code>
IBM Magstar (3590)	<code>/dev/rmt/tc3n</code>
4mm DAT	<code>/dev/rmt/td6n</code>

To configure pseudo-device files for tape drives to use fast positioning (locate block), perform the following steps:

1. The following output using `lsdev`, lists the devices in an example system. `lsdev` uses the pass-through capability to do an inquiry command.

```
/usr/openv/volmgr/bin/lsdev
Bus 0, target 0, lun 0, Disk: (IBM OEM DFHSS4E          4343)
Bus 0, target 1, lun 0, Disk: (SEAGATE ST15150W        0023)
Bus 0, target 3, lun 0, Tape: (EXABYTE EXB8500C8SQANXRU07J0)
Bus 0, target 4, lun 0, Tape: (TANDBERG TDC 3800      -07:)
Bus 1, target 1, lun 0, Disk: (SEAGATE ST15150W        0023)
```



```

Bus 1, target 3, lun 0, Changer: (STK      9730      1102)
Bus 1, target 4, lun 0, Tape: (Quantum DLT4000      CD3C)
Bus 1, target 5, lun 0, Tape: (Quantum DLT4000      CD3C)

```

Note the bus, target, and lun of the tape drives you want to configure (for example, the two Quantum DLT4000s).

2. Use the command `/etc/dumpconf` to determine the tape device name by matching the target (in the UNIT) column and the `scsibus`. The following is an excerpt from `dumpconf`:

```

NAME      CFGTYPE  DEVNUM  UNIT          FLAGS  OnBUS  OnDEVICE
t10       tl        0  0x00000040  S      scsi   scsibus1
t11       tl        1  0x00000050  S      scsi   scsibus1
The tape at target 4 is /dev/rmt/tl0.
The tape at target 5 is /dev/rmt/tl1.

```

3. Create a device file, as follows:

- a. Create a `veritas` directory in `/dev` if it does not exist (the name must be `veritas`).

```

cd /dev
mkdir veritas
cd veritas

```

- b. Create a file, *file-name*, in `dev/veritas` that contains the bus, target, and lun for each tape drive. *file-name* must be located in this directory and must match the last element of the path of the tape drive that is configured as the non-rewind device name (using the Media and Device management interface, `tpconfig`, or `xdevadm`).

For example, to configure the two DLT drives, use the output from the `tpconfig -d` command.

```

Index   DriveName      DrivePath      Type  Multihost  Status
*****  *
4       /dev/rmt/tl0   /dev/rmt/tl0n  dlt   no         UP
        TLD(0) Definition      DRIVE=1
5       /dev/rmt/tl1   /dev/rmt/tl1n  dlt   no         UP
        TLD(0) Definition      DRIVE=2

```

Currently defined robotics are:

```

TLD(0)      robotic path = /dev/veritas/stk9730, volume
                                     database host = hosta

```



Create files for the two DLT drives as follows. The existence of the files `/dev/veritas/tl0n` and `/dev/veritas/tl1n` with the correct bus, target, and lun is all that's needed to enable locate block. The important thing to remember is that the filename must be the same as the `/dev/rmt` filename for the non-rewind device.

```
cat > tl0n
1 4 0
^D
cat > tl1n
1 5 0
^D
```

Kernel Configuration

Media Manager (the `avrd` daemon) periodically attempts to open configured tape drives that are UP to see if a tape has been loaded. DYNIX logs error messages to the console when a not ready (empty) tape drive is opened.

The following are kernel configuration options you can make to reduce the number of messages that are logged. After making changes to any kernel configuration files you must generate a new kernel for the system. See the `config (1M)` man page.

Turning Off Messages

To turn off messages for drives being scanned, change the following line in `/usr/conf/uts/io/scsitape/scsitape_space.c`.

From

```
int sct_devroute = CE_TRACE | CE_WARN;
```

To

```
int sct_devroute = CE_TRACE;
```

Exabyte Drive Type

If you are using 8mm Exabyte tape drives, you may want to disable the 45 second wait for a drive to become ready. Change the following line in `/usr/conf/uts/io/tx/tx_space.c`.

From

```
int tx_ready_timeout = 45;
```

To

```
int tx_ready_timeout = 0;
```


DLT Drive Type

If you are using DLT tape drives, you may want to disable the 45 second wait for a drive to become ready. Change the following line in `/usr/conf/uts/io/tl/tl_space.c`.

From

```
int tl_ready_timeout = 45;
```

To

```
int tl_ready_timeout = 0;
```

Tape Drive Support

DLT Drive Type

The DLT driver from Sequent should be installed. Refer to the Sequent Computer Systems installation guide for instructions for this driver.

IBM Magstar (3590) Drive Type

The IBM Magstar driver from Sequent should be installed. Refer to the Sequent Computer Systems installation guide for instructions for this driver.



Command Summary

The following commands display the hardware configuration.

`/etc/dumpconf`

Examines the physical devices configured on the system.

The `-d` option shows the SCSI buses and tape devices on the system.

`/etc/showcfg`

Displays the configuration of the system in a manner similar to the power-up monitor configuration command.

The `-s` option selects an alternate one-line format that gives the quantity of each type of board.

The `-d` option produces a dump of relevant parts of the system configuration description table. The data displayed includes information about the memory available, the boot flags, the boot device, console tty control characters, and the current system bus mode.

Pyramid Running Reliant UNIX 5.43 C20/5.43 C30/5.44/5.45

11

This chapter explains how to configure devices for use with Media Manager on a Pyramid RM1000 running Reliant UNIX. You configure drives and robots using one of the available Media Manager administrative interfaces.

The main topics included in this chapter are as follows:

- ◆ Configuring Robotic Controls
- ◆ Configuring Tape Drives



Configuring Robotic Controls

No robots are supported with direct control.

Configuration information for network-controlled robots can be found in the Automated Cartridge System (ACS) and the ADIC Distributed AML Server (DAS) appendixes of the UNIX Media Manager system administrator's guide.

Configuring Tape Drives

When adding tape drives to a Media Manager configuration, you need only specify a no rewind on close device path. These device files are located in the `/dev/tape` directory and have the following format:

```
/dev/tape/rt2cn
```

Using Berkeley-style Close

You must specify a Berkeley-style close for tape devices that you configure under Media Manager.

The terms *Berkeley-style close* and *AT&T close* refer to where a tape is left logically positioned after a close operation (in relation to a tape mark). One style leaves an application logically positioned before a tape mark and the other leaves it after. Applications must assume where the tape is left after a close in order to establish the correct orientation the next time they do a tape position or read operation. Some operating systems allow tape devices to be configured with either type of close. NetBackup assumes it is using a Berkeley-style close on a Pyramid RM1000.

Checking For Berkeley-style Close

To determine if a tape device is set to Berkeley-style close, follow these steps:

1. Use the following command to list the available tape devices:

```
autoconf -l -n node_name
```

Where:

`-l` lists all devices

`node_name` is the name of the RM1000 cell node running Media Manager software.

The output will be similar to the following:



```
System Configuration:
  NCR 720 SCSI-2 Controller Rev:x.xx Path:0 Id:7
xpt0
t1 Pyramid Model 3466 (8mm tape)
  NCR 720 SCSI-2 Controller Rev:x.xx Path:1 Id:6
  xpt1
t2 Pyramid Model 3445 (128-trk wide tape drive)
```

This node has two tape devices configured, t1 (8mm tape) and t2 (128-trk wide tape drive).

2. Use the following command to list the characteristics of the required tape device:

```
vtconfig -p t2
```

The output will be similar to the following:

```
/*
Physical tape configuration for
*/
physical tape{
  filemark = default_file_tapemark; mts_type = 5; erase_op =
remaining_partition_logical;
  block_mode = variable;
  gap_size = default_size;
  eod = one_consecutive_tapemark generate_with_filemarks;
  node   name_suffix = "d0c"           <== Rewind Device
        density = 0x0
        compression = 0x1
        close_action = rewind
        mts_density = low
        alias_suffix = "c";
  node   name_suffix = "d0cn" <== No rewind Device
        density = 0x0
        compression = 0x1
        close_action = none           <== Close Action
        mts_density = low
        alias_suffix = "cn";
}
```

For a Berkeley-style close, the close action for the no rewind on close device must be set to none.

Setting Berkeley-style Close

If the close action is set to `forward_space_filemark`, an AT&T style close is used. In this case, the device must be reconfigured to use Berkeley-style close as follows:



1. Use the following command to remove the device file from `/dev/tape`:

```
tpadmin -d t2
```

2. Rename the tape device.

```
tpadmin -n
```

3. Configure the device as Berkeley-style close, as follows:

```
vtconfig -c tape_device PTC_128trkC_BSD /dev/phys/tape/tape_device
```

Where *tape_device* is the tape device name. For example, `t2`.

This command will use the file `PTC_128trkC_BSD` in `/etc/default/tapeinfo/vtconfig` to define the close action. This command also recreates `/dev/tape/rt2c` and `/dev/tape/rt2cn`.

4. Check the close action.

```
vtconfig -p tape_device | more
```

Where *tape_device* is the tape device name.

See the `vtconfig`, `tpadmin`, and `autoconf` man pages for further information.

Glossary

access control list (ACL)

Security information associated with files on some file systems.

ACS

Automated Cartridge System. This robot type is supported only by NetBackup DataCenter servers.

active job

A job for which NetBackup is currently processing backup or restore data.

activity logs

Logs that can be optionally enabled for specific NetBackup programs and processes and then used to investigate problems.

activity monitor

A NetBackup administration utility that displays information about NetBackup jobs and provides limited control over them.

administrator

A user that is granted special privileges to install, configure, and manage the operation of a system, network, or application

administration client

A Windows NT/2000 NetBackup client that has the administration interface software installed and can be used to administer NetBackup servers.

AIT

Sony Advanced Intelligent Tape, a type of tape drive or media type.



alternate-client restore

Restoring files to your client when they were originally backed up from a different client. The administrator using the interface on the master server can direct a restore to any client (this variation is called a server directed restore).

alternate-target restore

On a Novell NetWare server platform running the NetBackup target version of client software, this operation restores files to a different target than the one from which they were backed up.

alternate path restore

Restores files to a different directory than the one from which they were backed up.

archive

A special kind of backup where NetBackup backs up the selected files, and if the backup is successful, deletes the files from the local disk. In this manual, references to backups also apply to the backup portion of archive operations except where otherwise noted.

archive bit

A file-status bit that the Microsoft based operating system sets when it writes a file, thereby indicating that the file has changed.

attributes for a class

Configuration parameters that control the behavior of NetBackup during operations involving this class.

automatic backup

A scheduled backup by the master server.

back up

The act of copying and saving files and folders to storage media.

backup

Refers to the process of copying and saving files and directories to storage media. For example, "the backup is complete" This term can also refer to the collection of data that NetBackup saves for a client during a backup or archive. For example, "duplicate the backup."

Backup is two words when used as a verb. For example, "back up the file."



backup, archive, and restore interface

The name of the NetBackup Microsoft Windows and Java based user interfaces for clients. On servers, these interfaces can be started through the NetBackup Administration interface.

backup window

The period of time during which backups can begin.

block size

The number of bytes in each block of data written on the media during a backup.

bp

A backup, archive, and restore utility for users on NetBackup UNIX clients. It has a character-based, menu interface that can be run from terminals that do not have X Windows capabilities.

bpadm

An administrator utility that runs on NetBackup UNIX servers. It has a character-based, menu interface that can be run from terminals that do not have X Windows capabilities.

bp.conf file

A NetBackup configuration file on UNIX servers and also on UNIX, Macintosh, and OS/2 clients.

bp.ini file

NetBackup initialization file for Novell NetWare target clients.

bpcd

NetBackup Client service on Windows NT/2000 and the NetBackup Client daemon on UNIX.

bprd

NetBackup Request Manager service on Windows NT/2000 and NetBackup Request daemon on UNIX.

catalogs

Internal NetBackup and Media Manager databases. These catalogs contain information about configuration, media, devices, status, errors, and the files and directories in the stored backup images.



CDF

Context-dependent file, which is a type of directory structure on a Hewlett-Packard system.

class

Defines the backup policy for a group of one or more clients that have similar backup requirements.

client

The system with the files to back up, archive, or restore.

client-user interface

The program used to perform user backups, archives, and restores.

cluster

See master and media server cluster.

command lines

Commands that users can execute either from the system prompt or in scripts.

compression

The process of compacting data to enable more efficient transmission and storage.

configuration

The parameters that govern the behavior of an application. This term can also refer to the manner in which a network or system is laid out or connected (for example, a network configuration).

cpio

A UNIX command for formatting data on a tape.

ctime

The time that a UNIX inode was changed.

cumulative-incremental backup

A backup that is scheduled by the administrator on the master server and backs up files that have changed since the last successful full backup. All files are backed up if no prior backup has been done. Also see “differential-incremental backup.”



daemon

A program on a UNIX system that runs in the background and performs some task (for example, starting other programs when they are needed). Daemons are generally referred to as services or processes on Windows NT/2000 systems.

database-extension clients

Clients with additional NetBackup software that is designed to back up relational databases.

debug logs

See “activity logs.”

device delays

Delays caused by the device that are beyond the control of the storage application. An example is the time required to position tape under the read and write heads.

device host

A Media Manager host where a drive or robotic control is attached or is defined.

device monitor

A Media Manager administration utility that provides monitoring and manual control of Media Manager storage devices. For example, an administrator or computer room operator can use this utility to manually reset devices or set them to the UP or DOWN state.

DHCP

Dynamic host configuration protocol. This TCP/IP protocol automatically assigns temporary IP addresses to hosts when they connect to the network.

differential-incremental backup

Scheduled by the administrator on the master server and backs up files that have changed since the last successful incremental or full backup. All files are backed up if no prior backup has been done. Also see “cumulative-incremental backup.”

directory depth

The number of levels below the current directory level that the NetBackup interfaces show in their directory and file list displays.



directory tree

The hierarchical structure in which files are organized on a disk. Each directory lists the files and directories that are directly below it in the tree. On UNIX, the topmost directory is called the root directory.

disaster recovery

Recovering data from backups after a disk crash or other catastrophe.

disk

Magnetic or optical disk storage media.

disk-image backup

A bit-by-bit rather than a file system backup of a disk drive on Windows NT/2000.

DLT

Digital-linear tape or tape drive type.

Domain Name Service (DNS)

A program that handles name translation for network communications.

drive cleaning

The use of a special cleaning tape to clean the heads on a drive.

duplicate image

A copy of a backup image.

encryption

Provides additional security by encrypting backup data on the client. This capability is available only with the NetBackup Encryption option.

entry and exit ports

A slot or other opening in a robot where you can insert or remove a tape without having to access the interior of the robot. After inserting a tape, you move it to a slot by using an inject command. Prior to removing a tape, you move it to the port by using an eject command. The inject and eject commands are supported through the add and move screens in the Media Manager administration interface. Entry and exit ports are sometimes called mailslots, or inports and outports.



exclude list

A list that designates files or directories to exclude from automatic backups.

expiration (image)

The date and time when NetBackup stops tracking a backup image.

expiration (volume)

The date and time when the physical media (tape) is considered to be no longer usable.

EVSN

External volume serial number. This is an identifier written on a media cartridge or canister so the operator can identify the volume before inserting it into a drive or robot. For labeled media, the EVSN must be the same as the RVSN (identifier recorded on the media). For all media, the EVSN is the same as the media ID.

FastBackup

A special type of raw-partition backup that can be performed only on an Auspex client (this option is available only for NetBackup DataCenter).

FlashBackup

A special type of raw-partition backup that requires the NetBackup FlashBackup separately-priced option (this option is available only for NetBackup DataCenter).

flush level

Controls how often Netbackup clears its log files on a Novell NetWare or Microsoft Windows client platform.

fragment

A part of a backup or archive image. NetBackup can be configured to divide images into fragments when they exceed a certain size or span tapes.

frequency (backup)

How often NetBackup performs scheduled backups. For example, if the frequency is seven days then backups occur once a week.

FROZEN media state

If a volume is FROZEN, NetBackup keeps it indefinitely and can restore from it but not use it for further backups or archives.



full backup

A backup that copies, to a storage unit, all files and directories that are beneath a specified directory.

FULL media state

If this appears in a report or listing, it indicates the volume is FULL and cannot hold more data or be used for further backups.

global attributes

NetBackup configuration attributes that affect all classes.

Global Data Manager

A separately-priced option (for UNIX servers) that provides an interface with a tree view where the administrator can view and administer multiple master servers. The server where the option is installed is called a Master of Masters.

GNU tar

A public domain version of the UNIX tar program.

goodies directory

A directory containing programs, scripts, and other files that are not formally supported.

gravity stacker

A robot that relies on gravity to advance to the next required tape.

GUI

Graphical user interface.

hard link

On UNIX, a hard link is a pointer to the inode for the data.

heap level

A parameter for memory-heap debugging on a Novell NetWare or Windows NetBackup client.

hierarchical storage management

The process of automatically migrating selected files from a managed file system to specified migration levels on secondary storage, while maintaining transparent access to those files.



host

A computer that executes application programs.

host name

Name by which a host computer is identified by programs and other computers in the network.

HSM

See storage migrator.

image

The collection of data that NetBackup saves for an individual client during each backup or archive. The image contains all the files, directories, and catalog information associated with the backup or archive.

import

The process of recreating NetBackup records of images so the images can be restored.

include list

A list that designates files or directories to add back in from the exclude list.

incremental backup

See “cumulative-incremental backup” and “differential-incremental backup.”

inport

See “entry and exit ports.”

inode

A UNIX data structure that defines the existence of a single file.

install_path

Directory where NetBackup and Media Manager software is installed. The default on Windows NT/2000 is `C:\Program Files\VERITAS` and on UNIX it is `/usr/opensv`.

jbpSA

The Java-based NetBackup interface for performing user backups, archives, and restores.

jnbSA

The Java-based NetBackup interface for administrators.



job

A parcel of work submitted to a computer. NetBackup jobs are backups, archives, or restores.

kernel

The nucleus of an operating system.

keyword phrase

A textual description of a backup.

kill a job

Terminating a job and removing it from the job queue.

label

Identifier of a tape or optical disk volume. A recorded label includes a media ID.

A barcode label allows a barcode scanner to be used for media tracking.

library

Refers to a robot and its accompanying software. A library includes a collection of tapes or optical platters used for data storage and retrieval. For example, a Tape Library DLT (TLD) refers to a robot that has TLD robotic control.

link

See “hard link” or “symbolic link.”

LMF - Library Management Facility

A Media Manager designation for a category of robot. For the specific vendor types and models in this category, see the NetBackup release notes.

This robot type is supported only by NetBackup DataCenter servers.

load

(noun) Amount of work that is being performed by a system or the level of traffic on a network. For example, network load affects performance.

(verb) Copy data to internal memory. For example, load the installation program.

logs

Files where a computer or application records information about its activities.



mailslot

See “entry and exit ports.”

man pages

Online documentation provided with UNIX computer systems and applications.

Master and media server cluster

A NetBackup master server and the remote media servers that it is using for additional storage. It is possible to configure clusters only with NetBackup DataCenter servers. NetBackup BusinessServer supports only a single server, the master.

Master of Masters

A NetBackup host where Global Data Manager software is installed. When logging into this host, the interface has a tree view where the administrator can view and administer multiple master servers.

master server

The NetBackup server that provides administration and control for backups and restores for all clients and servers in a master and media server cluster. NetBackup BusinessServer supports only a single server and it is the master.

media

Physical magnetic tapes, optical disks, or magnetic disks where data are stored.

media host

NetBackup server to which the job (client) is sending the data.

media ID

An identifier that is written on a volume as part of the recorded label.

Media Manager

Software that is part of NetBackup and manages the storage devices and removable media.

Media Manager Host

A host where Media Manager software is installed.



media server

A NetBackup server that provides storage within a master and media server cluster. The master can also be a media server. A media server that is not the master is called a remote media server (or slave server). NetBackup BusinessServer does not support remote media servers.

menu interface

A character-based interface for use on terminals that do not have graphical capabilities.

MHD

See “multihosted drives.”

mount

Make a volume available for reading or writing.

mount point

The point where a file system on a disk logically connects to a system’s directory structure so the file system is available to users and applications.

MPX

See “multiplexing.”

mtime

The point in time when a UNIX or NTFS file is modified.

multihosted drives

A separately priced VERITAS option (Shared Storage Option or SSO) that allows tape drives (standalone or in a robotic library) to be dynamically shared among multiple NetBackup and Storage Migrator servers.

This option is supported only on NetBackup DataCenter servers.

multiplexing

The process of sending concurrent-multiple backups from one or more clients to a single storage device and interleaving those images onto the media.

multiplexed group

A set of backups that were multiplexed together in a single multiplexing session.



NDMP

Network data management protocol. NetBackup requires the NetBackup for NDMP separately-priced option to support NDMP.

NetBackup Client service

NetBackup Windows NT/2000 service that runs on clients and servers and listens for connections from NetBackup servers and clients in the network. When a connection is made, this service starts the necessary programs.

NetBackup configuration options

On UNIX servers and on UNIX and Macintosh, clients, these settings are made in the `bp.conf` file. On NetWare target and OS/2 clients, they are in the `bp.ini` file. On Windows NT/2000 servers and Microsoft Windows clients, these settings are called properties and are made through the Backup, Archive, and Restore interface or the Configure - NetBackup window in the administration interface.

NetBackup databases

See catalogs.

NetBackup Database Manager service

NetBackup Windows NT/2000 service that runs on the master server and manages the NetBackup internal databases (called catalogs). This service must be running on the master server during all NetBackup administrative operations.

NetBackup Device Manager service

The NetBackup Windows NT/2000 service that runs on a NetBackup server and starts the robotic control processes and controls the reservation and assignment of volumes. This service runs only if the server has devices under Media Manager control. The process is `ltid`.

NetBackup properties

Same as NetBackup configuration options but are called NetBackup properties on Microsoft Windows platforms.

NetBackup Request Manager service

The NetBackup Windows NT/2000 service that runs on the master server and starts the scheduler and receives requests from clients.



NetBackup Volume Manager service

A NetBackup Windows NT/2000 service that runs on a NetBackup server, allows remote administration of Media Manager, and manages volume information. The process is `vmd`.

NIS

Network information service.

NLM

NetWare loadable module.

NFS

Network file system.

nonrobotic

See “standalone.”

ODL

Optical disk library. This robot type is supported only by NetBackup DataCenter servers.

OSF and Motif

A set of specifications for user-interface design.

outport

See “entry and exit ports.”

partitions

The logical partitions into which a magnetic disk is divided.

patch

A program that corrects a problem or adds a feature to an existing release of software.

path length

Number of characters in a pathname.

pathname

The list of directories in the path to a destination directory or file.



PC clients

NetBackup clients that have Microsoft Windows (NT/2000, 98, 95), Macintosh, or IBM OS/2 operating systems.

peername

The name by which a computer identifies itself when establishing connections to other systems.

port

A location used for transferring data in or out of a computer.

primary copy

The copy of an image that NetBackup uses to satisfy restores. When NetBackup duplicates an image, the original is designated as the primary copy.

privileges

The tasks or functions that a user, system, or application is authorized to perform.

progress report

Log where NetBackup records events that occur during user operations.

proxy restore

A proxy restore allows the user to restore files, that he has write access to, on a machine other than his desktop. The files must be in a backup of the machine to which they are being restored.

QIC

Quarter-inch-cartridge tape.

queued job

A job that has been added to the list of jobs to be performed.

raw-partition backup

Bit-by-bit backup of a partition of a disk drive on UNIX. On Windows NT/2000, this is called a disk-image backup.

rbak

The program that Apollo clients use to read data from tape during a restore.



registry

A Microsoft Windows 2000, NT, 98, and 95 database that has configuration information about hardware and user accounts.

remote media server

A media server that is not the master. Note that only NetBackup DataCenter supports remote media servers. NetBackup BusinessServer supports only a single server, the master.

residence

In Media Manager, information about the location of each volume is stored in a volume database. This residence entry contains information, such as robot number, robot host, robot type, and media type.

resource

A Novell NetWare term that refers to a data set on the target. For example, in DOS, resources are drives, directories, and files. Also see “target service.”

restore

(verb) The act of restoring selected files and directories from a previous backup or archive and returning them to their original directory locations (or to an alternate directory).

(noun) The process of restoring selected files and directories from a previous backup and returning them to their original directory locations (or to an alternate directory).

retention level

An index number that corresponds to a user-defined retention period. There are 10 levels from which to choose (0 through 9) and the retention period associated with each is configurable. Also see “retention period.”

retention period

The length of time that NetBackup keeps backup and archive images. The retention period is specified on the schedule.

root

The highest level directory in a hierarchical directory structure. In MS-DOS, the root directory on a drive is designated by a backslash (for example, the root on drive C is C:\). On UNIX, the root directory is designated by a slash (/).

Also, a UNIX user name having administration capability.



RS-232

An industry-standard interface for serial communications and sometimes used for communicating with storage peripherals.

RSM Interface

Application in Windows 2000 used to manage Removable Storage Manager (RSM) devices.

RSM - Removable Storage Manager

A Media Manager designation for a category of robot.

Also, a component of the Windows 2000 operating system that manages storage devices.

RVSN

Recorded volume serial number. This is an identifier recorded as part of the label on a volume and used by Media Manager to ensure that the correct volume is mounted. The RVSN is the same as the media ID.

schedules

Controls when backups can occur in addition to other aspects of the backup, such as: the type of backup (full, incremental) and how long NetBackup retains the image.

SCSI

Small computer system interface. This is a type of parallel interface that is frequently used for communicating with storage peripherals.

slave server

See Remote media server.

server directed restore

Using the client interface on the master server to restore files to any client. Only the administrator can perform this operation.

server independent restore

Restoring files by using a NetBackup server other than the one that was used to write the backup. This feature is available only with NetBackup DataCenter.



server list

The list of servers that a NetBackup client or server refers to when establishing or verifying connections to NetBackup servers. On a Windows NT/2000 server and Microsoft Windows clients, you update the list through a dialog box in the interface. On a UNIX server and UNIX and Macintosh clients, the list is in the `bp.conf` file. On NetWare target and OS/2 clients, the list is in the `bp.ini` file.

service

A program on a Windows NT/2000 system that runs in the background and performs some task (for example, starting other programs when they are needed). Services are generally referred to as daemons on UNIX systems.

session

An instance of NetBackup checking its schedules for backups that are due, adding them to its worklist, and attempting to complete all jobs in the worklist. For user backups and archives, a session usually consists of a single backup or archive.

Shared Storage Option (SSO)

See “multihosted drives.”

SMDR

Storage management data requestor, a Novell NetWare program that provides its services transparently to all SMS modules and lets remote and local modules communicate with one another.

SMS

Novell NetWare storage management services.

standalone

A qualifier used with drives and media to indicate they are not associated with a robot. For example, a standalone tape drive is one where you must manually find and insert tapes before using them. A standalone volume is one that is located in a standalone drive or is stored outside of a drive and designated as standalone in the volume configuration.

status code

A numerical code, usually accompanied by a message, that indicates the outcome of an operation.



storage migrator

Refers to the VERITAS Storage Migrator line of hierarchical storage management products for UNIX and Windows NT/2000. These products make extra room on a disk by transparently moving data to other storage and then transparently retrieving the data when it is needed by a user or application.

Storage Migrator is available only for NetBackup DataCenter servers.

storage unit

Refers to a storage device where NetBackup or Storage Migrator stores files. It can be a set of drives in a robot or consist of one or more single tape drives that connect to the same host.

SUSPENDED media state

If a volume is SUSPENDED, NetBackup can restore from it but cannot use it for backups. NetBackup retains a record of the Media ID until the last backup image on the volume expires.

symbolic link

On a UNIX system, this is a pointer to the name of the file that has the source data.

tape format

The format that an application uses to write data on a tape.

tape marks

A mark that is recorded between backup images on a tape.

tape overhead

The space required for data that is not part of the backup images. For example, tape marks and catalogs of what are on the tape are considered overhead.

tape spanning

Using more than one tape to store a single backup image.

tar

Tape ARchive program that NetBackup uses to extract backup images during a restore.

target

See “target service.”



target service

A Novell NetWare service that needs storage management. The SMS views all services (for example, print services, communication services, workstations) as targets.

Target Service Agent

A Target-service agent is a Novell NetWare agent that prepares the target's data for SMS during a backup and for the target during a restore.

TLD - Tape Library DLT

A Media Manager designation for a category of robot. For the specific vendor types and models in this category, see the NetBackup release notes.

TLH - Tape Library Half-inch

A Media Manager designation for a category of robot. For the specific vendor types and models in this category, see the NetBackup release notes.

This robot type is supported only by NetBackup DataCenter servers.

TLM - Tape Library Multimedia

A Media Manager designation for a category of robot. For the specific vendor types and models in this category, see the NetBackup release notes.

This robot type is supported only by NetBackup DataCenter servers.

TL4 - Tape Library 4MM

A Media Manager designation for a category of robot. For the specific vendor types and models in this category, see the NetBackup release notes.

TL8 - Tape Library 8MM

A Media Manager designation for a category of robot. For the specific vendor types and models in this category, see the NetBackup release notes.

timeout period

The period of time that an application has allotted for an event to occur.

TIR

See "true image restore."



tpconfig

A Media Manager administration utility for configuring devices and is started from the command line. On UNIX, it has a character-based, menu interface that can be run from terminals that do not have X Windows capabilities.

transfer rate

The rate at which computer information is transferred between a source and a destination.

true image restore

Restores the contents of a directory to what it was at the time of any scheduled full or incremental backup. Previously deleted files are ignored.

TS8 - Tape Stacker 8MM

A Media Manager designation for a category of robot. For the specific vendor types and models in this category, see the NetBackup release notes.

TSA

“Target Service Agent.”

TSH - Tape Stacker Half-inch

A Media Manager designation for a category of robot. For the specific vendor types and models in this category, see the NetBackup release notes.

This robot type is supported only by NetBackup DataCenter servers.

user operation

A backup, archive, or restore that is started by a person on a client system.

verbose flag

Configuration file entry that causes a higher level of detail to be written in the logs.

verify

An operation that compares the list of files that are actually on a volume with what NetBackup has recorded as being on it. The data that is on the media is not verified.

vmadm

A Media Manager administrator utility for managing volumes. It runs on UNIX and has a character-based, menu interface that can be run from terminals that do not have X Windows capabilities.



vm.conf

A Media Manager configuration file with entries that include the servers that can manage local devices and default media ID prefixes for media that do not contain barcodes.

volume

Media Manager volumes are logical units of data storage or cleaning capability on media that have been assigned media IDs and other attributes, which are recorded in the Media Manager volume database.

volume configuration

Refers to configuration information that is stored in the Media Manager volume database.

volume database

An internal database where Media Manager keeps information about volumes. All Media Manager hosts have a volume database. However, the database is empty unless the host is designated as a volume database host.

volume database host

The Media Manager host that contains information about the volumes that Media Manager uses in a device. Because NetBackup BusinessServer supports only a single server, the volume database host is always the Media Manager host.

volume group

A set of volumes that are configured within Media Manager to reside at the same physical location (for example, in a specific robot).

volume pool

A set of volumes that are configured within Media Manager to be used by a single application and are protected from access by other applications and users.

wakeup interval

The time interval at which NetBackup checks for backups that are due.

wbak

The program that Apollo clients use to write data on tape.

wildcard characters

A character that can be used to represent other characters in searches.



WORM media

Write-once, read-many media for optical disks. NetBackup BusinessServer does not support WORM media.

Windows Display Console

A NetBackup-Java interface program that runs on Windows 2000, NT, 98, and 95 computers. Users and administrators can start this interface on their local system, connect to a UNIX system that has the NetBackup-Java software installed, and then perform any user and administrator operations that their permissions allow.

xbp

The X Windows-based backup, archive, and restore program for users on NetBackup UNIX clients.

xbpadm

The X Windows-based NetBackup administration interface on UNIX. This interface is available only with NetBackup DataCenter.

xbpmon

The X Windows-based NetBackup utility for monitoring jobs on UNIX. This utility is available only with NetBackup DataCenter.

xdevadm

The X Windows-based Media Manager utility for managing devices on UNIX. This interface is available only with NetBackup DataCenter.

xvmadm

The X Windows-based Media Manager utility for managing media on UNIX. This interface is available only with NetBackup DataCenter.





Index

A

- ACS (see Automated Cartridge System)
- Administrator, definition xi
- AIX (see RS6000)
- Alternate client restores
 - definition 160
- Alternate path restore
 - definition 160
- Alternate target restore
 - definition 160
- arch command 40
- Archive bit
 - definition 160
- Archives
 - definition 160
- AT&T style close 53, 98, 113, 156
- autoconfig command 132
- Automated Cartridge System
 - on HP9000-700 96
 - on HP9000-800 106
 - on Sun4/SPARC 43

B

- Backup frequency
 - definition 165
- Backup images, definition 167
- Backup windows
 - definition 161
- Backups
 - definition 160
- Berkeley-style close
 - on HP9000-700 98
 - on HP9000-800 113
 - on Pyramid 156
 - on Sun4/SPARC 53
- boot -r
 - on Sun4/SPARC 70
- bp.conf file
 - definition 161

C

- chdev command 93
- Client user interface 162
- Clients, NetBackup
 - definition 162
- Command summary
 - for DEC Alpha 141
 - for HP9000-700 104
 - for HP9000-800 117
 - for RS6000 93
 - for SGI IRIX 132
 - for Sun4/SPARC 69
 - for SunOS 40
- config command 40
- Corsair, HP (see HP 1.2 GB optical)

D

- DAT (see HP 4-mm DAT)
- DEC Alpha
 - introduction 133
 - locate-block 136
 - SCSI robotic controls 134
 - example device files 135
 - make device files 134
 - tape drive configuration
 - example device files 138
 - make device files 136, 137
- DEC DLT (see Quantum DLT)
- Device drivers
 - ovpass 73
 - sd
 - on Sun4/SPARC 68
 - on SunOS 37
 - SG
 - on Sun4/SPARC 49
 - on SunOS 20
 - spt (SCSI pass through)
 - on HP9000-800 108
 - st 57



Disk-image backup
definition 164
DLT, definition 164
dmesg command 40

E

Exabyte compression drives
on SunOS 29
Extended file marks 80

F

Fast-tape positioning (see locate-block)
Fixed mode devices 55, 80
Forward-space-record 53

H

HP 1.2 GB optical
on RS6000 73, 87
on SunOS 36
HP 4-mm DAT
on RS6000 84
on SGI IRIX 125
on Sun4/SPARC 62
on SunOS 30
HP C1560B DAT Autoloader
logical unit number 26
on RS6000 84
on SGI IRIX 125
on Sun4/SPARC 62
on SunOS 30
HP optical disk
on HP9000-700 102
on HP9000-800 116
on RS6000 87
on SGI IRIX 131
on Sun4/SPARC 66
on SunOS 35
HP9000-700
introduction 95
optical disk configuration
example device files 102
make device files 102
SCSI robotic controls 96
example device files 97
make device files 96
SCSI, core I/O 96
SCSI, on board 96
tape drive configuration
Berkeley-style close 98
example device files 99

make device files 98
HP9000-800
introduction 105
optical disk configuration
example device files 116
make device files 116
SCSI robotic controls 106
example device files 108, 110
make device files 108, 109
spt (SCSI pass through) driver 108
SCSI, core I/O 109
SCSI, on board 109
tape drive configuration
Berkeley-style close 113
example device files 114
make device files 114
HSM 167

I

IBM RS6000 (see RS6000)
install_ovpass script 73, 93
install_path 167
ioscan command
for HP9000-700 104
on HP9000-800 117
IRIX (see SGI IRIX)

K

Kernel changes
DEC Alpha 139
Sequent 152
SGI IRIX
for HP 4-mm DAT drives 125
for Quantum DLT 129
SunOS
for Exabyte compression 29
for HP 4-mm DAT drives 30
for Quantum DLT 33
for STK drives 32

L

Library, definition 168
locate-block
on DEC Alpha 136
on RS6000 80
on SGI IRIX 124
on Sun4/SPARC 53
Logical unit numbers
on HP C1560B 26
on Sun4/SPARC 57



- on SunOS 25
 - lsdev command
 - on DEC Alpha 141
 - on HP9000-800 117
 - on RS6000 93
 - lun (see logical unit numbers)
- M**
- make command 40
 - MAKEDEV
 - on DEC Alpha 141
 - on SGI IRIX 132
 - on SunOS 40
 - Media host, definition 169
 - Media Manager host
 - definition 169
 - Media server
 - definition 170
 - mediad command 121
 - mkdev command 93
 - mknod command 141
 - mksf command 104
 - modinfo command 69
 - modstat command 40
 - modunload command 40
 - motd file 40
 - multiple logical unit numbers 58
- N**
- NetBackup Client service
 - definition 171
 - NetBackup configuration options
 - definition 171
 - NetBackup Database Manager service
 - definition 171
 - NetBackup Device Manager service
 - definition 171
 - NetBackup Request Manager service
 - definition 171
 - NetBackup Volume Manager service
 - definition 172
 - NetWare Loadable Module 172
 - NLM (see NetWare Loadable Module)
 - Nonrobotic, definition 172
- O**
- Optical disk
 - on HP9000-700 102
 - on HP9000-800 116
 - on RS6000 87
 - on SGI IRIX 131
 - on Sun4/SPARC 66
 - on SunOS 35
 - ovpass driver 73
- P**
- Pass-through driver (see SCSI)
 - Psuedo-device file 148, 150
- Q**
- Quantum DLT
 - on SGI IRIX 129
 - on SunOS 33
- R**
- Raw partition backups
 - definition 173
 - Related manuals xii
 - rem_drv command 45, 69
 - Remote media server
 - definition 174
 - remove_ovpass command 93
 - Resource (also see Target service) 174
 - Restores
 - definition 174
 - Retention period
 - definition 174
 - Robotic controls
 - SCSI
 - on DEC Alpha 134
 - on HP9000-700 96
 - on HP9000-800 106
 - on RS6000 74, 78
 - on Sequent 148
 - on SGI IRIX 122
 - on Sun4/SPARC 49
 - on SunOS 20
 - root 174
 - RS6000
 - introduction 71
 - adapter numbers 72
 - install_ovpass driver
 - loading 73
 - unloading 73
 - install_ovpass script 73
 - locate-block 80
 - optical disk configuration
 - make device files 87
 - example device files 88
 - set in nonvolatile memory 89



- ovpass driver 73
 - pass-through driver 73
 - SCSI pass-through driver 73
 - SCSI robotic controls 74, 78
 - example device files 76
 - make device files 74, 78
 - smit tool 71
 - tape drive configuration
 - example device files 82
 - extended file marks 80
 - HP 4-mm DAT 84
 - make device files 81
 - multiple densities 83
 - Sony AIT 84
 - variable mode devices 80
- S**
- scip SCSI controller 120
 - Scripts
 - /etc/rc.local (SunOS) 21
 - install_ovpass 73
 - sg.install
 - on Sun4/SPARC 45
 - on SunOS 21
 - sgscan 22, 28, 40, 49, 50, 53, 54, 62, 64, 66, 70
 - spscan 41
 - vmconf 41
 - SCSI
 - integral, on SGI IRIX 119
 - kernel ID mapping
 - on SunOS 24
 - logical unit numbers
 - on Sun4/SPARC 57
 - on SunOS 25
 - on board
 - on HP9000-700 96
 - on HP9000-800 109
 - on SGI IRIX 119
 - pass-through driver
 - on RS6000 73
 - on Sun4/SPARC 45
 - robotic control
 - on DEC Alpha 134
 - on HP9000-700 96
 - on HP9000-800 106
 - on RS6000 74, 78
 - on Sequent 148
 - on SGI IRIX 122
 - on SunOS 20
 - spt (SCSI pass through) driver
 - on HP9000-800 108
 - scsi_command
 - on RS6000 91, 94
 - on Sun4/SPARC 67, 70
 - on SunOS 36
 - sd driver
 - on Sun4/SPARC 68
 - on SunOS 37
 - Server directed restore
 - definition 175
 - Session, NetBackup 176
 - SG driver
 - on Sun4/SPARC 49
 - on SunOS 20
 - rem_drv 45
 - sg.build command 69
 - sg.install script
 - on Sun4/SPARC 45, 69
 - on SunOS 21, 40
 - SGI IRIX
 - introduction 119
 - kernel changes
 - for HP 4-mm DAT 125
 - for Quantum DLT 129
 - locate-block 124
 - mediaid command 121
 - optical disk configuration
 - example device files 131
 - make device files 131
 - SCSI
 - integral 119
 - on-board 119
 - SCSI robotic controls 122
 - example device files 122
 - tape drive configuration
 - example device files 124
 - HP 4-mm DAT 125
 - make device files 124
 - Quantum DLT 129
 - using scip controllers 120
 - SMS (see Storage Management Services)
 - Sony AIT
 - on RS6000 84
 - on Sun4/SPARC 63
 - Sony AIT-2
 - on Sun4/SPARC 63
 - SPARC



- running Solaris 43
 - spt driver (see SCSI)
 - st driver 57
 - st.conf.c file 55
 - st_conf.c file 29
 - ST_KNOWS_EOD attribute 30
 - Standalone
 - definition 176
 - stdef.h file 32
 - STK drives 32
 - Storage Management Services 176
 - Storage Migrator xi, 177
 - Storage units
 - definition 177
 - Sun4/SPARC 45
 - introduction 43
 - adapter card removal 43
 - locate-block 53
 - optical disk configuration
 - example device files 67
 - make device files 66
 - set in nonvolatile memory 67
 - SCSI pass-through driver 45
 - SCSI robotic controls 49
 - SG driver
 - loading 45
 - unloading 45
 - sg.install script 45
 - st driver 57
 - st.conf.c file 55
 - tape drive configuration
 - Berkeley-style close 53
 - example device files 54, 64
 - HP 4-mm DAT 62
 - make device files 53
 - Sony AIT 63
 - Sony AIT-2 63
 - variable mode devices 55
 - using ACS 43
 - SunOS
 - kernel changes
 - for Exabyte compression 29
 - for HP 4-mm DAT 30
 - for Quantum DLT 33
 - for STK drives 32
 - kernel, rebuilding 38
 - optical disk configuration
 - example device files 36
 - make device files 35
 - set in nonvolatile memory 36
 - SCSI ID mapping
 - introduction 24
 - change device assignment 25
 - check device assignment 25
 - finding conf file 24
 - logical unit numbers 25
 - SCSI robotic controls 20
 - loading SG driver 20
 - SG driver
 - loading 21
 - unloading 21
 - sg.install script 21
 - st_conf.c file 29
 - ST_KNOWS_EOD attribute 30
 - stdef.h file 32
 - tape drive configuration
 - make device files 27
 - Exabyte compression 29
 - example device files 28
 - HP 4-mm DAT 30
 - Quantum DLT 33
 - STK drives 32
 - Switch settings, HP 4-mm DAT
 - on DEC Alpha 139
 - on HP9000-700 100
 - on HP9000-800 115
 - on RS6000 84
 - on SGI IRIX 125
 - on Sun4/SPARC 62
 - on SunOS 31
 - Switch settings, Sony AIT
 - on RS6000 85
 - on Sun4/SPARC 64
 - Switch settings, Sony AIT2
 - on Sun4/SPARC 64
- T**
- Tape drive configuration
 - on DEC Alpha 136, 137
 - on HP9000-700 98
 - on HP9000-800 114
 - on RS6000
 - HP 4-mm DAT 84
 - make device files 81
 - Sony AIT 84
 - on SGI IRIX
 - HP 4-mm DAT 125
 - make device files 124



-
- Quantum DLT 129
 - on Sun4/SPARC
 - HP 4-mm DAT 62
 - make device files 53
 - Sony AIT 63
 - Sony AIT-2 63
 - on SunOS
 - make device files 27
 - Exabyte compression 29
 - HP 4-mm DAT 30
 - Quantum DLT 33
 - STK 32
 - Target Service 178
 - tpconfig, definition 179
 - True image restore
 - definition 179
- V**
- Variable-mode devices
 - on RS6000 80
 - on Sun4/SPARC 55
 - vm.conf file
 - definition 180
 - vmadm, definition 179
 - vmconf script 41, 70, 94, 132, 142
 - vmunix file 38
 - Volume database host
 - definition 180
 - Volume database, definition 180
 - Volume group
 - definition 180
 - Volume pool
 - definition 180
- W**
- WORM media
 - definition 181